



All products are trademarks of Nostalgia Products Group, LLC.
Worldwide design & utility patented or patents pending.
© 2011 Nostalgia Products Group, LLC.

www.nostalgiaelectrics.com

(rev. 03/21/13)



ICE100COKE
SERIES

Coca-Cola™ Automatic Ice Cube Maker

Instructions and Recipes



CONTENTS

IMPORTANT PRECAUTIONS	3
IMPORTANT SAFEGUARDS	3
INTRODUCTION	4
PARTS & ASSEMBLY	5
HOW TO OPERATE	5
HELPFUL TIPS	7
CLEANING & MAINTENANCE	7
RECIPES	8
RETURNS & WARRANTY	10

SAFETY

Your safety and the safety of others are very important.

We have provided many important safety messages in this manual and on your appliance. Always read and obey all safety messages.



This is the safety alert symbol.

This symbol alerts you to potential hazards that can kill or hurt you and others.

All safety messages will follow the safety alert symbol.

All safety messages will tell you what the potential hazard is, tell you how to reduce the chance of injury, and tell you what can happen if the instructions are not followed.

Appliance Specifications:

115 Volts, 60 Hz

Ice Making Current - 1.9A, Ice Harvest Current - 2.7A


Refrigerant R134a, ETL Approved

IMPORTANT PRECAUTIONS

1. NEVER immerse in water.
2. NEVER use near water.
3. NEVER use an abrasive sponge, cloth or scouring pad on the unit.
4. NEVER leave appliance unattended while in use.
5. NEVER force the cover to lock.
6. Unplug unit from outlet when not in use and during cleaning.
7. DO NOT operate this appliance with a damaged cord or plug, nor if the appliance ever malfunctions.
8. DO NOT clean any parts of this appliance in a dishwasher.
9. Keep out of reach of children.
10. This appliance is NOT A TOY.
11. Unsupervised young children and cognitively challenged individuals should never operate this appliance.
12. Young children should be supervised while in proximity of the appliance to ensure their safety.

IMPORTANT SAFEGUARDS

Basic safety precautions should always be followed when using electrical appliances, including the following:

1. Read all instructions before operating this appliance.
2. To protect against electrical shock do not immerse cord, plug or any part of this appliance in water or other liquids.
3. Close supervision is necessary when any appliance is used near children.
4. Unplug from outlet when not in use, before removing parts and before cleaning.
5.  DO NOT clean unit with flammable liquids. The fumes can create a fire hazard or explosion.
6. DO NOT operate any appliance with a damaged cord or plug, nor if the appliance has been damaged in any manner. Return the appliance to the nearest repair shop for examination or repair.
7. The manufacturer does not recommend the use of accessory attachments. Use of accessory attachments may cause injuries.
8. Position the appliance as close to the outlet as possible to prevent injury due to tripping over cord.
9. DO NOT run the power cord over carpeting or heat insulators. DO NOT cover the cord or submerge cord in water.
10. DO NOT let the cord hang over the edge of a table or counter top or touch hot surfaces.
11. DO NOT place on or near a hot gas or electric burner, or in a heated oven.
12. Extreme caution must be used when moving this appliance.

13. DO NOT use the appliance for other than its intended use.
 14. An appliance that is plugged into an outlet should not be left unattended.
 15. Check Ice Hopper for presence of foreign objects prior to use.
 16. DO NOT turn unit upside down while in use, or when filled with ice.
 17. A short power supply cord is provided to reduce the risk resulting from becoming entangled or tripping over a long cord.
 18. Longer detachable power supply cords can be used if care is exercised in their use.
 19. The marked electrical rating of an extension cord should be at least as great as the electrical rating of the appliance.
- 20. Save these instructions!**


INTRODUCTION

Thank you for purchasing The COCA-COLA™ ICE CUBE MAKER from Nostalgia Electrics! This stylish and portable ice maker combines the classic look of your favorite soda with the functionality of a modern appliance. With its intuitive, easy-to-use design, you'll be making perfect ice cubes soon after you plug your new appliance in!

The COCA-COLA™ ICE CUBE MAKER can be used indoors and outdoors in places such as:

- Family Room
- Office
- Club House
- On a Boat
- Kitchen
- Patio or Deck

PARTS & ASSEMBLY



1. Cover: Has transparent window to allow interior visibility
2. Ice Scoop (inside)
3. Ice Shovel
4. Control Panel:
 - A. Display of selected ice size: Small or Large
 - B. Power Indicator
 - C. Ice Indicator (lights up when the Ice Basket is full)
 - D. Add Water Indicator (lights up when it is time to add water to Water Reservoir)
 - E. ON/OFF Power Button
 - F. Ice Size Button (press to select the size of ice cubes)
5. Water Drain Cap: For draining water from Water Reservoir
6. Air Outlet

HOW TO OPERATE

BEFORE FIRST USE

1. Remove the exterior and interior packaging. Make sure that the Ice Basket and Ice Scoop are included. If any parts are missing, please contact Customer Service at the phone number listed on the Returns and Warranty page of this manual.
2. Take out the Ice Basket and clean it. Clean the interior using a soft cloth and mixture of mild soap and warm water.
3. Use the soapy water to rinse the inside parts, and drain out the water by unplugging the Water Drain Cap on the side.

4. Find a location for your COCA-COLA™ ICE CUBE MAKER that is protected from direct sunlight and other sources of heat (i.e. stove, furnace, radiator). Place the COCA-COLA™ ICE CUBE MAKER on a flat, level surface. Make sure that there is at least four inches of empty space all around the COCA-COLA™ ICE CUBE MAKER.
5. Confirm that the chosen location for placing your COCA-COLA™ ICE CUBE MAKER is near an electrical outlet.
6. Allow one hour for the refrigerant fluid to settle before plugging the cord into an outlet for the first time.

CONNECTING YOUR COCA-COLA™ ICE CUBE MAKER

Improper use of the grounded plug can result in the risk of electrical shock. DO NOT use the machine if the power cord is damaged.

Plug your appliance into a properly installed, grounded wall outlet. Do not, under any circumstances, cut or remove the third (ground) prong from the power cord. Any questions concerning power and/or grounding should be directed toward a certified electrician.

USING YOUR COCA-COLA™ ICE CUBE MAKER

1. Open the cover, remove the Ice Basket and pour water into the Water Reservoir. Keep the water level below the level mark.
2. Press the ON/OFF Power Button on the Control Panel to begin the ice-making cycle.
3. Select the desired size of the ice cubes by pressing the Ice Size Button. If the room temperature is lower than 60°F (16°C), it is recommended to select the small- or medium-sized ice cubes in order to keep ice from sticking together.
4. The ice making cycle lasts 6 to 15 minutes, depending on the size of the ice cube selection and the ambient temperature. In extremely hot temperatures, ice-making time may vary considerably.
5. While the ice maker is on, verify water level periodically. If the water pump cannot inject water, the COCA-COLA™ ICE CUBE MAKER will stop automatically, and the Add Water Indicator light will turn on.
6. Press the ON/OFF Power Button to turn the unit OFF, fill water up to the level mark and press the ON/OFF Power Button again to turn the unit ON again.
7. The COCA-COLA™ ICE CUBE MAKER automatically stops working when the Ice Basket is full and the Ice Indicator light comes on.
8. Change the water in the Water Reservoir every 24 hours to ensure a reasonable hygiene level. If the unit isn't in use, drain all water left in the tank.

IMPORTANT NOTE: In the event that the COCA-COLA™ ICE CUBE MAKER power is disconnected during the ice making cycle or that the LED lights on the Control Panel are blinking, press the ON/OFF Power Button to stop the ice making cycle. Unplug the unit from the power source. Let the COCA-COLA™ ICE CUBE MAKER sit for a few minutes to let it warm up and allow ice to fall from the evaporator fingers. Empty the Water Tray and wait three minutes before restarting the unit.



DO NOT touch the Evaporator while the unit is in use or during the ice making process. This could cause severe burns.

HELPFUL TIPS

ADD WATER INDICATOR

If the Add Water Indicator comes on, try the following:

- Turn off the Ice Maker, add water and press the POWER Button again to restart the unit.
- There may be too much ice. Turn off the Ice Maker, remove some ice from the Ice Basket.

ICE CUBES STICK TOGETHER

- The ice cycle may be too long. Stop the Ice Maker, then restart it when the ice cubes melt. Select smaller sized ice cubes using the Ice Size Button.
- The water temperature in the Water Reservoir may be too low. Change the water in the Water Reservoir. The temperature should be set between 45° F - 90° F.

ICE MAKER NOT WORKING

If the ice making cycle seems to be running properly, but no ice is being made, try the following:

- The ambient temperature or water temperature in Water Reservoir may be too high. The Ice Maker must be in an environment below 90° F. Try pouring colder water (between 45° F - 90° F) into the Water Reservoir.
- If changing the water or allowing the Ice Maker to cool does not work, there may be a leakage of the refrigerant fluid, or a pipe in the cooling system may be blocked. Please take the Ice Maker to a qualified technician for repair.

LED LIGHTS

- If the LED lights on the Control Panel are blinking, there may be a disruption in the power source. Press the ON/OFF Power Button to stop the ice-making cycle. Let the Ice Maker sit for a few minutes to let it warm up and allow ice to fall from the evaporator fingers. Empty the Water Tray and wait three minutes before restarting the unit.

CLEANING & MAINTENANCE

Your COCA-COLA™ ICE CUBE MAKER should be cleaned after each use. This will help to maintain the unit and add to longevity.

- Unplug the unit.
- Take out the Ice Basket.
- Clean the interior with a soft cloth using warm water mixed with a mild soap.
- Use warm water to rinse the interior, and drain out the water by unplugging the Drain Cap.
- The outside of the COCA-COLA™ ICE CUBE MAKER should be cleaned regularly with a soft cloth using a mild soap mixed in warm water.
- Dry the interior and exterior with a non-abrasive soft cloth or towel.
- If the machine is not in use for a long time, always open the Water Drain Cap and completely drain the water from the Water Reservoir.

RECIPES

Your COCA-COLA™ ICE CUBE MAKER can be used to instantly make ice cubes to be for a variety of beverages. Here are some delicious beverages that you can make at home.

MUDDY WATER

- 1 Bottle Coca-Cola
- 1 Bottle Orange Juice
- Ice

Fill 1/4 of each glass with ice made with your COCA-COLA™ ICE CUBE MAKER.

Pour orange juice until the glass is half full, or to taste.

Pour Coca-Cola until glass is full.

Stir well.

ROY ROGERS

- 6-8 oz. Coca-Cola
- 1/4 oz. grenadine
- Maraschino cherries
- Ice

Fill glasses with ice from your COCA-COLA™ ICE CUBE MAKER.

Add in Coca-Cola and grenadine.

Stir well.

Add maraschino cherry as garnish.

ALL AMERICAN

- 1 oz. Bourbon Whiskey
 - 1 oz. Southern Comfort
 - 2 oz. Coca-Cola
- Fill glass half way with ice from your COCA-COLA™ ICE CUBE MAKER.
- Combine Bourbon Whiskey, Southern Comfort and Coca-Cola in glass.
- Stir thoroughly.

VANILLA COKE

- 1 oz. Vodka
 - 1 oz. Vanilla Schnapps
 - Coca-Cola to taste
- Fill tall glass with ice from your COCA-COLA™ ICE CUBE MAKER.
- Combine vodka and vanilla schnapps in glass. Stir.
- Add Coca-Cola until glass is full or to taste.

TEXAS TEA

- 3/4 oz. Vodka
 - 3/4 oz. Rum
 - 3/4 oz. Gin
 - 3/4 oz. Triple Sec
 - 3/4 oz. Tequila
 - 1 1/2 oz. Sour Mix
 - splash of Orange Juice
 - Coca-Cola to taste
- Combine vodka, rum, gin, triple sec, tequila and sour mix and shake with ice from your COCA-COLA™ ICE CUBE MAKER. Pour into glass.
- Add in orange juice and Coca-Cola to taste.

RETURNS & WARRANTY

SHOULD YOUR UNIT NOT WORK OR IS DAMAGED WHEN YOU FIRST TAKE IT OUT OF THE BOX, PLEASE RETURN IT TO THE PLACE OF PURCHASE IMMEDIATELY.

COCA-COLA™ ICE CUBE MAKER / ICE100COKE SERIES

Should you have any questions, please contact us via email or at the customer service number listed below between the hours of 8:00 AM and 5:00 PM, Monday through Friday, Central Standard Time.

Distributed by:

Nostalgia Products Group LLC
1471 Partnership Dr.
Green Bay, WI 54304-5685
Customer Service
Phone: (920) 347-9122
Web: www.nostalgielectrics.com

Customer Service Inquiry

To submit a Customer Service inquiry, go to www.nostalgielectrics.com and fill out the Customer Service Inquiry form and click the Submit button.

A representative will contact you as soon as possible.

This appliance is designed and built to provide many years of satisfactory performance under normal household use. The distributor pledges to the original owner that should there be any defects in material or workmanship during the first 90 days of purchase, we will repair or replace the unit at our option. Our pledge does not apply to damages caused by shipping, mishandling or unit being dropped. A product deemed defective either from manufacturing or being mishandled is up to the distributor's discretion. In order to obtain service under this warranty, please contact Nostalgia Products Group, LLC at the telephone number listed above or by filling out the Customer Service Inquiry Form located at www.nostalgielectrics.com.

This product is not recommended for use outside of North America. The warranty is void if products are exported outside of the USA, Canada or Mexico.

This warranty does not apply to re-manufactured merchandise.

Please read these instructions carefully. Failure to comply with these instructions, damages caused by improper replacement parts, abuse or misuse will void this pledge to you and is being made in place of all other expressed warranties.

For more information, visit us online at www.nostalgielectrics.com.

**Like us on Facebook at www.facebook.com/NostalgiaElectrics.
Follow our boards on Pinterest at www.pinterest.com/nostalgielectrx.
Tweet along with us on Twitter at www.twitter.com/NostalgiaElctrx.**