

Use and Care Manual for Camping Chair with Canopy

1. Safe Usage Guidelines

- **Weight Limit:** Maximum load capacity of **265 lbs (120 kg)**. Avoid standing or bouncing on the chair.
- **Canopy Use:**
 - Deploy the canopy in light rain only; avoid prolonged exposure to heavy downpours.
 - In windy conditions, secure the canopy's wind ropes to nearby stakes or anchors.
- **Sharp Objects:** Keep away from knives, fire pits, or rough surfaces to prevent fabric damage.

2. Setup & Adjustment

Canopy Deployment

1. Unfold the chair and lock the frame into place.
2. Pull the canopy upward from the backrest and secure it with the built-in clips.
3. Adjust the canopy angle using the rear baffle for optimal sun/rain protection.

Folding for Storage

1. Release all canopy clips and fold the canopy flat against the backrest.
2. Collapse the chair frame by pushing the seat and backrest together.
3. Slide into the backpack-style carry bag and fasten the straps.

3. Maintenance Tips

Cleaning

- **Daily Use:** Wipe dirt with a damp cloth.
- **Deep Cleaning:** Use mild soap and water; rinse and air-dry.
- **Avoid:** Bleach, harsh chemicals, or machine washing (may damage waterproof coating).

Frame Care

- Regularly check for loose screws or rust on the metal frame.
- Lubricate moving parts with silicone spray if they become stiff.

Storage

- Store in a dry, shaded area. Avoid prolonged sunlight exposure to prevent fabric fading.
- For long-term storage, ensure the chair is fully dry and folded loosely to avoid creasing.