



Play Action®



Climbing Bar Kit

Safety Guide & Assembly Instructions



Important!

Intended for residential use by children ages 2 to 10, only on properly installed PlayStar playsets. Before use refer to complete safety guidelines in your original playset, at www.playstarinc.com, or at 1-888-752-9782.

We're Here To Help!

Call Toll Free **1-888-752-9782**
Customer Service: Monday - Friday, 8:00 A.M. to 5:00 P.M. C.S.T.

PS 7766



SAFETY

- This product is intended for single-family residential use only, by children ages two to ten and a maximum weight of 105 pounds. Any recommendation over 10 years of age or 105 pounds exceeds the upper limits specified in the American Society for Testing and Materials (ASTM) Home Playground Safety Standard. In order for PlayStar to comply with the ASTM Standard, we cannot recommend anyone above these limits.
- It is a misuse of this product when installed or used in places of public assembly such as schools or parks.
- Follow the instructions provided, do not alter its design in any way.
- Construction requires at least two adults capable of heavy lifting.
- Thoroughly read all safety instructions before beginning.
- Children must remain clear of construction site until this product is properly installed and ready for use.
- Save these instructions in the event the manufacturer has to be contacted.

The Consumer Product Safety Commission provides the following consumer information for your Home Playground Equipment

Select Protective Surfacing

One of the most important things you can do to reduce the likelihood of serious head injuries is to install shock-absorbing protective surfacing under and around your play equipment. The protective surfacing should be applied to a depth that is suitable for the equipment height in accordance with ASTM F1292. There are different types of surfacing to choose from; whichever product you select, follow these guidelines:

NOTE: Do not install home playground equipment over concrete, asphalt, or any other hard surface. A fall onto a hard surface can result in serious injury to the equipment user. Grass and dirt are not considered protective surfacing because wear and environmental factors can reduce their shock absorbing effectiveness. Carpeting and thin mats are generally not adequate protective surfacing. Ground level equipment -- such as a sandbox, activity wall, playhouse or other equipment that has no elevated play surface -- does not need any protective surfacing.

Loose-Fill Materials

PlayStar Playsets require fall-height protection from eight feet.

- Maintain a minimum depth of 9 inches of loose-fill materials such as wood mulch / chips, engineered wood fiber (EWF), or shredded/recycled rubber mulch for

equipment up to 8 feet high. NOTE: An initial fill level of 12 inches will compress to about a 9-inch depth of surfacing over time. The surfacing will also compact, displace, and settle, and should be periodically refilled to maintain at least a 9-inch depth.

- Use containment, such as digging out around the perimeter and/or lining the perimeter with landscape edging. Don't forget to account for water drainage.
- Check and maintain the depth of the loose-fill surfacing material. To maintain the right amount of loose-fill materials, mark the correct level on play equipment support posts. That way you can easily see when to replenish and/or redistribute the surfacing.
- **Do not** install loose fill surfacing over hard surfaces such as concrete or asphalt.

Poured-In-Place Surfaces or Pre-Manufactured Rubber Tiles

You may be interested in using surfacing other than loose-fill materials -- like rubber tiles or poured-in-place surfaces.

- Installations of these surfaces generally require a professional and are not "do-it-yourself" projects.
- Review surface specifications before purchasing this type of surfacing. Ask the installer/manufacturer for a report showing that the product has been tested to the following safety standard: ASTM F1292 *Standard Specification for Impact Attenuation of Surfacing Materials within the Use Zone of Playground Equipment*. This report should show the specific height for which the surface is intended to protect against serious head injury.


This height should be equal to or greater than the *fall height* - vertical distance between a designated play surface (*elevated surface for standing, sitting, or climbing*) and the protective surfacing below - of your play equipment.

- Check the protective surfacing frequently for wear.

Placement

Proper placement and maintenance of protective surfacing is essential. Be sure to;

- Extend surfacing at least 6 feet from the equipment in all directions.
- For to-fro swings, extend protective surfacing in front of and behind the swing to a distance equal to twice the height of the top bar from which the swing is suspended.



SAFETY

INSTALLATION:

1. Follow the instructions provided, do not alter its design in any way.
2. Place the playset on level ground, not less than 6' (1.8m) from any structure or obstruction such as a fence, garage, house, overhanging branches, laundry lines or electrical wires. If the area where you will be installing your playset is not level, you must make it level.
3. Playsets must be anchored to the ground. Follow the anchoring instructions provided with your building kit. If soil conditions permit anchors to be pulled out easily, such as in sandy soil conditions, cementing is required.
4. Tighten all bolts securely to the intended member then cut off all protruding threaded ends of bolts with a hack saw **flush to the end of the nut** and remove sharp edges with a metal file.

WARNING: Children must not use the playset until properly installed and proper shock-absorbing surfacing material is in place.

OPERATION: *Observing and following statements and warnings reduces the likelihood of serious or fatal injury.*

1. On-site adult supervision is recommended for children of all ages.

2. Only one child, for each single planned seat or single planned activity should be allowed on this set at one time, with a maximum weight of **105 pounds** for each child.

WARNING: You must teach children the following:

- A. **Not** to walk close to, in front of, behind, or between moving items.
- B. **Not** to twist swing chains or ropes or loop them over the top support bar since this may reduce the strength of the chain or rope.
- C. **Avoid** swinging empty seats.
- D. **To Sit** in the center of the swings with their full weight on the seats.
- E. **Not** to use the equipment in a manner other than intended.
- F. **Not** to get off equipment while it is in motion.
- G. **Not** to climb when equipment is wet.
- H. **Not** to attach items to the playground equipment that are not specifically designed for use with the equipment such as, but not limited to, jump ropes, clothesline, pet leashes, cables and chain as they may cause a strangulation hazard.
- I. **Remove** bike or other sports helmet before playing on the play equipment as the helmet may become entrapped in an enclosed opening and cause a strangulation hazard.

3. Verify that suspended climbing ropes are secured at both ends and that they cannot be looped back on themselves. (A rope that is not taut enough may cause a strangulation hazard.)
4. Dress children appropriately. Provide well fitting shoes. Avoid ponchos, scarves, and other loose-fitting clothing which is potentially hazardous while using equipment.
5. Verify that all suspended swinging components have at least 8" clearance between the lowest point of component and top of shock-absorbing surfacing material.

WARNING: Lawn swings are designed for use by children two years of age and older. Use by children under the age of two can result in entrapment between the seat and backrest. **NEVER** place children in a rearward facing position or with legs between the seat and backrest because the child's body may pass through the opening causing entrapment of the child's head.

DISPOSAL:

When the playset is to be retired from service, disassemble and dispose of in such a way that no unreasonable hazards will exist. Follow your local disposal requirements.

ANNUAL MAINTENANCE CHECKLIST

(Copy this section as needed and maintain for your records or visit www.playstarinc.com/maintenance)



At the beginning of play season: Date: _____

- Tighten all hardware.
- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Check all moving parts including swing seats, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.
- Check metal parts for rust. If found, sand and repaint using a nonlead-based paint meeting the requirements of 16 CRF 1303.
- Check all wood members for deterioration and splinters. Sand down splinters and replace deteriorating wood members.
- Reinstall any plastic parts, such as swing seats or any other items that were removed for the cold season.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

Twice a month during play season: Date: _____

- Tighten all hardware.
- Check all protective coverings on bolts, pipes, edges, and corners. Replace if they are loose, cracked, or missing.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

Once a month during play season: Date: _____


- Lubricate all metallic moving parts per manufacturer's instructions.
- Check all moving parts including swing seats, ropes, cables, and chains for wear, rust, or other deterioration. Replace as needed.

At the end of each play season or when the temperature drops below 0° F: Date: _____


- Remove plastic swing seats and other items as specified by the manufacturer and take indoors or do not use.
- Rake and check depth of loose fill protective surfacing materials to prevent compaction and to maintain appropriate depth. Replace as necessary.

If any of these conditions exist, call 1-888-752-9782 for ordering information.
Clean plastic components with warm water and a mild detergent such as dish soap.


COMPONENTS INCLUDED (not actual size)



Corner Brackets (4)



Climbing Bars (4)



Triangle Brackets (4)

TOOLS REQUIRED


Level
Square
Pencil
Hammer

Adjustable Wrench
Socket Wrench
Drill


Screwdriver (regular or phillips)
Tape Measure
Safety Glasses

Sawhorses (optional)
Shovel
Ladder


HARDWARE INCLUDED (shown actual size)




3/8" x 3" Lag Screw (4)




#14 x 1 1/4" Pan Head Screw (16)




3/8" x 2" Hex Bolt (16)




3/8" Washer (8)



#8 x 2 1/2" Deck Screw (15)



3/8" Lock Nut (16)



#8 x 1 1/4" Deck Screw (32)


NOTE: Depending on your particular applicaton, not all of this hardware may be used.

LUMBER LIST *and* CUTTING GUIDE (PURCHASE SEPARATELY)



Go to Compatibility Chart on page 11 to identify your playset design and locate modification pages. This will help you determine materials required to attach the Climbing Bar Kit.

2" x 4" x 8' – three (3) boards required for: All Star XP, Powerhouse XP, Legend and Tradition



**2" x 4" x 8' – one additional board required for All Star XP and Powerhouse XP – or –
when attaching a climbing component/accessory other than climbing bars**



CLIMBING BAR ASSEMBLY


Items for STEP 1:

- (1) 2" x 4" x 96" board
- (1) 2" x 4" x 46³/₄" board
- (1) triangle bracket
- (4) #8 x 1¹/₄" deck screws



On a flat work surface, lay out the 2" x 4" x 96" and 2" x 4" x 46³/₄" boards as shown.

Lay bracket flat on the board. Slide bracket until the stops on the underside are tight against the boards as shown. **(Fig. 1)**

Use the bracket as a drill guide and drill four 1/8" holes 1" deep into the board. Attach with #8 x 1¹/₄" deck screws. **(Fig. 2)**



Helpful Hint: Mark the two boards at the dimensions shown. This could help to better locate the boards at the correct angle.





Items for STEP 2:

- (1) 2" x 4" x 96" board
- (1) 2" x 4" x 46³/₄" board
- (1) triangle bracket
- (4) #8 x 1¹/₄" deck screws


On a flat work surface, lay out the 2" x 4" x 96" and 2" x 4" x 46³/₄" boards as shown.

Lay bracket flat on the board. Slide bracket until the stops on the underside are tight against the boards as shown. **(Fig. 1)**

Use the bracket as a drill guide and drill four 1/8" holes 1" deep into the board. Attach with #8 x 1¹/₄" deck screws. **(Fig. 2)**



Helpful Hint: Mark the two boards at the dimensions shown. This could help to better locate the boards at the correct angle.



Items for STEP 3:

- (2) Climbing Bar Assemblies
- (2) Triangle Brackets
- (8) #8 x 1 1/4" deck screws
- (10) 3/8" x 2" hex bolts
- (10) 3/8" lock nuts


Turn Climbing Bar Assembly over.

Lay bracket flat on the board. Slide bracket until the stops on the underside are tight against the boards as in previous step.



Use the bracket as a drill guide and drill four 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws. **(Fig. 1)**

Use the bracket as a drill guide and drill five 3/8" holes completely through the board. Attach with 3/8" x 2" hex bolts and 3/8" lock nuts. **(Fig. 2)**


Repeat for second Climbing Bar Assembly. **(Figs. 3 & 4)**



Right Assembly



Left Assembly




Items for STEP 4:

- (4) Climbing Bars
- (16) #14 x 1¼" pan head screws

Attach Climbing Bars at dimensions shown.
 Make sure to keep assemblies 21½" apart.

Use the Climbing Bar as a drill guide and
 drill ⅛" holes 1" deep in the boards

Attach with #14 x 1¼" pan head screws.



IMPORTANT:
The climbing bars must be positioned as specified, otherwise a head entrapment could exist.

Items for STEP 5:

- (2) corner brackets
- (4) #8 x 1 1/4" deck screws
- (2) 3/8" x 2" hex bolts
- (4) 3/8" washers
- (2) 3/8" lock nuts

Attach corner brackets (see details below).


Position brackets so that the long sides are against the 2" x 4" x 46 3/4" board and the short side is flush with the end of the board.

Use the bracket as a drill guide and drill 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws.

Again use the bracket as a drill guide and drill 3/8" holes completely through the boards. Secure with 3/8" x 2" hex bolts, 3/8" washers and 3/8" lock nuts.


Tradition, Powerhouse XP Gold and All Star XP Only:

Corner brackets must be flush with end of boards.



Legend and Powerhouse XP Silver Only:

Mount corner brackets flush to the inside as shown.



Climbing Bar Kit Compatibility

Attach the Climbing Bar to your existing PlayStar playset according to the Chart.

Place on level ground.

Playset	Design Option	To Place Climbing Bar - Move	Playset Modifications See Page
All Star^{XP}	Gold	Climbing Rock Wall	12
	Silver	Climbing Wall	13 & 14
	Bronze	N/A	N/A
Champion^{XP}	Gold	Monkey Ring	18
	Silver	Monkey Ring	18
	Bronze	Monkey Ring	18
Powerhouse^{XP}	Gold	Arch Climber	15
	Silver	Climbing Rock Wall	16 & 17
	Bronze	N/A	N/A
Super Star^{XP}	Gold	Monkey Ring	18
	Silver	Monkey Ring	18
	Bronze	Monkey Ring	19
LEGEND	All Design Options	Scoop Wave Slide	20 & 21
TRADITION	Qualifier, Bronze, Silver & Gold	Scoop Wave Slide	22
ROOKIE	Gold	Monkey Ring	23
	Silver	Monkey Ring	23
	Bronze	Monkey Ring	23

NOTE: Climbing Bar Kit only fits a 21½" opening and is designed for PlayStar playsets with a deck height of 48" or 60". Extend Safety Zone and shock-absorbing material a minimum of six feet in all directions from the perimeter of the Climbing Bar Kit, Steps, Rock Walls, and Climbers.


PLAYSET MODIFICATIONS & CLIMBING BAR ATTACHMENT

ALL STAR XP - GOLD

Remove Climbing Rope.
Remove Climbing Rock Wall and baseboards.

Items for this STEP:

- (4) #8 X 1 1/4" deck screws
- (2) 3/8" x 3" lag screws
- (2) 3/8" washers



Attach Climbing Bar Accessory

Lift Climbing Bar Assembly into an upright position at the dimension shown.

Dig into the ground about 6" at the base so the top bars are leveled.

Use the brackets as a drill guide and drill 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws.

Drill a 1/4" hole 2 1/2" deep into the boards. Secure with 3/8" x 3" lag screw and 3/8" washer.

Go to page 30 for instructions to reattach Wood Rock Wall and baseboards.

Go to page 31 for anchoring instructions.

ALL STAR XP - SILVER

Additional Materials Required (Purchase Separately)

$\frac{5}{4}$ " x 6" x 8' – One board required
 2" x 4" x 8' – One board required

Items for this STEP:

- (2) 2" x 4" x 45½" boards (cut from lumber listed above)
- (2) $\frac{5}{4}$ " x 6" x 37½" boards (cut from lumber listed above)
- (24) #8 x 2½" deck screws (reused from removed boards)
- (2) Corner Brackets
- (8) #8 x 1¼" deck screws
- (2) $\frac{3}{8}$ " x 3" lag screws
- (2) $\frac{3}{8}$ " x 2" hex bolts
- (2) $\frac{3}{8}$ " lock nuts
- (4) $\frac{3}{8}$ " washers

Remove Climbing Wall.


Remove (2) $\frac{5}{4}$ " x 6" x 24" vertical railings from backside (not shown).

Remove (2) 2" x 4" x 38" vertical boards (not shown).


Remove top (2) 2" x 4" x 13¼" horizontal boards (not shown).

Relocate horizontal 2" x 4" x 48" board up to 88" as shown.

Attach (2) 2" x 4" x 45½" vertical boards (using #8 x 2½" deck screws) to replace removed ones.



Back View



Attach Corner Brackets

Position brackets so that the short sides are against the 2" x 4" x 48" board.

Use the brackets as a drill guide and drill $\frac{1}{8}$ " holes 1" deep into the boards. Attach with #8 x 1¼" deck screws.


Use the brackets as a drill guide and drill $\frac{1}{4}$ " holes 2½" deep through the **long** side and a $\frac{3}{8}$ " hole completely through the **short** side of the bracket. Secure the **long** side with a $\frac{3}{8}$ " x 3" lag screw and $\frac{3}{8}$ " washer. Secure the **short** side with a $\frac{3}{8}$ " x 2" hex bolt, $\frac{3}{8}$ " washer and $\frac{3}{8}$ " lock nut.

Attach (2) $\frac{5}{4}$ " x 6" x 37½" vertical panels (using #8 x 2½" deck screws) to replace removed ones.

ALL STAR XP - SILVER

Items for this STEP:

- (4) #8 x 1¼" deck screws
- (2) ⅜" x 3" lag screws
- (2) ⅜" washers



Attach Climbing Bar Assembly

Lift Climbing Bar Assembly into an upright position at the dimension shown.

Dig into the ground 10½" at the base so the top bars are leveled.

Use the brackets as a drill guide and drill ⅛" holes 1" deep into the boards. Attach with #8 x 1¼" deck screws.

Drill a ¼" hole 2½" deep into the boards. Secure with a ⅜" x 3" lag screw and ⅜" washer.

Go to page 24 for instructions to reattach Climbing Wall.

Go to page 31 for anchoring instructions.


POWERHOUSE XP - GOLD

Items for this STEP:

- (4) #8 x 1 1/4" deck screws
- (2) 3/8" x 3" lag screws
- (2) 3/8" washers

Remove Arch Climber.

Remove (1) 2" x 4" x 21 1/2" and (2) 2" x 4" x 28 1/2" boards used to attach Arch Climber to playset (not shown).



Attach Climbing Bar Assembly

Lift Climbing Bar Assembly into an upright position at the dimension shown.

Dig into the ground 6" at the base so the top bars are leveled.

Use the brackets as a drill guide and drill 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws.

Drill a 1/4" hole 2 1/2" deep into the boards. Secure with 3/8" x 3" lag screw and 3/8" washer.

Go to page 25 for instructions to reattach Arch Climber.


Go to page 31 for anchoring instructions.

POWERHOUSE XP - SILVER

Items for this STEP:

- (2) Corner Brackets
- (8) #8 x 1 1/4" deck screws
- (2) 3/8" x 2" hex bolts
- (2) 3/8" x 3" lag screws
- (2) 3/8" lock nuts
- (4) 3/8" washers

Remove Climbing Rope.
 Remove Wood Rock Wall and baseboards.
 Remove 5/4" x 6" x 28" boards from Wood Rock Wall (not shown) and save the screws.



Attach brackets here.

Attach Corner Brackets

Position brackets so that the short sides are against the 2" x 4" x 60" board.

Use the brackets as a drill guide and drill 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws.

Use the brackets as a drill guide and drill 1/4" holes 2 1/2" deep through the **long** side and a 3/8" hole completely through the **short** side of the bracket. Secure the **long** side with a 3/8" x 3" lag screw and 3/8" washer. Secure the **short** side with a 3/8" x 2" hex bolt, 3/8" washer, and 3/8" lock nut.

Items for this STEP:

- (1) 2" x 4" x 21½" board
- (4) #8 x 2½" deck screws
- (4) #8 x 1¼" deck screws
- (2) ⅜" x 2" hex bolts
- (2) ⅜" washers
- (2) ⅜" lock nuts


Attach Climbing Bar Assembly

Lift Climbing Bar Assembly into an upright position at the dimension shown making sure it is centered in the opening.

Dig into the ground about 6" at the base so the top bars are leveled.

Use the brackets as a drill guide and drill ⅜" holes 1" deep into the boards. Attach with #8 x 1¼" deck screws.

Drill a ⅜" hole completely through the board. Secure with ⅜" x 2" hex bolt, ⅜" washer and ⅜" lock nut.



Reattach Wood Rock Wall

Cut ten (10) ⅝" x 6" x 28" boards removed from Wood Rock Wall down to 24½".

Position first ⅝" x 6" x 24½" board tight against the ground as shown. Secure with #8 x 2½" deck screws reused from Wood Rock Wall.

Position next ⅝" x 6" x 24½" board tight against the first board. Secure with #8 x 2½" deck screws reused from Wood Rock Wall.

Repeat for remaining eight (8) boards, for a total of ten (10) ⅝" x 6" x 24½" boards.

Position 2" x 4" x 21½" board flush with top ⅝" x 6" x 24½" board as shown. Secure with #8 x 2½" deck screws provided.

Dig into the ground 6" at the base so the top bars are leveled.

Go to page 31 for anchoring instructions.


CHAMPION XP - GOLD, SILVER, BRONZE
SUPER STAR XP - GOLD, SILVER

Items for this STEP:

- (4) Climbing Bars
- (16) #14 x 1/4" pan head screws

Remove existing Gym Rings and attachment hardware.

NO swinging elements, including Gym Rings, should be attached to overhead Climbing Bars since they pose a conflicting/fall hazard.



Attach Climbing Bars at dimensions shown.

Use the Climbing Bar as a drill guide and drill 1/8" holes 1" deep in the boards.

Attach with #14 x 1/4" pan head screws.

IMPORTANT:

The Climbing Bars must be positioned as specified, otherwise a head entrapment could exist.

SUPER STAR XP - BRONZE

Items for this STEP:


- (4) Climbing Bars
- (16) #14 x 1/4" pan head screws

Remove existing Gym Rings and attachment hardware.

NO swinging elements, including Gym Rings, should be attached to overhead Climbing Bars since they pose a conflicting/fall hazard.

IMPORTANT:

The Climbing Bars must be positioned as specified, otherwise a head entrapment could exist.



Remove 2" x 4" x 28 1/2" horizontal board (not shown) from this area so no entrapment hazard is created when Climbing Bars are attached.

Attach Climbing Bars at dimensions shown. Use the Climbing Bar as a drill guide and drill 1/8" holes 1" deep in the boards.


Attach with #14 x 1/4" pan head screws.

LEGEND

Items for this STEP:

- (4) #8 x 1¼" deck screws
- (2) ⅜" x 2" hex bolts
- (2) ⅜" lock nuts
- (2) ⅜" washers

Remove slide.
 Remove existing climbing bars from tower.
 Remove 2" x 4" x 38¾" board (see next page).
 Reattach slide to tower opening where climbing bars were attached.
 Follow instructions provided with your slide to attach to tower.



Attach Climbing Bar Assembly

Lift Climbing Bar Assembly into an upright position at the dimension shown, making sure it is centered in the opening.

Dig into the ground 10½" at the base so the top bars are leveled.

Use the brackets as a drill guide and drill ⅛" holes 1" deep into the boards. Attach with #8 x 1¼" deck screws.

Drill a ⅜" hole completely through the boards. Secure with ⅜" x 2" hex bolt, ⅜" washer and ⅜" lock nut.

Go to page 29 for instructions to reattach Climbing Bars.


Dig into the ground 10½" at the base so the top bars are leveled.

Go to page 31 for anchoring instructions.

LEGEND - Back view

Items for this STEP:

- (2) Corner Brackets
- (8) #8 x 1 1/4" deck screws
- (2) 3/8" x 2" hex bolts
- (2) 3/8" x 3" lag screws
- (2) 3/8" lock nuts
- (4) 3/8" washers



Attach Corner Brackets

Position brackets so that the short sides are against the 2" x 4" x 62 1/2" board as shown.

Use the brackets as a drill guide and drill 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws.

Use the brackets as a drill guide and drill 1/4" holes 2 1/2" deep through the **long** side and a 3/8" hole completely through the **short** side of the bracket. Secure the **long** side with 3/8" x 3" lag screw and 3/8" washer. Secure the **short** side with 3/8" x 2" hex bolt, 3/8" washer and 3/8" lock nut.

Remove this board.

TRADITION with Tunnel Kit Only

Items for this STEP:

- (12) #8 x 1 1/4" deck screws
- (2) 3/8" x 3" lag screw
- (4) 3/8" x 2" hex bolts
- (4) 3/8" lock nuts
- (6) 3/8" washers

Remove slide.

Reattach slide to tunnel deck. Follow instructions provided with your slide.

If using Climbing Bars from tower, remove them at this time. Attach Vertical Climber or Climbing Steps to replace the bars. Refer to instructions provided with your climbing component.


Attach Climbing Bar Assembly

Lift Climbing Bar Assembly into an upright position at the dimension shown.

Dig into the ground 10 1/2" at the base so the top bars are leveled.

Use the brackets as a drill guide and drill 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws.

Drill a 3/8" hole completely through the board. Secure with 3/8" x 2" hex bolt, 3/8" washer and 3/8" lock nut.



Attach Corner Brackets

Position brackets so that the short sides are against the 2" x 4" x 46 3/4" board as shown.

Use the brackets as a drill guide and drill 1/8" holes 1" deep into the boards. Attach with #8 x 1 1/4" deck screws.

Use the brackets as a drill guide and drill 1/4" holes 2 1/2" deep through the **long** side and a 3/8" hole completely through the **short** side of the bracket. Secure the **long** side with 3/8" x 3" lag screw and 3/8" washer. Secure the **short** side with 3/8" x 2" hex bolt, 3/8" washer and 3/8" lock nut.

Go to page 29 for instructions to reattach Climbing Bars.

Go to page 31 for anchoring instructions.


ROOKIE - GOLD, SILVER, BRONZE

Remove existing Gym Rings and attachment hardware.

Items for this STEP:

- (4) Climbing Bars
- (16) #14 x 1/4" pan head screws

NO swinging elements, including Gym Rings, should be attached to overhead Climbing Bars since they pose a conflicting/fall hazard.



Remove 2" x 4" x 24 1/2" horizontal board (not shown) from this area so no entrapment hazard is created when Climbing Bars are attached.

Attach Climbing Bars at dimensions shown.

Use the Climbing Bar as a drill guide and drill 1/8" holes 1" deep in the boards.

Attach with #14 x 1/4" pan head screws.

IMPORTANT:

The Climbing Bars must be positioned as specified, otherwise a head entrapment could exist.

Go to page 31 for anchoring instructions.

ACCESSORY ATTACHMENTS


CLIMBING WALL

Items for this STEP:


- (2) 2" x 4" x 24½" board
- (1) 2" x 4" x 21½" board
- (15) #8 x 2½" deck screws

Use the screws provided to attach the three boards at the dimensions shown.

Follow directions provided with your Climbing Wall to attach to end of frame.



Detail for board placement.



Dig into the ground so top bars are leveled.

Go to page 31 for anchoring instructions.


ARCH CLIMBER

Items for this STEP:


- (2) 2" x 4" x 24½" board
- (1) 2" x 4" x 21½" board
- (15) #8 x 2½" deck screws

Use the screws provided to attach the three boards at the dimensions shown.

Follow directions provided with your Arch Climber to attach to end of frame.



Back detail for board placement.



Dig into the ground so top bars are leveled.

Go to page 31 for anchoring instructions.


ROCK WALL

Items for this STEP:

- (2) 2" x 4" x 24½" board
- (1) 2" x 4" x 21½" board
- (15) #8 x 2½" deck screws


Use the screws provided to attach the three boards at the dimensions shown.

Follow directions provided with your Rock Wall to attach to end of frame.



Dig into the ground so top bars are leveled.

Detail for board placement.



Bottom board should be tight against the ground

Go to page 31 for anchoring instructions.


VERTICAL CLIMBER

Items for this STEP:

- (2) 2" x 4" x 24½" board
- (1) 2" x 4" x 21½" board
- (15) #8 x 2½" deck screws


Use the screws provided to attach the three boards at the dimensions shown.

Follow directions provided with your Vertical Climber to attach to end of frame.



Dig into the ground so top bars are leveled.

Back detail for board placement.



Go to page 31 for anchoring instructions.


CLIMBING STEPS

Items for this STEP:

- (2) 2" x 4" x 24½" board
- (8) #8 x 2½" deck screws


Use the screws provided to attach the two boards at the dimensions shown.

Follow directions provided with your Climbing Steps to attach to end of frame.



Dig into the ground so top bars are leveled.

Back detail for board placement.




Go to page 31 for anchoring instructions.

CLIMBING BARS

These Climbing Bars may or may not be from existing playset. Attach Climbing Bars at dimensions from ground as shown.

IMPORTANT:
The climbing bars must be positioned as specified, otherwise a head entrapment could exist.



Go to page 31 for anchoring instructions.

WOOD ROCK WALL

Item for this STEP:

- (1) 2" x 4" x 21½" board
- (1) 2" x 4" x 24½" board
- (8) #8 x 2½" deck screws


Relocate Wood Rock Wall from tower.

Use the screws provided to attach the two boards at the dimensions shown.



Cut baseboards as shown.

Attach baseboards as shown reusing hardware. Use scrap 2" x 4" boards as temporary spacers for proper alignment as shown.

Attach Wood Rock Wall as shown reusing hardware,



Baseboards



Baseboards

Spacers

56¾"

Go to page 31 for anchoring instructions.

ANCHORING


Items for this **STEP**:

- (1) Playset Anchors PS 7690 (sold separately)
- (2) $\frac{3}{8}$ " x 2" lag screws (provided with PS 7690)
- (2) $\frac{3}{8}$ " washers (provided with PS 7690)

At locations shown screw Playset Anchors into ground by hand (a long screwdriver will help).

Use the anchor as a drill guide and drill a $\frac{1}{4}$ " hole 1" deep into the board. Attach with $\frac{3}{8}$ " x 2" lag screw and $\frac{3}{8}$ " washer.

Note: *If soil conditions permit anchors to be pulled out easily, such as in sandy soil conditions, cementing is required. If your ground is too hard to screw in the anchors you can remove the earth with a shovel. Install the anchors and compact the earth as you replace it. Anchors must be placed below the level of the shock-absorbing surfacing material to prevent tripping or injury resulting from a fall.*



Reminder:
Be sure to install proper shock-absorbing surfacing material. Refer to the Safety Guidelines at the beginning of this plan.

T *Thank You for choosing PlayStar. Because it is our intention to make this a positive family experience, we have taken great care in preparing this product. Should you have any questions, or if we can assist you in any way, please call our friendly Customer Service Department for immediate action.*

Do not return to the store.
Please call us Toll Free at 1-888-PLAYSTAR
(752-9782)

Monday through Friday, 8:00 A.M. to 5:00 P.M. C.S.T.

Ask for Customer Service.

We Will Gladly Help!



PlayStar, Incorporated, Janesville, WI 53547

© 2009, 2007, PlayStar, Inc. Reproduction of this document in part or whole is prohibited without the permission of PlayStar, Inc.

Protected by one or more of the following United States or Foreign Patents: US D418,189; US D409,708; US D424,154; US D428,637; US 6,402,663; US D422,332; US D410,059; US 6,068,557; US 6,302,801; US 6,482,095; US 6,039,654; US D410,060; US D424,649; US 6,361,445; CA 2,304,345; US 6,540,645; US 6,709,365; US 6,942,600; US D513,779; US 6,991,550; CA D109,228; CA D109,224; CA D109,225; CA 2,304,113; US 6,629,907; US D517,636; US D518,530; US D520,590; US 5,205,591; US D534,613; US 7,186,183; US 7,189,034; US 7,253,951; US D548,760; US 7,304,810; CA D109,227; CA D109,226; CA D112,355; CA D113,437; CA D113,442; CA D114,067; CA D114,068; CA 2,304,896; CA D119,674; US D573,222; US 7,419,437; CA 2,304,068; CA 2,488,576; US D580,507; US D585,570; CA 2,490,923; CA 2,304,341; US 7,594,875; CA 2,304,043; CA 2,529,276; CA 2,633,628; CA 633,056