

PRESSURE SETTING

STEP 1: PLACE FOOD

with minimum of 1.5 cups of thin liquid (water, broth, wine).

STEP 2: LOCK LID

Turn lid counter-clockwise to lock in place.



OPEN POSITION



LOCKED POSITION

STEP 3: TURN UNIT ON

Plug unit in. Turn the pressure regulator knob to **Pressure** position.



PRESSURE
POSITION



STEP 4: SELECT COOKING MODE AND TIME

1. Press desired pre-set button on the control panel.
2. Select **LOW** or **HIGH** pressure by pressing **PRESSURE** button.
3. Press **ADJUST** to select different cooking times (**Less**, **Normal**, **More**).
4. To adjust cooking time, press "+" and "-" buttons.

PRE-SETS	PRESSURE	TIME (NORMAL)	TIME (MORE)	TIME (LESS)
Soup/broth	High	0:30	0:40	0:20
Meat stew	High	0:35	0:45	0:20
Bean/Chili	High	0:30	0:40	0:25
Poultry	High	0:15	0:30	0:05
Rice	Low	0:12	0:15	0:10
Multigrain	High	0:20	0:30	0:15
Porridge	High	0:20	0:30	0:15
Steam	High	0:10	0:15	0:03
Manual	High	0:30	-	-

STEP 5: COOKING



PRESSURE IS BUILDING/
UNIT IS HEATING



TIMER IS COUNTING DOWN

When cooking is done, unit will beep 5 times, the LED will display "00:00" and it will automatically go into **KEEP WARM** state. Wait for Floating Valve to drop before opening the lid. To manually release pressure, please refer to p.10 of main manual.

SAUTÉ SETTING

STEP 1: TURN UNIT ON

Remove the lid. Plug unit in.

STEP 2: SELECT COOKING MODE AND TIME

1. Press **SAUTÉ** button on the control panel.
2. Press **ADJUST** to select different cooking times (**Less**, **Normal**, **More**).
3. The default time is **0:30**. To adjust cooking time, press "+" and "-" buttons.

STEP 3: COOKING

Add food to begin browning. **BE CAREFUL OF OIL SPLATTER**. When cooking is done, unit will beep 5 times, the LED will display "00:00" and it will automatically go into **KEEP WARM** state.

PRE-SETS	PRESSURE	TIME (NORMAL)	TIME (MORE)	TIME (LESS)
Slow cook	-	4:00	-	-
Yogurt	-	8:00	-	-
Sauté	-	0:30	0:40	0:20

SLOW COOK SETTING

STEP 1: PLACE FOOD

with minimum of 1.5 cups of thin liquid (water, broth, wine).

STEP 2: LOCK LID AND TURN UNIT ON

Turn lid counter-clockwise to lock in place. Plug unit in.

STEP 2: SELECT COOKING MODE AND TIME

1. Press **SLOW COOK** button on the control panel.
2. The default time is **4:00**. To adjust cooking time, press "+" and "-" buttons.

STEP 5: COOKING

When cooking is done, unit will beep 5 times, the LED will display "00:00" and it will automatically go into **KEEP WARM** state.

FOR OTHER FUNCTIONS, PLEASE REFER TO MAIN MANUAL.