

30416-30417 FAQs

The links below will work in most PDF viewers and link to the topic area by clicking the link. We recommend Adobe Reader version 10 or greater available at: <http://get.adobe.com/reader>

CONTENTS

| | |
|---|---|
| 30416-30417 FAQs..... | 1 |
| Clock Factory Restart..... | 1 |
| Clock | 1 |
| Power Requirements | 1 |
| Battery Backup..... | 1 |
| Clock Dimmer..... | 2 |
| Manually Set Time/Date: Program Menu..... | 2 |
| Set Time Alarm..... | 2 |
| Snooze | 2 |
| USB Charging Port..... | 3 |
| Clock has missing segments..... | 3 |

Clock Factory Restart

Explanation: The factory restart returns the clock and outdoor sensor to an “out-of-the-box” default state and often resolves an issue.

Factory Restart:

1. Remove all power (batteries and power cord) from the clock.
2. Press one of the buttons on the clock at least 20 times to clear all memory.
3. Verify that the clock is blank before proceeding (there may be lines painted on the screen that will show when there is no power).
4. Leave **without power for 15 minutes** (very important).
5. Insert the power cord into the wall outlet then into the clock.

Clock Power Requirements

- Power cord (120-volt) as primary power source.
- A 9v battery may be added to back up time and date.

Battery Backup

- Insert one “9V” battery into the battery compartment on the bottom of the clock. The battery will keep the alarm and time settings until the power is restored.
- The LED display will not light-up but the alarm will sound at the preset alarm time.

- If there is no battery installed but the power is interrupted, the display will flash at 12:00 and the time and alarm need to be set again

Clock Dimmer

- Brighter: Slide the HI/LO display dimmer switch to HI position.
- Normal: Slide the HI/LO display dimmer switch to LO position.

Manually Set Time/Date: Program Menu

You must hold the TIME button while setting the hour and minutes.

1. Continuously hold down the TIME button while setting your hour and minutes.
2. While holding the TIME button, press the HOUR button to set your hour.

Note: The PM indicator will appear when you advance to PM time.

3. While holding the TIME button press the MINUTE button to set your minutes.
4. Release the TIME button when the correct time shows on the display.

Set Time Alarm

You must hold the ALARM button while setting the hour and minutes.

1. Continuously hold down the ALARM button while setting your alarm time.
2. While holding the ALARM button, press the HOUR button to set your alarm hour.

Note: The PM indicator will appear when you advance to PM time.

3. While holding the ALARM button, press the MINUTE button to set alarm minutes.
4. Release the ALARM button when the correct alarm time is shown on the display.

Alarm ON/OFF

- Slide the ON/OFF switch to the ON position to activate the alarm
- Slide the ON/OFF switch to the OFF position to deactivate the alarm

Snooze

- When alarm sounds, press the SNOOZE button to silence alarm for 8 minutes.
- Snooze function can be repeated many times if desired.

USB Charging Port

Note: This is a power-output charging port. It does not provide power to the alarm clock.

- Connect your external device's USB charging cable (not included) to the USB charging port.
- Charging times will vary.
- USB Power Output: 1A and 2A maximum current.
- Charge devices that are self-regulating.

Clock has missing segments

Explanation: When parts of numbers, letters, or pictures are missing on the display, it is often power related.

- Check the Power cord. Is it correctly installed and connects to an active outlet.
- Press any button 20 times. Leave the alarm clock unpowered for 1-2 hours.
- Power clock with Power cord only to determine if batteries were an issue.