

PRODUCT OVERVIEW


Parts







Accessories

Included Accessories









(LDG4315 Model only)

Owner's manual (1ea)

Anti-tip kit



Anti-tip (1ea)



Screws (6ea)



Anchors (6ea)



Template (1ea)

LP nozzle conversion kit



Cooktop Nozzles (5ea)



Oven Nozzles (2ea)



Installation guide (1ea)

EasyClean™ kit




Spray bottle (1ea)



Non-scratch scouring pad (1ea)

Optional Accessories



NOTE

- · Contact LG Customer Service at 1-800-243-0000 (1-888-542-2623 in Canada) if any accessories are
- For your safety and for extended product life, only use authorized components.
- The manufacturer is not responsible for product malfunction or accidents caused by the use of separately purchased, unauthorized components or parts.
- The images in this guide may be different from the actual components and accessories, which are subject to change by the manufacturer without prior notice for product improvement purposes.