






RYi4022X QUICK REFERENCE GUIDE


**WARNING:**
This Quick Reference Guide is not a substitute for reading the operator’s manual. To reduce the risk of injury or death, user must read and understand operator’s manual before using this product. All page references refer to the operator’s manual.

IMPORTANT!

**WARNING:**
Do not connect to a building’s electrical system unless the generator and transfer switch have been properly installed and the electrical output has been verified by a qualified electrician. The connection must isolate the generator power from utility power and must comply with all applicable laws and electrical codes.


**DANGER**
Using a generator indoors **CAN KILL YOU IN MINUTES**. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.
 NEVER use inside a home or garage, **EVEN IF** doors and windows are open.
 Only use **OUTSIDE** and far away from windows, doors, and vents.

TOOLS NEEDED




FIRST TIME ASSEMBLY


1 Install the feet (see page 12).




2 Install the wheels (see page 12).




3 Raise the handle (see page 13).



4 Add entire bottle of lubricant provided to the generator (see page 14).







Set unit on flat surface so engine is level. Remove dipstick, wipe clean, put back in hole (but don’t screw in) and check lubricant level.

STARTING THE UNIT


1 Add fuel (see page 14).

NOTICE: Do not use E15 or E85 fuel in this product. It is a violation of federal law and will damage the unit and void your warranty. Only use unleaded gasoline containing up to 10% ethanol.







2 Place the easy start lever in the **START** position (see page 15).




3 Pull the recoil starting grip until the engine runs (see page 15).




4 Allow engine to run for 15–30 seconds, then move the easy start lever to the **RUN** position (see page 15).






This is a 4-cycle engine. Do not mix fuel and lubricant together.



Mix fuel stabilizer with gasoline according to manufacturer’s directions prior to filling the tank.

STOPPING THE UNIT

1 Place the easy start lever in the **OFF** position (see page 15).



USING THE GENERATOR

1 Connect devices to be powered by generator by following the steps below (see pages 9-10).

- Make sure the generator can supply enough continuous (running) and surge (starting) watts for the items you will power at the same time. See page 9 for how to calculate total amount of power needed.
- Start the generator with nothing connected.
- Plug in and turn on the first load, preferably the largest load you have.
- Permit the generator output to stabilize (engine runs smoothly and attached device operates properly).
- Plug in and turn on the next load.
- Again, permit the generator to stabilize.
- Repeat previous two steps for each additional load.

IMPORTANT: Never add more loads than the generator capacity. Take special care to consider surge loads in generator capacity. (See pages 9-10.)

STORING THE UNIT

1 When preparing to store the generator, allow the unit to cool completely for 30 minutes, then follow the guidelines listed on page 19.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Engine will not start.	Engine switch is off.	Turn engine switch on.
	Fuel valve is OFF .	Turn fuel valve to ON position.
	No fuel.	Fill fuel tank.
	Stale gasoline or water in gasoline.	Drain entire system and refill with fresh fuel.
	Lubricant level is low.	Engine is equipped with low oil shutdown. If engine lubricant level is low, it must be filled before it will start. Check engine lubricant level and fill, if necessary.
	Spark plug faulty, fouled, or improperly gapped.	Replace spark plug.
Engine hard to start.	Engine stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel and carburetor. Refuel with fresh gasoline.
	Dirty fuel filter.	Contact a qualified service center.
	CO sensor LED is flashing red, indicating a CO hazard.	Leave area immediately and relocate to an open outdoor area. Ventilate area thoroughly before occupying again. Ensure the generator is located in an open outdoor area and point exhaust away from occupied structures.
Engine lacks power.	CO sensor LED is flashing yellow and/or making an audible chirp, indicating a sensor fault.	The CO sensor needs to be repaired or replaced. Contact customer service or a qualified service center for assistance.
	Water in gasoline.	Drain entire system and refill with fresh fuel.
AC receptacle does not work.	Weak spark at spark plug.	Contact a qualified service center.
	Item plugged in is defective.	Try a different item.
	Generator is overloaded.	Remove loads and press the reset button.
Generator makes a “spark knock” or “pinging” noise.	Circuit breaker is tripped.	Reset the AC circuit breaker.
	An occasional light “knocking” or “pinging” under heavy load is not a cause for concern. However, if the knocking or pinging occurs under normal load at a steady engine speed, the problem may be with the brand of gasoline being used.	Switch to a different brand of gasoline, making sure that the octane rating is 86 or higher. If problem continues, contact a qualified service center.
If problem persists after trying the above solutions, contact customer service or a qualified service center for assistance.		
NOTICE: As the equipment owner, you are responsible for the performance of the required maintenance listed in the <i>Maintenance</i> section. It is recommended that you retain all receipts covering maintenance on your equipment. Neglecting or failing to perform the required maintenance may increase emissions, decrease fuel efficiency, degrade performance, cause irreversible engine damage and/or void your warranty.		

Make the most of your purchase! Go to www.ryobitools.com and register your new tool online. For questions about operating or maintaining your product, please call, 1-800-860-4050.

