Camping Chair User Manual

1. Introduction

Thank you for choosing our camping chair. This chair is designed to provide you with comfort and convenience during your outdoor activities. It features a built - in cup holder, a folding side table, and a sturdy steel frame, making it suitable for various occasions such as camping, lawn parties, beach outings, and more.

2. Features

2.1 Built - in Cup Holder

The chair is equipped with a built - in cup holder. Simply place your drink in the cup holder to prevent it from spilling out. This is especially useful when you are enjoying a beverage outdoors and want to keep your hands free.

2.2 Folding Side Table

There is a folding side table attached to the chair. You can use it to place your mobile phone, snacks, sunglasses, or other small items. To use the side table, unfold it from the side of the chair. When not in use, fold it back neatly against the chair for easy storage and transportation.

2.3 Easy - to - carry Grip

There is a grip behind the back of the camping chair. This grip makes it convenient for you to carry the chair outdoors. Whether you are walking to your campsite, the beach, or the lawn, you can hold the chair firmly by this grip.

2.4 Sturdy Construction

• **Weight Capacity**: The chair is constructed with a sturdy steel frame that can afford up to 250 LBS . This makes it suitable for heavy - duty use by adults.

 Materials: The double - seam 600x300D Oxford Cloth & 200g mesh not only provides great strength and durability but also offers excellent breathability. You can sit comfortably for long periods without feeling stuffy. The chair itself weighs 17.16 LBS, which is light enough for easy transportation.

3. Setup

- 1. First, take the chair out of the carry bag. The carry bag has handle straps for easy carrying.
- 2. Pull the frame of the chair apart gently. Make sure all parts of the frame are extended fully.
- 3. Click the frame to lock it into place. You will hear a distinct clicking sound when the frame is locked correctly. Now, your chair is ready to use.

4. Usage

- 1. Sit on the chair carefully, making sure your weight is evenly distributed. The maximum weight capacity of the chair is 250 LBS. Do not exceed this weight limit to ensure safety and the longevity of the chair.
- 2. Use the built in cup holder for your drinks and the folding side table for your personal items.
- 3. This chair can be used in various settings. It can be a camping chair at your campsite, a folding chair for your backyard, a lawn chair for a picnic, a travel chair during your trips, a beach chair for sunbathing, or a chair for tailgating, fishing, backpacking, sport games, and car travelling.

5. Folding and Storage

- 1. To fold the chair, first, remove any items from the cup holder and side table.
- 2. Unlock the frame by pressing the locking mechanism (the part where you clicked the frame to lock it).
- 3. Gently push the frame back together until the chair is folded into a compact shape.
- 4. Place the folded chair back into the carry bag. Make sure the chair is properly inserted into the bag and the bag is zipped up. Store the chair in a dry place away from direct sunlight and moisture.

6. Maintenance

- 1. Regularly check the steel frame for any signs of damage, such as cracks or bends. If you find any damage, stop using the chair immediately and contact our customer service.
- 2. Clean the 600x300D Oxford Cloth & 200g mesh regularly. You can use a mild detergent and water to wipe down the fabric. Avoid using harsh chemicals as they may damage the fabric.
- 3. If the chair has been exposed to rain or moisture, dry it thoroughly before storing it to prevent rust on the steel frame and mold on the fabric.

7. Safety Precautions

- 1. Do not exceed the weight capacity of 250 LBS. Overloading the chair may cause it to break and result in injury.
- 2. When setting up and folding the chair, be careful of your fingers to avoid getting pinched by the frame.
- 3. Use the chair on a flat and stable surface. Uneven surfaces may cause the chair to tip over.