


ALEKO®

www.aleko.com



**Nest Swing - BSW07**  
**FOR CHILDREN AGED 3 TO 10 YEARS**

## SAFETY GUIDELINES

### Warnings

**Only for domestic use. This product has not been designed for commercial use in play centers, nurseries etc.**

**Only suitable for outdoor use.**

**Maximum 3 children. Total weight must not exceed 100kg.**

**Not for children under 3 years due to small component which may cause choking hazard.**

This equipment must be assembled and checked by an adult. Two adults may be required to assemble this product.

Adult supervision is required at all times.

Check all nuts, bolts and fittings for tightness and tighten if required.

Check all coverings for bolts and sharp edges and replace when required.

Check swing seats, chain, ropes and other means of attachments relevant to your product for evidence of deterioration. Replace when required in accordance with the manufacturers instructions if necessary.

Place the product on level surface at least 2 metres from any structure or obstruction such as a fence, garage, house, wall, overhanging branches, laundry line or electrical wires.

The items **MUST** be anchored firmly into the ground.

DO NOT install the product over concrete, asphalt or any hard surface.

DO NOT orientate the product directly towards the sun.

Leave all fittings finger tight until assembly is complete, for ease of construction. Then tighten firmly.

Children should not wear cycle helmets whilst on this equipment.

Do not allow children to stand on any swing seats, glider seats or slide chutes relevant to your product.

Do not allow children to jump or climb off any moving equipment.

Do not twist swing ropes or wrap them over the top bar.

Do not allow loose, hooded or baggy clothes to be worn as children can get trapped and may be unable to free themselves.

Do not allow children to climb on parts of this equipment not intended for this purpose.

Do not allow children to wander into the play area whilst the equipment is in use.

Glider seats must not exceed an angle of 60 degrees from the ground.

Regularly check the item for wear and damage, removing the item from use when necessary until replacement parts are fitted.

Failure to assemble and maintain this item as per instruction may cause injury to the user.

Please keep the instructions in a safe place for future reference.

The minimum clearance between the swing seat and ground level should be 350mm.

Please contact our customer services department if you have any problems.

Inspect all parts of this product every 6 months following purchase. If any parts look worn or you find any problems, please contact us for replacements and do not use product until problem has been corrected. Hedstrom




recommends replacing the plastic swing rope clamps every 2 years even if there is no sign of deterioration.

Do not modify this item

Conforms to EN71



Made in China to European Standards

## SWING PARTS LIST



**IMPORTANT:** Make sure you read the safety notice on the front page and always supervise children while they are playing on the equipment. Once assembly is completed carefully check equipment. In the unlikely event that you do find any problems, please contact us. Do not allow children to use this product until the problem has been corrected.

## ASSEMBLY INSTRUCTIONS



M8 U-BOLT (X2)



M6 BOLT 50mm (X8)



M6 BOLT 47mm (x4)



M8 BOLT 53mm (X1)



M8 BOLT 60mm (X4)

**Step 1.** Insert tapered end of Top Bar 1 into the end of Top Bar 2. Make sure there is only 1 set of holes in the end connected to Top Bar 1.

Use 1 F2 fastener to connect Top Bar 1 to Top Bar 2

**\*\*Always Make sure to place included washers between fastener head or nut and adjoining swing components\*\***

**Step 2.** Insert 1 Top Leg segment into either side of the T-shaped Connector, secure with 2 F3 fasteners per Leg. Repeat for both Connector and Top Leg assemblies.

**Step 3.** Insert either end of assembled Top Bar into Connector and Leg Assemblies. Use 2 F5 fasteners on each side to attach.

**Step 4.** Completely disassemble F1 U-Bolts then place u-shaped bolt through the hole in the bearing assembly found at the end of the Swing ropes.

Tighten open-ended F1 nut down onto u-shaped bolt, place 1 F1 washer on each end of the bolt and insert into Top Bar through 2 sets of vertical holes. Ensure washer placement between nuts and Top Bar.

Place 1 F1 washer on the exposed threaded ends of the F1 bolt, then attach F1 cap nuts and tighten down. Repeat for both sets of Swing ropes.

**Step 5.** Insert 1 Bottom Leg into the open end of each of the 4 Top Legs. Place a F4 fastener into each of the holes at the junction, making sure the exposed threaded end is pointed away from the Nest Swing.

Place Side Stay Bar over the exposed fastener ends so that the flat side of the Stay Bar ends is in contact with the Top/Lower Leg assembly.

Tighten F4 nut down onto Side Stay Bar.

## Anchoring the Gym to the Ground

**Step 1.** Attach Ground Pegs to all 4 Nest Swing Bottom Legs using F6 fasteners.

**Step 2.** Place assembled Swing Set in desired location and dig a footing hole, measuring 12" (30cm) Long x 12" (30cm) Wide x 20" (50cm) Deep, at the base of each support leg.

**Step 3.** Prepare and pour concrete into the footing holes following concrete manufacturer's instructions. Fully fill footing holes to be level with ground surface.




**Step 4.** While Concrete is still wet, angle Ground Pegs toward opposing legs at roughly 120-degrees, then insert Ground Pegs into concrete footing, making sure Swing set Bottom Legs do not sink below ground surface (utilize concrete set time information). Use temporary support made from wood or other material if necessary to prevent sinking.

Swing Set will be ready for use once concrete is fully set and cured (consult concrete manufacturer's instructions).

# ALEKO®

Visit us at [www.aleko.com](http://www.aleko.com) for Tech Support, Customer Service, and more great products for your Home, Garden, Patio and Pets!

**IMPORTANT:** For safety reasons this gym **MUST** be anchored and concreted into the ground. If you are uncertain about this procedure, telephone our helpline number.



M6 BOLT 58mm (X4)

