

COSTWAY[®]



USER'S MANUAL
Net Swing

THIS INSTRUCTION BOOKLET CONTAINS **IMPORTANT** SAFETY INFORMATION. PLEASE READ AND KEEP FOR FUTURE REFERENCE.

Please give us a chance to make it right and do better!

Contact our friendly customer service department for help first.

Replacements for missing or damaged parts will be shipped ASAP!

Follow Costway

Visit us: www.costway.com



Contact Us!

Do NOT return this item.

Contact our friendly customer service department for help first.



Before You Start

- ⚠ Please read all instructions carefully.
- ⚠ Retain instructions for future reference.
- ⚠ Separate and count all parts and hardware.
- ⚠ Read through each step carefully and follow the proper order.
- ⚠ We recommend that, where possible, all items are assembled near to the area in which they will be placed in use, to avoid moving the product unnecessarily once assembled.
- ⚠ Always place the product on a flat, steady and stable surface.
- ⚠ Keep all small parts and packaging materials for this product away from babies and children as they potentially pose a serious choking hazard.

(GB) Detachable Net Swing

IMPORTANT

READ AND FOLLOW ALL SAFETY INFORMATION AND INSTRUCTIONS, KEEP FOR FUTURE REFERENCE.

⚠ WARNING! CHOKING HAZARD-SMALL PARTS, NOT FOR CHILDREN UNDER 3 YEARS. WARNING! DO NOT USE WITHOUT ADULT SUPERVISION. WARNING! ADULT ASSEMBLING REQUIRED.

LIABILITY

While every attempt is made to embody the highest degree of protection in all equipment, we can not guarantee freedom from injury, The user assumes all risk of injury due to use, All merchandise is sold on this condition, while no representative of the company can waive or change.

ESSENTIAL INFORMATION

- Recommended for children 5+ years
- Do not leave child unattended while in use.
- CAUTION: Use only under adult supervision.
- Good safety practices should be followed at all times.
- Read all instruction before using this product.

INSTALLATION INSTRUCTIONS

- Adequate overhead clearance is essential, A minimum of 4m from ground level is recommended, Provide clearance for wires, ceiling fans and other possible hazards.
- Lateral clearance is essential, Place the swing away from walls, Structures, furniture, and other play areas, Maintain a clear space on all sides of the swings, A minimum of 2.5m from frame edge is recommended.
- The swing is under heavy tension, 2 adults are required to set it up, use appropriate clothing and shoes, Failure to follow these instructions may lead to injury or damage to the swing.
- Hang it firmly before using.
- The owner and supervisors of the swing are responsible to make all users aware of practices specified in the use instructions.

CARE AND MAINTENANCE INSTRUCTIONS.

Inspect the swing before each use, the following conditions could represent potential hazards.

1. Swing hooks and suspension must be greased regularly. Also check swing hooks and rings for rust points, which could affect their strength. Replace if in any doubt.
2. Check the swing seats and trapezes for cracks or breaks
3. Check swing ropes for fraying or extreme wear resulting from the twisting of the swing accessories. In order to assess this you need to unwind the ropes at the point of suspected wear in order to check the swing rope fibers carefully for breaks. Replace if in any doubt.
4. The swing can be packaged in a bag (plastic or other material) after use, and make sure the swing is dry. Do not store it under the sun.

USER SAFETY INSTRUCTIONS

1. Read the instructions carefully before use.
2. Before starting to use the swing, make sure the rings are strongly attached, so that a release or slipping of the rope is safely excluded.
3. The height of the attachment points of the swing should be in the way to make sure sit comfortably. The corresponding height is 40cm above the floor, exceeding this level is forbidden.
4. The swing is not permitted to be used as a hammock - maximum tilt of 45 degree
5. Do not place anything under the swing.
6. Do not jump on the swing or jump to the swing.
7. The swing should be set only by adults, children (under 12 years old) use this swing must be under the supervision of adults.
8. Put soft padding under the swing if the ground is hard.
9. Check the swing, the facilities, the fixing ring and hanging points carefully. A secure fit is required before using.
10. WHEN the rope broken or loosen, swing is not allowed for next using.

SWING SAFETY AND ACCIDENT PREVENTION

As in most recreational sport, participants may be injured, this section covers the most common accidents responsibilities of the supervisors and users in accident prevention are also outlined.

The following are reasons why accidents happen:

- Attempting to jump to the swing, it will be easy fall off and injury, each time, the users should step onto the swing carefully.
- Always stay in the center of the swing net, injury may result from hitting the frame when control lost. Be sure the foam cover in good condition.
- Loss of control, a users who loses control will increase his/her chance of injury, do not swing big degree to avoid any falling of and injury.
- Alcohol and drug use, because alcohol and drug use impairs the jumpers coordination, loss of control as well as injuries are greatly increased.
- Poor maintenance of the swing. Make sure you inspect the swing before each use, Check for puncture and sharp burrs on the body, and the rope not rust or broken.

ASSEMBLY INSTRUCTIONS

- Place all from the box in a cleared area and position them on the floor in front of you.
- Remove all packing material from your area and place them back to the box, do not dispost of the packing material until assembly is completed. Read each step carefully before beginning.

WARNING!

Two adults in good physical condition are required for the following assembly. Wear proper shoes and maintain balance to prevent a fall, failure to follow all instructions and warnings exactly may result in serious injury.

1. Keep children away from the swing during assembly.
2. Keep fingers away from the ends of the rails in the connecting area.

Step 3. Insert the eyebolt screw to the 4 joints on by one tightly as below.



Screws Swing body



Step 4. Finished!ready for swing.

Step 1. Place the swing on the floor, one small socket to one big socket, as below.



Step 2: Connect the small socket to the big socket firmly like below picture shows, repeat this 3 times one by one.



Welcome to visit our website and purchase our quality products!

Your suggestions and comments for COSTWAY are really important to us!
We sincerely solicit you to go back to our shop and leave a good rating in just a simple click. It would be quite encouraging if you could kindly do so like below:

★★★★★ Great products so far

February 24, 2019

Great products so far. Fast delivery, easy setup, and working without any issues.

With your inspiring rating, COSTWAY will be more consistent to offer you EASY SHOPPING EXPERIENCE, GOOD PRODUCTS and EFFICIENT SERVICE!

US office: Fontana, California

UK office: Ipswich



- * Reward Points
- * Exclusive Customer Service
- * Personalized Recommendations
- * Permanent Shopping Cart
- * Order History

5 Star Rating



We would like to extend our heartfelt thanks to all of our customers for taking time to assemble this product and giving us valuable feedbacks.

THANK
YOU
☺