



## Waterproof Laminate Flooring Care and Maintenance Do & Do Nots

<b>Do</b>	<b>Do Not</b>
Do vacuum using a soft bristle attachment	Do not use vacuum with beater bar
Do use a humidifier, dehumidifier, or air conditioner to help maintain temperature and humidity levels	Do not let your ambient temperature in the room fall outside the range of 60°F - 80°F and a relative humidity of 35% - 70%
Do use cleaning solutions specially formulated for laminate flooring	Do not use oil soaps, wax based cleaning solutions, or other chemicals that have abrasive properties
Do use a damp cloth, a well rung-out mop, or a residential steam mop where the head is covered and steam does not directly contact the laminate surface to clean up light spills and stains.	Do not use spray nozzle equipped mopping systems, or industrial steam equipment.
Do clean up spills immediately	Do not leave standing liquids of any kind
Do apply cleaning solution directly to cloth or mop	Do not spray liquids directly on floor
Do use protective mats under chairs with castors. Place felt floor protectors under furniture legs	Do not try to slide heavy objects across floor
Do use entry mats	Do not try sealing your floor with any aftermarket floor sealer