

OPERATOR'S MANUAL

MODEL #100814 7500W PORTABLE GENERATOR



REGISTER YOUR PRODUCT ONLINE

at championpowerequipment.com













or visit championpowerequipment.com

READ AND SAVE THIS MANUAL. This manual contains important safety precautions which should be read and understood before operating the product. Failure to do so could result in serious injury. This manual should remain with the product.

Specifications, descriptions and illustrations in this manual are as accurate as known at the time of publication, but are subject to change without notice. This product is rated in accordance with PGMA (Portable Generator Manufacturers' Association) standard PGMA G300 (Standard for Testing and Validating Performance of Portable Generators).

TABLE OF CONTENTS			
Introduction	3		
Safety Definitions	3		
Important Safety Instructions	4		
Fuel Safety	6		
Safety Symbols.	7		
Operation Symbols	8		
Safety Labels	9		
Controls and Features	10		
<u>Generator</u>	10		
Control Panel	11		
Parts Included	12		
Tools Needed	12		
Assembly	13		
<u>Unpacking</u>	13		
Install the Wheel Kit	13		
Connect the Battery	13		
Add Engine Oil	14		
Add Fuel	15		
Grounding	15		
<u>Operation</u>	16		
Generator Location	16		
<u>Grounding</u>	16		
Surge Protection	16		
Starting the Engine	16		
Connecting Electrical Loads	17		
Do Not Overload Generator	17		
<u>GFCI</u> .	18		
Stopping the Engine			
Operation at High Altitude	18		

<u>Maintenance</u>	19
Cleaning the Generator	19
Changing the Engine Oil	19
Cleaning and Adjusting the Spark Plug(s)	20
Cleaning the Air Filter	20
Cleaning the Spark Arrestor	20
Adjusting the Governor.	20
Generator Battery	20
Maintenance Schedule	21
Storage	21
Short Term Storage (up to 1 year)	
Long Term Storage (more than 1 year)	22
Removing from Storage	22
Specifications	23
Generator Specifications	23
Engine Specifications	23
Oil Specifications	23
Fuel Specifications	23
Spark Plug Specifications	23
Valve Specifications	23
Battery Specifications	23
Temperature Specifications	23
Parts Diagram	24
Parts List	25
Engine Parts Diagram	27
Engine Parts List	28
Wiring Diagram.	30
<u>Troubleshooting</u>	31

INTRODUCTION

Congratulations on your purchase of a Champion Power Equipment (CPE) product. CPE designs, builds, and supports all of our products to strict specifications and guidelines. With proper product knowledge, safe use, and regular maintenance, this product should bring years of satisfying service.

Every effort has been made to ensure the accuracy and completeness of the information in this manual at the time of publication, and we reserve the right to change, alter and/ or improve the product and this document at any time without prior notice.

Since CPE highly values how our products are designed, manufactured, operated and are serviced, and also highly value your safety and the safety of others, we would like you to take the time to review this product manual and other product materials thoroughly and be fully aware and knowledgeable of the assembly, operation, dangers and maintenance of the product before use. Fully familiarize yourself, and make sure others who plan on operating the product fully familiarize themselves too, with the proper safety and operation procedures before each use. Please always exercise common sense and always err on the side of caution when operating the product to ensure no accident, property damage, or injury occurs. We want you to continue to use and be satisfied with your CPE product for years to come.

When contacting CPE about parts and/or service, you will need to supply the complete model and serial numbers of your product. Transcribe the information found on your product's nameplate label to the table below

CPE TECHNICAL SUPPORT TEAM
1-877-338-0999
MODEL NUMBER
100814
SERIAL NUMBER
DATE OF DUDOUA OF
DATE OF PURCHASE
PURCHASE LOCATION

SAFETY DEFINITIONS

The purpose of safety symbols is to attract your attention to possible dangers. The safety symbols, and their explanations, deserve your careful attention and understanding. The safety warnings do not by themselves eliminate any danger. The instructions or warnings they give are not substitutes for proper accident prevention measures.

A DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

A WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

IMPORTANT SAFETY INSTRUCTIONS

A WARNING

Cancer and Reproductive Harm – <u>www.P65Warnings.ca.gov</u>

A DANGER

Generator exhaust contains carbon monoxide, a colorless, odorless, poison gas. Breathing carbon monoxide will cause nausea, dizziness, fainting or death. If you start to feel dizzy or weak, get to fresh air immediately.

OPERATE GENERATOR OUTDOORS ONLY IN A WELL VENTILATED AREA.

DO NOT operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle.

DO NOT allow exhaust fumes to enter a confined area through windows, doors, vents or other openings.

A DANGER

Using a generator indoors **CAN KILL YOU IN MINUTES**. Generator exhaust contains carbon monoxide. This is a poison you cannot see or smell.

NEVER use inside a home or garage, **EVEN IF** doors and windows are open.

ONLY use **OUTSIDE** and far away from windows, doors, and vents.



Install battery-operated carbon monoxide alarms or plug-in carbon monoxide alarms with battery back-up according to the manufacturer's instructions.

A DANGER

Rotating parts can entangle hands, feet, hair, clothing and/ or accessories. Traumatic amputation or severe laceration can result.

Keep hands and feet away from rotating parts.

Tie up long hair and remove jewelry.

Operate equipment with guards in place.

DO NOT wear loose-fitting clothing, dangling drawstrings or items that could become caught.

A WARNING

Operation of this equipment may create sparks that can start fires around dry vegetation.

A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.

A DANGER

Generator produces powerful voltage.

DO NOT touch bare wires or receptacles.

DO NOT use electrical cords that are worn, damaged or frayed. Use Champion electrical cords only for proper application.

DO NOT operate generator in wet weather.

DO NOT allow children or unqualified persons to operate or service the generator

Use a ground fault circuit interrupter (GFCI) in damp areas and areas containing conductive material such as metal decking.

Connection to your home's electrical system requires a listed 30A transfer switch installed by a licensed electrician and approved by the local authority having jurisdiction. The connection must isolate the generator from the utility power and must comply with all applicable laws and electrical codes.

A WARNING

Sparks can result in fire or electrical shock.

When servicing the generator:

Disconnect the spark plug wire and place it where it cannot contact the plug or any other metal object.

DO NOT check for spark with the plug removed.

Use only approved spark plug testers.

A WARNING

Running engines produce heat. Severe burns can occur on contact. Combustible material can catch fire on contact.

DO NOT touch hot surfaces.

Avoid contact with hot exhaust gases.

Allow equipment to cool before touching.

Maintain at least 3 ft. (91.4 cm) of clearance on all sides to ensure adequate cooling.

Maintain at least 5 ft. (1.5 m) of clearance from combustible materials.

A WARNING

Rapid retraction of the starter cord will pull hand and arm towards the engine faster than you can let go. Unintentional startup can result in entanglement, traumatic amputation or laceration. Broken bones, fractures, bruises or sprains could result.

When starting engine, pull the starter cord slowly until resistance is felt and then pull rapidly to avoid kickback.

DO NOT start or stop the engine with electrical devices plugged in and turned on.

A CAUTION

Exceeding the generator's running capacity can damage the generator and/or electrical devices connected to it.

DO NOT overload the generator.

DO NOT tamper with the governed speed.

DO NOT modify the generator in any way.

A CAUTION

Start the generator and allow the engine to stabilize before connecting electrical loads.

Connect electrical equipment in the off position, and then turn them on for operation.

Turn electrical equipment off and disconnect before stopping the generator.

A CAUTION

Improper treatment or use of the generator can damage it, shorten its life and void your warranty.

Use the generator only for intended uses.

Operate only on level surfaces.

DO NOT expose generator to excessive moisture, dust, or dirt.

DO NOT allow any material to block the cooling slots.

If connected devices overheat, turn them off and disconnect them from the generator.

DO NOT use the generator if:

- Electrical output is lost
- Equipment sparks, smokes or emits flames
- Equipment vibrates excessively

A WARNING

Medical and life support uses.

In case of emergency, call 911 immediately.

NEVER use this product to power life support devices or life support appliances.

NEVER use this product to power medical devices or medical appliances.

Inform your electricity provider immediately if you or anyone in your household depends on electrical equipment to live.

Inform your electrical provider immediately if a loss of power would cause you or anyone in your household to experience a medical emergency.

Fuel Safety

A DANGER

GASOLINE AND GASOLINE VAPORS) ARE HIGHLY FLAMMABLE AND EXPLOSIVE.

Fire or explosion can cause severe burns or death.

Gasoline and gasoline vapors:

- Gasoline is highly flammable and explosive.
- Gasoline can cause a fire or explosion if ignited.
- Gasoline is a liquid fuel but it's vapors can ignite.
- Gasoline is a skin irritant and needs to be cleaned up immediately if spilled on skin or clothes.
- Gasoline has a distinctive odor, this will help detect potential leaks quickly.
- In any petroleum gas fire, flames should not be extinguished unless by doing so the fuel supply valve can be turned OFF.
 This is because if a fire is extinguished and a supply of fuel is not turned OFF, then an explosion hazard could be created.
- Gasoline expands or contracts with ambient temperatures.
 Never fill the gasoline tank to full capacity, as gasoline needs room to expand if temperatures rise.

When adding or removing gasoline:

Turn the generator off and let it cool for at least two minutes before removing the gasoline cap. Loosen the cap slowly to relieve pressure in the tank.

Only fill or drain gasoline outdoors in a well-ventilated area.

DO NOT pump gasoline directly into the generator at the gas station. Use an approved container to transfer the fuel to the generator.

DO NOT overfill the gasoline tank.

Always keep gasoline away from sparks, open flames, pilot lights, heat and other sources of ignition.

DO NOT light or smoke cigarettes.

When starting the generator:

DO NOT attempt to start a damaged generator.

Make certain that the gasoline cap, air filter, spark plug, fuel lines and exhaust system are properly in place.

Allow spilled gasoline to evaporate fully before attempting to start the engine.

Make certain that the generator is resting firmly on level ground.

When operating the generator:

DO NOT move or tip the generator during operation.

DO NOT tip the generator or allow fuel or oil to spill.

When transporting or servicing the generator:

Make certain that the fuel valve is in the OFF position, the gasoline tank is empty.

Disconnect the spark plug wire.

When storing the generator:

Store away from sparks, open flames, pilot lights, heat and other sources of ignition.

Do not store generator or gasoline near furnaces, water heaters, or any other appliances that produce heat or have automatic ignitions.

A WARNING

Never use a gasoline container, gasoline tank, or any other fuel item that is damaged or appears damaged.

Safety Symbols

Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to more safely operate the product.

SYMBOL	MEANING
	Read Operator's Manual. To reduce the risk of injury, user must read and understand operator's manual before using this product.
\$\frac{1}{5ft/1.5m}\$	Clearance. Keep all objects at least 5 feet from this machine. Heat from the muffler and exhaust gas can ignite combustible objects.
	Ground. Consult with local electrician to determine grounding requirements before operation.
<u>A</u>	Electric Shock. Failure to use in dry conditions and to observe safe practices can result in electric shock. Improper connections to a building can allow current to backfeed into utility lines, creating an electrocution hazard. A transfer switch must be used when connecting to a building.
	Fire/Explosion. Fuel and its vapors are extremely flammable and explosive. Fire or explosion can cause severe burns or death. Operation of this equipment may create sparks that can start fires around dry vegetation. A spark arrestor may be required. The operator should contact local fire agencies for laws or regulations relating to fire prevention requirements.
	Hot Surface. To reduce the risk of injury or damage, avoid contact with any hot surface.
	Open Flame Alert. Fuel and its vapors are extremely flammable and explosive. Keep fuel away from smoking, open flames, sparks, pilot lights, heat, and other ignition sources.
	Wet Conditions Alert. Do not expose to rain or use in damp locations.

Operation Symbols

Some of the following symbols may be used on this product. Please study them and learn their meaning. Proper interpretation of these symbols will allow you to more safely operate the product.


SYM	IB0L	MEANING	
•	B	Engine START	
4		Engine ON	
\emptyset	U	Engine STOP	
3		Circuit Breaker Reset: Push	
N		Neutral Bonded to Frame. Neutral circuit IS electrically connected to the frame/ground of the generator.	
10W-30		Check Oil Level. Recommended oil is 10W-30. The engine can be seriously damaged without oil. Always check the oil level before using. The machine must be resting firmly on level ground when checking.	
		Fuel Valve ON.	
		Ignition Switch ON. Press the Ignition Switch to "ON" position.	
/		Choke. Move choke lever to "CHOKE" position.	
*		Recoil Starter. Pull recoil starter to start the engine.	


SYMBOL	MEANING
	Choke. Move choke lever to "RUN" position.
4	Plug In. Plug in desired devices.
4	Unplug. Unplug devices when turning generator off.
	Ignition Switch OFF. Press the Ignition Switch to "OFF" position.
	Fuel Valve OFF.
0-65	See Manual for Electric Start. Follow instruction in operator's manual to start the generator electrically.
	Check Fuel Level. Use clean, fresh, regular unleaded gasoline with a minimum octane rating of 87 and an ethanol content of less than 10% by volume.

Safety Labels

These labels warn you of potential hazards that can cause serious injury. Read them carefully.

If a label comes off or becomes hard to read, contact Technical Support Team for possible replacement.






Top Back

	LABEL	DESCRIPTION
Α	Using a generator indoors CAN KILL YOU IN MINUTES. Generator edusart contains curbon monoids. This is a poion you cannot see or small. NEVER use inside a fluor so grange, since the contains and the contains an	Safety Icons/ CO Danger
В	UNLEADED FUEL ONLY. Minimum octane rating of 87. Maximum 10% ethanol. 687. Maximum 10% ethanol. 688	Fuel
С	A WARNING DO NOT TOUCH Exhaust gases, muffler and engine components required. The operation of this equipment may create sparks that can start first are out mently HOT and leaves and regulations relating to fire prevention requirements. If installed, clean every 100 hours or every season. If installed, clean every 100 hours or every season.	Hot Surface

CONTROLS AND FEATURES

Read this operator's manual before operating your generator. Familiarize yourself with the location and function of the controls and features. Save this manual for future reference.


Generator



- 1. **Gasoline Tank** 5.7 gal. (21.5 L)
- 2. **Choke** Used to start the engine.
- 3. Fuel Valve Used to turn fuel supply on and off to engine.
- 4. **Air Filter** Protects the engine by filtering dust and debris from the intake air.
- 5. **Recoil Starter** Used to manually start the engine.
- 6. **Never Flat Wheels** 9.5 in. (24.1 cm)
- 7. **Battery** Provides 12V DC power the starting system.

- 8. **Oil Fill Cap/Dipstick** Used to check and fill oil level.
- 9. **Control Panel** See "Control Panel" section.
- 10. **Folding Handle** Used to move unit by lifting and rolling on wheels. Do not use to lift or carry the unit.
- 11. Carrying Handle(s) Used to lift or carry the unit.
- 12. **Ground Terminal** Consult an electrician for local grounding regulations.

Control Panel




- 1. **Ignition Switch** Used to START or STOP the generator.
- 2. **Intelligauge** Three mode digital meter for displaying run time, voltage and hertz.
- 3. **Circuit Breakers (Push Reset)** Protects the generator against electrical overloads.

	RECEPTACLES			
A	Ţ.	(4×) 120V AC, 20A GFCI (NEMA 5-20R) May be used to supply electrical power for operation of 120 Volt AC, 20 Amp, single phase, 60 Hz electrical loads.		
В	(3)	120/240V AC, 30A Locking (NEMA L14-30R) May be used to supply electrical power for operation of 120/240 Volt AC, 30 Amp, single phase, 60 Hz electrical loads.		
С	•	120/240V AC, 50 Amp (NEMA 14-50R) May be used to supply electrical power for operation of 120/240 Volt AC, 50 Amp, single phase, 60 Hz electrical loads.		

Parts Included

Accessories





Assembly Parts

Wheels

	9.5 in. (24.1 cm) Never Flat Wheel (A)	. 2
	Roll Pin (B)	. 2
	Large R-clip (C)	. 2
En	gine Vibration Mounts	
	Support Leg with Vibration Mounts (D)	. 1
	Flange Bolt (M8×16) (E)	. 2
	Flange Lock Nut (M8) (F)	. 2
Fo	lding Handle	
	Handle (G)	. 1
	Short Pin (H)	. 2
	Small R-clip (I)	. 2

Tools Needed

- Wrench/Socket Set (metric)
- Pliers
- Phillips Screwdriver

ASSEMBLY

Your generator requires some assembly. This unit ships from our factory without oil. It must be properly serviced with fuel and oil before operation.

If you have any questions regarding the assembly of your generator, call our Technical Support Team at 1-877-338-0999. Please have your serial number and model number available.

Unpacking


- 1. Set the shipping carton on a solid, flat surface.
- 2. Remove everything from the carton except the generator.
- Carefully cut each corner of the box from top to bottom.Fold each side flat on the ground to provide a surface area to work with the generator.

Install the Wheel Kit

A CAUTION


The wheel kit is not intended for over-the-road use.

- 1. Before adding fuel and oil, tip the generator on it's end.
- 2. Slide the Roll Pin (B) through the Wheel (A) from the outside.
- 3. Slide the Roll Pin through the mount point on the frame.
- 4. Secure with the R-clip (C).
- 5. Repeat to attach the second Wheel.




Install the Support Leg

- 1. Attach the Support Leg (D) to the generator frame with Flange Bolts (E) and Flange Lock Nuts (F).
- 2. Slowly tip the generator back down so that it rests on the Wheels and Support Leg.




Install the Handle

- 1. Place the Handle (G) inside the mounting channel on the frame.
- 2. Secure the Handle to the frame using an Short Pin (H).
- 3. Place an R-clip (I) on the end of the Short Pin and fasten securely.



Connect the Battery

- 1. Remove the protective cover from the black (–) lead on the battery.
- 2. Attach the black (–) lead to the (–) terminal on the battery with the bolt and secure with the nut.



Add Engine Oil

A CAUTION


DO NOT attempt to crank or start the engine before it has been properly filled with the recommended type and amount of oil. Damage to the generator as a result of failure to follow these instructions will void your warranty.

NOTICE


The generator rotor has a sealed, pre-lubricated ball bearing that requires no additional lubrication for the life of the bearing.

NOTICE


The recommended oil type is 10W-30 automotive oil.



- Place the generator on a flat, level surface.
- 2. Remove oil fill cap/dipstick to add oil.
- 3. Using a funnel, add up to 1.2 qt. (1.1 L) of oil (included) and replace oil fill cap/dipstick. DO NOT OVERFILL.



4. Check engine oil level daily and add as needed.



NOTICE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole.

If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.

NOTICE

Check oil often during the break-in period. Refer to the Maintenance section for recommended service intervals.

A CAUTION

The engine is equipped with a low oil shut-off and will stop when the oil level in the crankcase falls below the threshold level.

NOTICE

The first 5 hours of run time are the break-in period for the unit. During the break in period stay at or below 50% of the running watt rating and vary the load occasionally to allow stator windings to heat and cool. Adjusting the load will also cause engine speed to vary and help seat piston rings. After the 5 hour break-in period, change the oil.

NOTICE


Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

NOTICE

Synthetic oil may be used after the 5 hour initial breakin period. Using synthetic oil does not increase the recommended oil change interval. Full synthetic 5W-30 oil will aid in starting in cold ambient <5° C (41° F).

Add Fuel

- Use clean, fresh, regular unleaded gasoline with a minimum octane rating of 87 and an ethanol content of 10% or less by volume.
- 2. DO NOT mix oil with gasoline.
- 3. Remove the gasoline cap.
- 4. Slowly add gasoline to the tank. Tank is full when gasoline reaches red circle on screen. DO NOT OVERFILL. Gasoline can expand after filling. A minimum of ¼ in. (6.4 mm) of space left in the tank is required for gasoline expansion, although more than ¼ in. (6.4 mm) is recommended. Gasoline can be forced out of the tank as a result of expansion if overfilled, and can affect the stable running condition of the generator.



5. Screw on the gasoline cap and wipe away any spilled fuel.

A CAUTION

Use regular unleaded gasoline with a minimum octane rating of 87 and an ethanol content of 10% or less by volume.

DO NOT mix oil and gasoline.

Fill tank to approximately ¼ in. (6.4 mm) below the top of the tank to allow for gasoline expansion.

DO NOT pump gasoline directly into the generator at the pump. Use an approved container to transfer the gasoline to the generator.

DO NOT fill tank indoors.

DO NOT fill tank when the engine is running or hot.

DO NOT overfill the tank.

DO NOT light cigarettes or smoke when filling the tank.

A WARNING

Pouring gasoline too fast through the fuel screen may result in blow back of gasoline at the operator while filling.

NOTICE

Our engines work well with 10% or less ethanol blend gasoline. When using ethanol-gasoline blends there are some issues worth noting:

- Ethanol-gasoline blends can absorb more water than gasoline alone.
- These blends can eventually separate, leaving water or a watery goo in the tank, fuel valve and carburetor.
- With gravity-fed supplies, the compromised gasoline can be drawn into the carburetor and cause damage to the engine and/or potential hazards.
- There are only a few suppliers of fuel stabilizer that are formulated to work with ethanol-gasoline blends.
- Any damages or hazards caused by using improper gasoline, improperly stored gasoline, and/or improperly formulated stabilizers, are not covered by manufacturer's warranty.

It is advisable to always shut off the gasoline supply, run the engine to starvation and drain the tank when the equipment is not in use for more than 30 days.

Grounding

Your generator must be properly connected to an appropriate ground to help prevent electric shock.

A WARNING

Failure to properly ground the generator can result in electric shock.

A ground terminal connected to the frame of the generator has been provided (see <u>Controls and Features</u> for terminal location). For remote grounding, connect of a length of heavy gauge (12 AWG minimum) copper wire between the generator ground terminal and a copper rod driven into the ground. We strongly recommend that you consult with a qualified electrician to ensure compliance with local electrical codes.

OPERATION

Generator Location

NEVER operate the generator inside any building, including garages, basements, crawlspaces and sheds, enclosure or compartment, including the generator compartment of a recreational vehicle. Please consult your local authority. In some areas, generators must be registered with the local utility. Generators used at construction sites may be subject to additional rules and regulations. Generators should be on a flat, level surface at all times. (Even while not in operation) Generators must have at least 5 ft. (1.5 m) of clearance from all combustible material. In addition to clearance from all combustible material, generators must also have at least 3 ft. (91.4 cm) of clearance on all sides to allow for adequate cooling, maintenance and servicing. Generators should never be started or operated in the back of a SUV, camper, trailer, in the bed of a truck (regular, flat or otherwise), under staircases/stairwells, next to walls or buildings, or in any other location that will not allow for adequate cooling of the generator and/or the muffler. DO NOT contain generators during operation. Allow generators to properly cool before transport or storage.

Install battery-operated carbon monoxide alarms or plug-in carbon monoxide alarms with battery back-up in your home according to the manufacturer's instructions.

Place the generator in a well-ventilated area. DO NOT place the generator near vents or intakes where exhaust fumes could be drawn into occupied or confined spaces. Carefully consider wind and air currents when positioning generator.

Failure to follow proper safety precautions may void manufacturer's warranty.

A WARNING

Do not operate or store the generator in rain, snow, or wet weather.

Using a generator or electrical appliance in wet conditions, such as rain or snow, or near a pool or sprinkler system, or when your hands are wet, could result in electrocution.

A WARNING

During operation the muffler and exhaust fumes produced will become hot. If adequate cooling and breathing space are not supplied, or if the generator is blocked or contained, temperatures can become extremely heated and may lead to fire.

Grounding

A ground terminal connected to the frame of the generator has been provided (see Controls and Features for terminal location).

Neutral Floating*

- Neutral circuit IS NOT electrically connected to the frame/ ground of the generator.
- The generator (stator winding) is isolated from the frame and from the AC receptacle ground pin.
- Electrical devices that require a grounded receptacle pin connection will not function if the receptacle ground pin is not functional.

Neutral Bonded to Frame*

- Neutral circuit IS electrically connected to the frame/ground of the generator.
- The generator system ground connects lower frame cross-member below the alternator. The system ground is connected to the AC neutral wire.

Surge Protection

Electronic devices, including computers and many programmable appliances use components that are designed to operate within a narrow voltage range and may be affected by momentary voltage fluctuations. While there is no way to prevent voltage fluctuations, you can take steps to protect sensitive electronic equipment.

 Install UL1449, CSA-listed, plug-in surge suppressors on the outlets feeding your sensitive equipment.
 Surge suppressors come in single- or multi-outlet styles.
 They're designed to protect against virtually all shortduration voltage fluctuations.

Starting the Engine

- 1. Make certain the generator is on a flat, level surface.
- Disconnect all electrical loads from the generator. Never start or stop the generator with electrical devices plugged in or turned on.
- 3. Turn the gasoline fuel valve to the "ON" position.
- 4. Move the choke to the "CHOKE" position.
- 5. For restarting a warm engine, move the choke to 75% of the "CHOKE" position.

Electric Start

- 1. Push the ignition switch to the "ON" position.
- Press and hold the ignition switch to the "START" position.
 Release as the engine begins to start. If the engine fails
 to start within five seconds, release the switch and wait
 at least ten seconds before attempting to start the engine
 again.

^{*}See your model's control panel for specified type of grounding.

3. Do not over-choke. As soon as engine starts, move the choke to the "RUN" position over a 2-5 second duration.

A CAUTION

If the ignition switch is held down in the "START" position longer than 5 seconds it could damage the starter.

Manual Start

- 1. Push the ignition switch to the "ON" position.
- 2. Pull the starter cord slowly until resistance is felt and then pull rapidly.
- 3. Do not over-choke. As soon as engine starts, move the choke to the "RUN" position over a 2-5 second duration.

NOTICE

Keep choke in "CHOKE" position for only 1 pull of the recoil starter. After first pull, move choke to the "RUN" position for up to the next 3 pulls of the recoil starter. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

NOTICE

For gasoline restarts with hot engine in hot ambient > 30°C (86°F): Keep the choke in 75% of the "CHOKE" position for only 1 pull of the recoil starter. After first pull, move choke to the "RUN" position for up to 3 more pulls of the recoil starter. Too much choke leads to spark plug fouling/engine flooding due to the lack of incoming air. This will cause the engine not to start.

NOTICE

For gas starting in cold ambient <15°C (59°F): the choke must be in 100% of the "CHOKE" position for recoil start procedures. Do not over-choke. As soon as engine starts, gradually move the choke lever to the "RUN" position over a 2-5 second duration.

NOTICE

If the engine starts but does not run make certain that the generator is on a flat, level surface. The engine is equipped with a low oil sensor that will prevent the engine from running when the oil level falls below a critical threshold.

Connecting Electrical Loads

Let the engine stabilize and warm up for a few minutes after starting.

Plug in and turn on the desired 120 or 240 (if applicable) Volt AC single phase, 60 Hz electrical loads.

- D0 N0T connect 3-phase loads to the generator.
- D0 N0T connect 50 Hz loads to the generator.
- DO NOT overload the generator.

A WARNING

Connecting a generator to your electric utility company's power lines or to another power source may be against the law. In addition this action, if done incorrectly, could damage your generator and appliances and could cause serious injury or even death to you or a utility worker who may be working on nearby power lines. If you plan to run a portable electric generator during an outage, please notify your electric utility company immediately and remember to plug your appliances directly into the generator. Do not plug the generator into any electric outlet in your home. Doing so could create a connection to the utility company power lines. You are responsible for ensuring that your generator's electricity does not feed back into the electric utility power lines.

If the generator will be connected to a building electrical system, consult your local utility company or a qualified electrician. Connections must isolate generator power from utility power and must comply with all applicable laws and codes.

Do Not Overload Generator

Capacity

Follow these simple steps to calculate the running and starting watts necessary for your purposes:

- 1. Select the electrical devices you plan on running at the same time.
- 2. Total the running watts of these items. This is the amount of power you need to keep your items running.
- 3. Identify the highest starting wattage of all devices identified in step 1. Add this number to the number calculated in step 2. Starting wattage is the extra burst of power needed to start some electric driven equipment. Following the steps listed under "Power Management" will guarantee that only one device will be starting at a time.

Power Management

Use the following formula to convert voltage and amperage to watts:

Volts × Amps = Watts

To prolong the life of your generator and attached devices, follow these steps to add electrical load:

- 1. Start the generator with no electrical load attached
- 2. Allow the engine to run for several minutes to stabilize.
- 3. Plug in and turn on the first item. It is best to attach the item with the largest load first.
- 4. Allow the engine to stabilize.
- 5. Plug in and turn on the next item.
- 6. Allow the engine to stabilize.
- 7. Repeat steps 5-6 for each additional item.




Never exceed the specified capacity when adding loads to the generator.

GFCI

Your generator is equipped with ground fault circuit interrupter (GFCI) receptacles. In the event of a ground fault, a GFCI trips automatically to stop the flow of electricity and prevent serious injury. The green indicator light (A) on the receptacle will also turn off. Press the "RESET" (B) button located on the front of the receptacle to restore flow of electricity. The indicator light will also turn back on. GFCI does not protect against circuit overloads.

To ensure proper operation of the GFCI duplex, perform this test monthly:

- 1. With the generator running, plug a lamp into the GFCI receptacle. Turn the lamp on.
- Press the "TEST" (C) button located on the front of the receptacle to trip the device. This should immediately stop the flow of electricity and shut off the lamp. If the electricity is not stopped, do not use this receptacle until is has been serviced or replaced.
- Press the "RESET" button located on the front of the receptacle to restore the flow of electricity. If the indicator light does not come back on or if the GFCI cannot be reset then it must be replaced.



Stopping the Engine

- Turn off and unplug all electrical loads. Never start or stop the generator with electrical devices plugged in or turned on.
- 2. Let the generator run at no-load for several minutes to stabilize internal temperatures of the engine and generator.
- 3. Turn the fuel valve to the "OFF" position.
- 4. Let the engine run until fuel starvation has stopped the engine. This usually takes a few minutes.
- 5. Press the ignition switch to the "OFF" position.

Important: Always ensure that the fuel valve and the ignition switch are in the "OFF" position when the generator is not in use.

NOTICE

If the engine will not be used for a period of two (2) weeks or longer, please see the <u>Storage</u> section for proper engine and fuel storage.

Operation at High Altitude

The density of air at high altitudes is lower than at sea level. Engine power is reduced as the air mass and air-fuel ratio decrease. Engine power and generator output will be reduced approximately 3½% for every 1000 ft. of elevation above sea level. At high altitudes increased exhaust emissions can also result due to the increased enrichment of the air fuel ratio. Other high altitude issues can include hard starting, increased fuel consumption and spark plug fouling.

To alleviate high altitude issues other than the natural power loss, CPE can provide a high altitude carburetor main jet. The alternative main jet and installation instructions can be obtained by contacting our Technical Support Team. Installation instructions are also available in the Technical Bulletin area of the CPE website.

The part number and recommended minimum altitude for the application of the high altitude carburetor main jet is listed in the following table.

In order to select the correct high altitude main jet it is necessary to identify the carburetor model. For this purpose, a code is stamped on the side of the carburetor. Select the correct high altitude jet part number corresponding to the carburetor code found on your particular carburetor.

Carb. Code	High Alt. Jet Part Number	Min. Altitude
Z950-1	100155681	3281 ft. (1000 m)
2930-1	100155681	6562 ft. (2000 m)

A WARNING

Operation using the alternative main jet at elevations lower than the recommended minimum altitude can damage the engine. For operation at lower elevations, the originally supplied standard main jet must be used. Operating the engine with the wrong engine configuration at a given altitude may increase its emissions and decrease fuel efficiency and performance.

MAINTENANCE

Make certain that the generator is kept clean and stored properly. Only operate the unit on a flat, level surface in a clean, dry operating environment. DO NOT expose the unit to extreme conditions, excessive dust, dirt, moisture or corrosive vapors.

A WARNING

Never operate a damaged or defective generator.

A WARNING

Improper maintenance will void your warranty.

NOTICE

Maintenance, replacement, or repair of emission control devices and systems may be performed by any non-road engine repair establishment or individual.

The owner/operator is responsible for all periodic maintenance.

Complete all scheduled maintenance in a timely manner.

Correct any issue before operating the generator.

For service or parts assistance, contact our Technical Support Team at 1-877-338-0999.

Cleaning the Generator

A CAUTION

DO NOT spray engine with water.

Water can enter the generator through the cooling slots and damage the generator windings. It can also contaminate the fuel system.


- Use a damp cloth to clean exterior surfaces of the generator.
- 2. Use a soft bristle brush to remove dirt and oil.
- 3. Use an air compressor (25 PSI) to clear dirt and debris from the generator.
- 4. Inspect all air vents and cooling slots to ensure that they are clean and unobstructed.

To prevent accidental starting, remove and ground the spark plug wire before performing any service.

Changing the Engine Oil

Change oil when the engine is warm. Refer to the oil specification to select the proper grade for your operating environment.

 Remove the oil drain plug with a 12 mm socket (not included) and extension.




- 2. Allow the oil to drain completely into an appropriate container.
- 3. Replace the oil drain plug.
- 4. Remove the oil fill cap/dipstick to add oil.
- Add oil according to "Add Engine Oil" on Assembly section. DO NOT OVERFILL. Oil not included for routine maintenance.
- 6. Dispose of used oil at an approved waste management facility.

NOTICE

Once oil has been added, a visual check should show oil about 1-2 threads from running out of the fill hole. If using the dipstick to check oil level, DO NOT screw in the dipstick while checking.

Cleaning and Adjusting the Spark Plug(s)

- 1. Remove the spark plug cable from the spark plug.
- 2. Use a spark plug socket tool (not included), or a 13/16 in. (21 mm) socket (not included) to remove the plug.
- 3. Inspect the electrode on the plug. It must be clean and not worn to produce the spark required for ignition.
- 4. Make certain the spark plug gap is 0.024-0.031 in. (0.6-0.8 mm).



- 5. Refer to the spark plug types in <u>Specifications</u> when replacing the plug.
- 6. Firmly re-install the plug.
- 7. Attach the spark plug cable to the spark plug.


Cleaning the Air Filter

- Remove the snap-on cover holding the air filter to the assembly.
- 2. Remove the foam element.
- 3. Wash in liquid detergent and water. Squeeze thoroughly dry in a clean cloth.
- 4. Saturate in clean engine oil.
- 5. Squeeze in a clean, absorbent cloth to remove all excess oil.
- 6. Place the filter in the assembly.
- 7. Reattach the air filter cover and snap in place.

Cleaning the Spark Arrestor

- Allow the engine to cool completely before servicing the spark arrestor.
- Remove the two or three screws (varies by model) holding the cover plate which retains the spark arrestor to the muffler.

- 3. Remove the spark arrestor screen.
- 4. Carefully remove the carbon deposits from the spark arrestor screen with a wire brush.



- *See your model's parts list for specified type of spark arrestor.
- 5. Replace the spark arrestor if it is damaged.
- 6. Position the spark arrestor on the muffler and attach with the screws removed in step 2.

A CAUTION

Failure to clean the spark arrestor will result in degraded engine performance.

NOTICE

Federal and local laws and administrative requirements indicate when and where spark arrestors are required. When ordered, spark arrestors are required for operation of this generator in National Forest lands. In California, this generator must not be used on any forest-covered land, brush-covered land, or grass-covered land unless the engine is equipped with a spark arrestor.

Adjusting the Governor

▲ WARNING

Tampering with the factory set governor will void your warranty.

The air-fuel mixture is not adjustable. Tampering with the governor can damage your generator and your electrical devices and will void your warranty. Contact our Technical Support Team at 1-877-338-0999 for all other service and/or adjustment needs.

Generator Battery

Your generator is equipped with an automatic battery charging circuit that charges the battery while the engine is running. The battery will maintain a proper charge if the unit is used on a regular basis (about once every two weeks). If it is used less frequently, the battery should be connected to a trickle charger or battery maintainer (not included) to keep the battery properly charged.

Maximum charging rate should not exceed 1.5 amps. Follow the instructions included with the battery charger. The battery should be fully charged at least once per month. If the battery is not able to start the engine, it can be started by manually pulling the engine recoil cord. If the battery voltage is extremely low, the charging circuit may not be able to re-charge the battery. In this case, the battery must be connected to a standard automotive style battery charger for re-charging before it can be used.

Disconnect the Battery

- Remove the protective cover from the black (–) battery lead.
- 2. Disconnect the black (–) lead from the black (–) terminal on the battery and store the cap screw and nut.
- 3. Repeat steps 1-2 for the red (+) battery lead.
- 4. Store the battery in a cool, dry place.

Charge the Battery

For a generator equipped with batteries for electric starting, proper battery maintenance and storage should be followed. A trickle charger or battery maintainer should be used to charge the battery while the generator is in storage. Maximum charging rate should not exceed 1.5 amps. Follow the instructions included with the trickle charger or battery maintainer. The battery should be fully charged at least once per month.

Maintenance Schedule

Follow the service intervals indicated in the following maintenance schedule.

Service your generator more frequently when operating in adverse conditions.

Contact our Technical Support Team at 1-877-338-0999 to locate the nearest CPE certified service dealer for your generator or engine maintenance needs.

EVERY 8 HOURS OR DAILY
☐ Check oil level
☐ Clean around air intake and muffler
FIRST 5 HOURS
☐ Change oil
EVERY SO HOURS OF EVERY OF AGON
EVERY 50 HOURS OR EVERY SEASON
☐ Clean air filter

Change oil if operating under heavy load or in hot

environments

EVERY 100 HOURS OR EVERY SEASON ☐ Change oil ☐ Clean/adjust spark plug ☐ Check/adjust valve clearance* ☐ Clean spark arrestor ☐ Clean fuel tank and filter*

EVERY 250 HOURS

□ Clean combustion chamber*

EVERY 3 YEARS

☐ Replace fuel line*

*To be performed by knowledgeable, experienced owners or CPE certified service centers.

STORAGE

A DANGER

Gasoline and gasoline vapors are highly flammable and extremely explosive.

Fire or explosion can cause severe burns or death. Only fill or drain fuel outdoors in a well-ventilated area. DO NOT pump gasoline directly into the generator. Use an approved container to transfer the fuel to the generator. Never use a gasoline container, gasoline tank, or any other fuel item that is damaged or appears damaged. DO NOT overfill the gasoline tank. Always keep fuel away from sparks, open flames, pilot lights, heat and other sources of ignition. DO NOT light or smoke cigarettes.


Short Term Storage (up to 1 year)

Gasoline in the gasoline tank has a maximum shelf life of up to 1 year with the addition of properly formulated fuel stabilizers and if stored in a cool, dry place. Gasoline in the carburetor, however, may gum up and clog the carburetor if it isn't used or drained within 2-4 weeks.

- 1. Be sure all appliances are disconnected from the generator.
- 2. Add a properly formulated fuel stabilizer to the gasoline tank.
- 3. Turn the fuel valve to the "ON" position.
- 4. Start and run the generator for 10 minutes so the treated gasoline cycles through the fuel system and carburetor.
- Turn ignition switch to the "OFF" position and allow generator to cool completely before continuing.

6. Option 1: Drain Gasoline from Carburetor

- 6a. Turn the fuel valve to the "OFF".
- 6b. Use the drain bolt on the carburetor to empty any excess gasoline from the carburetor into an appropriate container. Use a funnel (and appropriate hose if necessary) under the carburetor drain bolt to avoid spillage.



6c. When gasoline stops flowing from the carburetor, replace and tighten the carburetor drain bolt and be sure to properly dispose of the drained gasoline according to local regulations or guidelines.

7. Option 2: Run Dry

- 7a. Turn ignition switch to the "ON" position and start the generator.
- 7b. With the generator running, turn the fuel valve to the "OFF" position and allow the generator to run until the engine stops from complete fuel starvation. This may take a few minutes.
- 7c. Turn ignition switch to the "OFF" position and allow generator to cool completely before continuing.
- 8. Remove the spark plug cap and spark plug and pour about a tablespoon of oil into the cylinder.
- 9. Pull the recoil slowly to crank the engine to distribute the oil and lubricate the cylinder.
- 10. Reattach the spark plug and spark plug cap.
- 11. Disconnect and charge the battery according to <u>Generator</u> <u>Battery</u>.
- 12. Clean the generator according to Cleaning the Generator.
- 13. Store the generator in a cool, dry place out of direct sunlight.

Long Term Storage (more than 1 year)

For storage over 1 year, the gasoline tank and carburetor must be completely drained of gasoline.

- 1. Follow steps 1-5 according to **Short Term Storage**.
- 2. Use the drain bolt on the carburetor to empty any excess gasoline from the gasoline tank and carburetor into an

- appropriate container. Use a funnel (and appropriate hose if necessary) under the carburetor drain bolt to avoid spillage.
- When gasoline stops flowing from the carburetor, replace and tighten the carburetor drain bolt and be sure to properly dispose of the drained gasoline according to local regulations or guidelines.
- 4. Turn the fuel valve to the "OFF" position.
- 5. Follow steps 8-13 according to Short Term Storage.

Removing from Storage

If the generator has been improperly stored for a long period of time with gasoline in the gasoline tank and/or carburetor, all fuel must be drained and the carburetor must be thoroughly cleaned. This process involves technically advanced tasks. For assistance please call our Technical Support Team at 1-877-338-0999.

If the gasoline tank and carburetor were properly emptied of all gasoline prior to the generator being stored, follow the below steps when removing from storage.

- 1. Be sure the ignition switch is in the "OFF" position.
- Add gasoline to the generator according to <u>Add Fuel:</u> <u>Gasoline</u>.
- 3. Turn the fuel valve to the "ON" position.
- 4. After 5 minutes check the carburetor and air filter areas for any leaking gasoline. If any leaks are found, the carburetor will need to be disassembled and cleaned or replaced. If no gasoline leaks are found, turn the fuel valve to the "OFF" position.
- Check engine oil level and add clean, fresh oil if needed.See <u>Oil Specifications</u> for proper oil type.
- Check and clear air filter of any obstructions such as bugs or cobwebs. If necessary, clean air filter according to <u>Cleaning the Air Filter</u>.
- 7. Connect the battery according to Connect the Battery.
- 8. Start the generator according to Starting the Engine.

A DANGER

Generator exhaust contains odorless and colorless carbon monoxide gas.

To avoid accidental or unintended ignition of your generator during periods of storage, the following precautions should be followed:

- When storing the generator make sure the ignition switch and fuel valve are set to the "OFF" position.
- Disconnect the battery according to <u>Generator Battery</u>.

SPECIFICATIONS

Generator Specifications

Generator Model	100814
Start Type	Electric, Manual
Watts (Starting/Running)	9375/7500
AC Volts	120/240
AC Amps @ 120 (Starting/Running)	
AC Amps @ 240 (Starting/Running)	39.1/31.3
Frequency	60 Hz
Phase	Single
Gross Weight	218.4 lb. (99.1 kg)
Net Weight	202.8 lb. (92 kg)
Length	29.9 in. (76 cm)
Width	27.2 in. (69.1 cm)
Height	25.2 in. (64.1 cm)


Engine Specifications

Model F	H420
Displacement 4	20 cc
Type 4-Stroke	OHV :

Oil Specifications

DO NOT OVERFILL.

Type	*See chart below
Capacity	1.2 qt. (1.1 L)



NOTICE

Weather will affect engine oil and engine performance. Change the type of engine oil used based on weather conditions to suit the engine needs.

Fuel Specifications

Use regular unleaded gasoline with a minimum octane rating of 87 and an ethanol content of 10% or less by volume. DO NOT USE E15 or E85. DO NOT OVERFILL.

Gasoline Capacity	5 7 aal	(21.5 L)
Casulle Canacity	uai.	(Z 1.0 L)

Spark Plug Specifications

OEM Type	NHSP F6RTC
Replacement Type	NGK BPR6ES or equivalent
Gap	0.024-0.031 in. (0.6-0.8 mm)

Valve Specifications

Intake Clearance	0.004 0.006 in.	(0.10-0.15 m	ım)
Exhaust Clearance	0.006-0.008 in.	(0.15-0.20 m	ım)

NOTICE

A technical bulletin regarding valve adjustment procedures is available at www.championpowerequipment.com.

Battery Specifications

Type	Rechargeable, Non-Spillable Lead Acid
Volts	12
Canacity	14 Ah


Temperature Specifications

Starting Temperature Range (°F/°C) 5 to 104/-15 to 40

NOTICE

An important message about temperature: Your product is designed and rated for continuous operation at ambient temperatures up to 40°C (104°F). When your product is needed it may be operated at temperatures ranging from 5°F (-15°C) to 122°F (50°C) for short periods of time. If exposed to temperatures outside this range during storage, it should be brought back within this range before operation. In any event, the product must always be operated outdoors, in a well-ventilated area and away from doors, windows and vents.

Parts Diagram




Parts List

#	Part Number	Description	Qty.
1	100011530-0002	Flange Bolt M6 x 16	4
2	100156698-0001	Panel Assembly	1
3	100019844	Protect Panel	1
4	100086301	Control Panel	1
5	100019771-0001	Switch	1
6	100019890	Intelligauge, VFT	1
7	100019754	20Amp Circuit Breaker, Push Button	2
8	100052461-0001	Receptacle GFCI 5-20R, Duplex	2
9	100020021	Receptacle L14-30R	1
10	100020022	Receptacle 14-50R	1
11	100019751	30Amp Circuit Breaker, Push Button	2
12	100088266	Receptacle Cover 14-50R	1
13	100088267	Receptacle Cover L14-30R	1
14	100088270	Receptacle Cover GFCI 5-20R, Duplex	2
15	100011064-0002	Roll Pin Ø16 x 100	2
16	100020700-0002	9.5 In. Wheel, Black	2
17	100023414-0001	R-pin	2
18	100085051-0001	Frame	1
19	100005138	Clamp	1
20	100021153	Fuel Valve	1
21	100136768-0001	Fuel Tank, 21.5 L	1
22	100032382	Fuel Level Filter Assembly	1
23	100008968	Reversal Valve	1
24	100091755	Fuel Tank Cap	1
25	100010439-0002	Washer Ø6.5 x 2 x Ø25	4
26	100011268-0003	Flange Bolt M6 x 25	5
27	100009075	Rubber Damper	1
28	100009983	Grounding Line	1
29	100011025-0001	Lock Washer Ø6, Toothed	1
30	100010886-0004	Spring Washer Ø6	2
31	100011421-0003	Flange Nut M6	1
32	100010920-0002	Flat Washer Ø6	3
33	100010828-0002	Butterfly Type Nut M6	1
34	100009967-0001	Positive Wire	1
35	100009990-0001	Negative Wire	1
36	100021409	Battery, 12V 14Ah	1
37	100021362	Fixing Bolt, Battery	2

#	Part Number	Description	Qty.
		Pressing Plate, Battery,	
38	100021372-0017	184 mm	1
39	100011452-0003	Lock Nut M6, Flange	5
40	100011311-0005	Flange Bolt M8 x 16	4
41	100020981-0004	Support Leg Assembly, 80 mm	1
42	100020665-0001	Support Leg	1
43	100021015	Vibration Mount	2
44	100011265-0003	Flange Bolt M6 x 18	2
45	100011453-0003	Lock Nut M8, Flange	6
46	100011049-0001	Roll Pin Ø8 x 45	2
47	100023415-0001	R-pin, R5	2
48	100020954-0001	Handle Assembly	1
49	100011570-0001	Big Flange Bolt M6 x 12	1
50	100018662-0001	Generator End Cover	1
51	100011250-0002	Flange Bolt M5 x 14	2
52	100020167	Support, End Cover	1
53	100011252-0001	Flange Bolt M5 x 18	7
54	100000563	Cable Ties, L=85 mm	1
55	100018611	AVR	1
56	100018595	Carbon Brush Assembly	1
57	100018701	Terminal Block	1
58	100011261-0004	Flange Bolt M6 x 12	3
59	100010885-0004	Spring Washer Ø5	3
60	100010919-0002	Flat Washer Ø5	1
61	100011304-0002	Flange Bolt M6 x 194	4
62	100018572	End Housing	1
63	100011456-0003	Flange Nut M10 x 1.25	4
64	100068992	Vibration Mount, Support 1	2
65	100031984	Vibration Mount, Support 2	2
66	100011381-0002	Flange Bolt M10 x 1.25 x 40	4
67	100033045-0001	Flange Bolt M10 x 1.25 x 280	1
68	100010888-0002	Spring Washer Ø10	1
69	100010905-0001	Washer Ø10	1
70	100031927-0001	Flange Bolt M5 x 225	2
71	100011419-0001	Flange Nut M5	2
72	100091342	Alternator Assembly, Al, Ø204 x 155 mm	1

#	Part Number	Description	Qty.
73	100091343-0001	Stator Cover,	1
/3	100091343-0001	147.5 mm	<u> </u>
74	100091341	Stator Assembly, Al,	1
	100031341	Ø204 x 155 mm	<u> </u>
75	100091340	Rotor Assembly, Al,	1
		Ø119 x 155 mm	<u> </u>
76	100007025	Cooling Fan	1
77	100000657	Cable Clamp	1
78	1ZC7DF0A7	Engine, 420 cc	1
79	100021039	Holder, Air Cleaner	1
80	100018704	Rubber Plug	1
81	100000658	Clamp 2	2
82	100005148	Calmp 1, Ø8	2
83	100006138	Connection Tube	1
03	100000130	Assembly 1	<u> </u>
84	100087746	Connection Tube	1
85	100008945	Carbon Canister,	1
	100000340	650 cc	'
86	100008675-0001	Holder,	1
		Carbon Canister	
87	100011553-0001	Flange Bolt M8 x 32	2
88	100010887-0004	Spring Washer Ø8	2
89	100006938	Gasket, Exhaust Pipe	1
90	100006208-0001	Exhaust Muffler	1
		Assembly	
91	100011260-0004	Flange Bolt M6 x 10	11
92	100127251	Muffler Guard	1
93	100006497	Muffler	1
94	100006876	Side Plate 2,	1
<u> </u>		Muffler Cover	Ŀ
95	100006594	Spark Arrester	1
		Assembly	
96	100006999	Plate, Spark Arrester	1
97	100011247-0003	Flange Bolt M5 x 8	2
98	100120180	Breaker Cover	4

Engine Parts Diagram



Engine Parts List

2 100002337	#	Part Number	Description	Qty.
100002337 Cover(Cpe) 3 100031973 Breather Tube 1 4 100010186 Gasket, Cylinder Head Cover 5 100011463-0002 Flange Nut M6 2 100004435 Rocker Arm Assembly, Intake 7 100004508 Retainer, Rocker Arm 1 100004505 Bolt, Rocker Arm 2 10 100004480 Guide Plate, Push Rod 1 100001261-0004 Flange Bolt M6 × 12 10 100004504 Rocker Arm Assembly, Exhaust 1 100004506 Rocker Arm Assembly, Exhaust 1 100004506 Rocker Arm Assembly, Exhaust 1 100004506 Valve Spring Seat, 182F 2 100004576 Valve Collet 2 100004576 Valve Collet 2 100004575 Valve Spring Seat, 173F 1 100004575 Valve Spring Seat, 173F 1 100004576 Valve Spring Seat, 173F 1 100004576 Valve Spring Seat, 173F 1 100002470 Flange Bolt M10 × 1.25 × 87 1 100002469 Flange Bolt M10 × 1.25 × 65 1 100010389 Stud Bolt M8 × 35 2 100006940 Gasket, Exhaust Pipe 1 2 100005550 Gasket, Insulator 1 2 100005550 Gasket, Carburetor 1 100005555 Gasket, Air Filter Base, 173F 3 100004747 Air Filter Assembly 1 100005555 Casket, Air Filter Base, 173F 3 100004747 Air Filter Assembly 1 10004747 Air Filter Asse	1	100011264-0003	1	9
4 100010186 Gasket, Cylinder Head Cover 5 100011463-0002 Flange Nut M6 6 100004435 Rocker Arm Assembly, Intake 7 100004514 Shaft, Rocker Arm 8 100004508 Retainer, Rocker Arm 1 9 100004505 Bolt, Rocker Arm 2 10 100004480 Guide Plate, Push Rod 1 11 100011261-0004 Flange Bolt M6 × 12 6 12 100007115 Air Guide, Lower 1 13 100004504 Rocker Arm Assembly, Exhaust 2 14 100004504 Valve Spring Seat, 182F 2 15 100004576 Valve Collet 4 16 100004576 Valve Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 85 3	2	100002337	1 *	1
4 100010186 Cylinder Head Cover 5 100011463-0002 Flange Nut M6 6 100004435 Rocker Arm Assembly, Intake 7 100004514 Shaft, Rocker Arm 1 8 100004508 Retainer, Rocker Arm 1 9 100004505 Bolt, Rocker Arm 2 10 100004480 Guide Plate, Push Rod 1 11 10001261-0004 Flange Bolt M6 × 12 6 12 100007115 Air Guide, Lower 1 13 100004504 Rocker Arm Assembly, Exhaust 2 14 100004504 Valve Spring Seat, 182F 2 15 100004576 Valve Collet 4 16 100004574 Spring Valve 2 17 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 85 1 21 100010389 Stud Bolt M8 × 35 2	3	100031973	Breather Tube	1
6 100004435 Rocker Arm Assembly, Intake 1 7 100004514 Shaft, Rocker Arm 1 8 100004508 Retainer, Rocker Arm 1 9 100004505 Bolt, Rocker Arm 2 10 100004480 Guide Plate, Push Rod 1 11 100011261-0004 Flange Bolt M6 × 12 6 12 100007115 Air Guide, Lower 1 13 100004504 Rocker Arm Assembly, Exhaust 1 14 100004504 Rocker Arm Assembly, Exhaust 2 15 100004576 Valve Spring Seat, 182F 2 16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Stud Bolt M8 × 35 2 21 100010389 Stud Bolt M8 × 35 2 22 100006940 G	4	100010186	1	1
6 100004514 Shaft, Rocker Arm 7 100004508 Retainer, Rocker Arm 9 100004505 Bolt, Rocker Arm 10 100004480 Guide Plate, Push Rod 11 100011261-0004 Flange Bolt M6 × 12 12 100007115 Air Guide, Lower 13 100004504 Rocker Arm Assembly, Exhaust 14 100004516 Valve Spring Seat, 182F 15 100004576 Valve Collet 4 16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 65 3 21 100010389 Stud Bolt M8 × 35 2 22 100006940 Gasket, Exhaust Pipe 1 23 10001373 Stud Bolt M6-8 × 110 2 24 100005550 Gasket, Insulator 1	5	100011463-0002	Flange Nut M6	2
8 100004508 Retainer, Rocker Arm 1 9 100004505 Bolt, Rocker Arm 2 10 100004480 Guide Plate, Push Rod 1 11 100001261-0004 Flange Bolt M6 × 12 6 12 100007115 Air Guide, Lower 1 13 100004504 Rocker Arm Assembly, Exhaust 1 14 100004504 Valve Spring Seat, 182F 2 15 100004576 Valve Collet 4 16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Stud Bolt M8 × 35 2 21 100010389 Stud Bolt M8 × 35 2 22 100006940 Gasket, Exhaust Pipe 1 23 10001422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe	6	100004435	1	1
9 100004505 Bolt, Rocker Arm 2 10 100004480 Guide Plate, Push Rod 1 11 100011261-0004 Flange Bolt M6 × 12 6 12 100007115 Air Guide, Lower 1 13 100004504 Rocker Arm Assembly, Exhaust 1 14 100004504 Valve Spring Seat, 182F 2 15 100004576 Valve Collet 4 16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 65 1 21 100010389 Stud Bolt M8 × 35 2 22 100006940 Gasket, Exhaust Pipe 1 23 10001422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 1 25 100002418 Cylinder Head	7	100004514	Shaft, Rocker Arm	1
10 100004480 Guide Plate, Push Rod 1 11 100011261-0004 Flange Bolt M6 × 12 1 12 100007115 Air Guide, Lower 1 13 100004504 Rocker Arm Assembly, Exhaust 2 14 100004516 Valve Spring Seat, 182F 2 15 100004576 Valve Collet 2 16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 65 3 21 100010389 Stud Bolt M8 × 35 2 22 10006940 Gasket, Exhaust Pipe 1 23 10001422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 1 25 100002418 Cylinder Head 1 26 100005550 Gasket, Insulator	8	100004508	Retainer, Rocker Arm	1
11 100011261-0004 Flange Bolt M6 × 12 6 12 100007115 Air Guide, Lower 1 13 100004504 Rocker Arm Assembly, Exhaust 1 14 100004516 Valve Spring Seat, 182F 2 15 100004576 Valve Collet 2 16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 65 3 21 100010389 Stud Bolt M8 × 35 3 22 100006940 Gasket, Exhaust Pipe 3 23 10001422-0004 Flange Nut M8 3 24 100006993 Exhaust Pipe 3 25 100002418 Cylinder Head 3 26 100010373 Stud Bolt M6-8 × 110 3 27 100005550 Gasket, Insulator	9	100004505	Bolt, Rocker Arm	2
12 100007115 Air Guide, Lower 13 100004504 Rocker Arm Assembly, Exhaust 14 100004516 Valve Spring Seat, 182F 15 100004576 Valve Collet 16 100004574 Spring Valve 17 100004602 Oil Seal, Valve 18 100004575 Valve Spring Seat, 173F 19 100002470 Flange Bolt M10 × 1.25 × 87 20 100002469 Flange Bolt M10 × 1.25 × 65 21 100010389 Stud Bolt M8 × 35 22 100006940 Gasket, Exhaust Pipe 23 100011422-0004 Flange Nut M8 24 100006993 Exhaust Pipe 25 100002418 Cylinder Head 26 100010373 Stud Bolt M6-8 × 110 27 100005550 Gasket, Insulator 28 100005910 Gasket, Carburetor 30 100005526-0001 Carburetor 31 100004747 Air Filter Assembly	10	100004480	Guide Plate, Push Rod	1
13 100004504 Rocker Arm Assembly, Exhaust 14 100004516 Valve Spring Seat, 182F 15 100004576 Valve Collet 16 100004574 Spring Valve 17 100004602 Oil Seal, Valve 18 100004575 Valve Spring Seat, 173F 19 100002470 Flange Bolt M10 × 1.25 × 87 20 100002469 Flange Bolt M10 × 1.25 × 65 21 100010389 Stud Bolt M8 × 35 22 100006940 Gasket, Exhaust Pipe 23 100011422-0004 Flange Nut M8 24 100006993 Exhaust Pipe 25 100002418 Cylinder Head 26 100010373 Stud Bolt M6-8 × 110 27 100005550 Gasket, Insulator 28 100005910 Gasket, Carburetor 30 100005526-0001 Carburetor 31 100004747 Air Filter Assembly				6
13 100004504 Exhaust 14 100004516 Valve Spring Seat, 182F 15 100004576 Valve Collet 16 100004574 Spring Valve 17 100004602 Oil Seal, Valve 20 Valve Spring Seat, 173F 19 100002470 Flange Bolt M10 × 1.25 × 87 20 100002469 Flange Bolt M10 × 1.25 × 65 21 100010389 Stud Bolt M8 × 35 22 100006940 Gasket, Exhaust Pipe 23 100011422-0004 Flange Nut M8 24 100006993 Exhaust Pipe 25 100002418 Cylinder Head 26 100010373 Stud Bolt M6-8 × 110 27 100005550 Gasket, Insulator 28 100005988 Insulator, Carburetor 29 100005910 Gasket, Air Filter Base, 173F 31 100005955 Gasket, Air Filter Assembly	12	100007115	Air Guide, Lower	1
14 100004576 182F 2 15 100004576 Valve Collet 2 16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 x 1.25 x 87 3 20 100002469 Flange Bolt M10 x 1.25 x 65 3 21 100010389 Stud Bolt M8 x 35 2 22 100006940 Gasket, Exhaust Pipe 3 23 100011422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 3 25 100002418 Cylinder Head 3 26 100010373 Stud Bolt M6-8 x 110 2 27 100005550 Gasket, Insulator 3 28 100005588 Insulator, Carburetor 3 29 100005910 Gasket, Air Filter Base, 173F 3 31 100005955 Gasket, Air Filter Assembly	13	100004504	•	1
16 100004574 Spring Valve 2 17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 65 3 21 100010389 Stud Bolt M8 × 35 2 22 100006940 Gasket, Exhaust Pipe 3 23 100011422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 3 25 100002418 Cylinder Head 3 26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 3 28 100005910 Gasket, Carburetor 3 30 100005956 Gasket, Air Filter Base, 173F 31 100004747 Air Filter Assembly 3	14	100004516	1	2
17 100004602 Oil Seal, Valve 2 18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 65 3 21 100010389 Stud Bolt M8 × 35 3 22 100006940 Gasket, Exhaust Pipe 1 23 100011422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 1 25 100002418 Cylinder Head 1 26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 1 28 100005910 Gasket, Carburetor 1 30 100005926-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	15	100004576	Valve Collet	4
18 100004575 Valve Spring Seat, 173F 2 19 100002470 Flange Bolt M10 × 1.25 × 87 3 20 100002469 Flange Bolt M10 × 1.25 × 65 3 21 100010389 Stud Bolt M8 × 35 3 22 100006940 Gasket, Exhaust Pipe 3 23 100011422-0004 Flange Nut M8 3 24 100006993 Exhaust Pipe 3 25 100002418 Cylinder Head 3 26 100010373 Stud Bolt M6-8 × 110 3 27 100005550 Gasket, Insulator 3 28 100005588 Insulator, Carburetor 3 29 100005910 Gasket, Carburetor 3 30 100005956 Gasket, Air Filter Base, 173F 31 100004747 Air Filter Assembly	16	100004574	Spring Valve	2
18 100004575 173F 19 100002470 Flange Bolt M10 x 1.25 x 87 20 100002469 Flange Bolt M10 x 1.25 x 65 21 100010389 Stud Bolt M8 x 35 22 100006940 Gasket, Exhaust Pipe 23 100011422-0004 Flange Nut M8 24 100006993 Exhaust Pipe 25 100002418 Cylinder Head 26 100010373 Stud Bolt M6-8 x 110 27 100005550 Gasket, Insulator 28 100005588 Insulator, Carburetor 30 100005910 Gasket, Carburetor 30 100005955 Gasket, Air Filter Base, 173F 31 100004747 Air Filter Assembly	17	100004602	Oil Seal, Valve	2
M10 × 1.25 × 87 Sample M10 × 1.25 × 87 M10 × 1.25 × 65 M10 × 35 M	18	100004575		2
20 100002469 M10 × 1.25 × 65 21 100010389 Stud Bolt M8 × 35 2 22 100006940 Gasket, Exhaust Pipe 1 23 100011422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 1 25 100002418 Cylinder Head 1 26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 1 28 100005588 Insulator, Carburetor 1 29 100005910 Gasket, Carburetor 1 30 100005926-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	19	100002470		3
22 100006940 Gasket, Exhaust Pipe 1 23 100011422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 1 25 100002418 Cylinder Head 1 26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 1 28 100005988 Insulator, Carburetor 1 30 100005910 Gasket, Carburetor 1 30 100005956-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	20	100002469		1
23 100011422-0004 Flange Nut M8 2 24 100006993 Exhaust Pipe 1 25 100002418 Cylinder Head 1 26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 1 28 100005588 Insulator, Carburetor 1 29 100005910 Gasket, Carburetor 1 30 100005956-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	21	100010389	Stud Bolt M8 × 35	2
24 100006993 Exhaust Pipe 1 25 100002418 Cylinder Head 1 26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 1 28 100005588 Insulator, Carburetor 1 29 100005910 Gasket, Carburetor 1 30 100005526-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	22	100006940	Gasket, Exhaust Pipe	1
25 100002418 Cylinder Head 1 26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 1 28 100005588 Insulator, Carburetor 1 29 100005910 Gasket, Carburetor 1 30 100005526-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	23	100011422-0004	Flange Nut M8	2
26 100010373 Stud Bolt M6-8 × 110 2 27 100005550 Gasket, Insulator 1 28 100005588 Insulator, Carburetor 1 29 100005910 Gasket, Carburetor 1 30 100005526-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	24	100006993	Exhaust Pipe	1
27 100005550 Gasket, Insulator 1 28 100005588 Insulator, Carburetor 1 29 100005910 Gasket, Carburetor 1 30 100005526-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	25		+	1
28 100005588 Insulator, Carburetor 1 29 100005910 Gasket, Carburetor 1 30 100005526-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	_			2
29 100005910 Gasket, Carburetor 1 30 100005526-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1	\vdash		}	1
30 100005526-0001 Carburetor 1 31 100005955 Gasket, Air Filter Base, 173F 1 32 100004747 Air Filter Assembly 1			<u> </u>	1
31 100005955 Gasket, Air Filter Base, 173F 32 100004747 Air Filter Assembly	\vdash		 	1
31 100005955 173F 32 100004747 Air Filter Assembly 1	30	100005526-0001		1
	31	100005955		1
33 100005024 Air Filter Base 1	32	100004747	Air Filter Assembly	1
	33		Air Filter Base	1
		100004878		1
35 100004895 Air Filter Clip 2	35	100004895	Air Filter Clip	2


#	Part Number	Description	Qty.
36	100004798	Gasket, Air Filter	
30	100004798	Cover, 173F-2	1
37	100004781	Air Filter Element	1
38	100004874	Air Filter Cover	1
39	100011452-0003	Lock Nut M6, Flange	2
40	100009378	Spark Plug(F6RTC)	1
41	100010228	Gasket, Cylinder Head	1
42	100010562	Dowel Pin Ø12 × 20	2
43	100004413	Push Rod	2
44	100004559	Valve Exhaust	1
45	100004539	Valve Intake	1
46	100004268	Lifter, Valve	2
47	100003264	Piston Ring Set	1
48	100003167	1st Piston Ring	1
49	100003209	2nd Piston Ring	1
50	100003294	Oil Ring	1
51	100003225	Circlip	2
52	100003100	Piston	1
53	100003131	Wrist Pin	1
54	100003458	Connecting Rod	1
55	100003432	Bolt, Connecting Rod	2
56	100011217-0002	Flange Bolt M6 × 16	2
57	100010037	Oil Level Sensor	1
58	100007116	Shroud 2	1
59	100003952	Crankshaft	1
60	100004319	Camshaft	1
61	100010521-0001	Washer Ø16.2 × Ø24 × 0.3	1
62	100010497	Washer $\emptyset 35 \times \emptyset 42 \times 0.3$	1
63	100010789	Bearing TM6207E - P64	1
64	100010162	Gasket, Crankcase Cover	1
65	100010553	Dowel Pin Ø9 × 12	1
66	100003042	Cover, Crankcase	1
67	100011324-0001	Flange Bolt M8 × 38	7
68	100017653	Oil Seal Ø35 × Ø52 × 7, Spiral Grain	1
69	100011329-0001	Flange Bolt M8 × 45	1
70	100032064-0001	Oil Dipstick Assembly	1
71	100010544	Dowel Pin Ø7 × 14	1
72	100008305	Gear, Governor	1
73	100010742	Bearing TM6202 / P63	2

SPECIFICATIONS

#	Part Number	Description	Qty.
74	100003999	Balance Shaft	1
75	100009851	Flange Bolt	2
76	100009696	Electric Starter	1
77	100002445	Cylinder Head Shield	1
78	100007817	Spring, Governor	1
79	100007910	Spring, Throttle Return	1
80	100007936	Rod, Governor	1
81	100008400	Arm, Governor	1
82	100011309-0002	Flange Bolt M8 × 14	2
83	100008060	Control Assembly	1
84	100007989	Pin, Shaft	1
85	100017631	Oil Seal Ø8 × Ø14 × 4	1
86	100010518-0001	Washer $\emptyset 8 \times \emptyset 20 \times 0.8$	1
87	100007980	Shaft, Governor Arm	1
88	100002782	Crankcase	1
89	100017834	Pipe, Fuel, $\emptyset 4 \times \emptyset 10 \times 175$	1
90	100005138	Clamp Ø9.5 × 8	1
91	100010467	Washer Ø12 × Ø20 × 2	2
92	100010275	Drain Bolt, M12 \times 1.5 \times 15	2
93	100017649	0il Seal Ø35 × Ø52 × 7	1
94	100007117	Shroud 3	1
95	100009346	Ignition Module	1
96	100009362	Bolt M6 × 28, Ignition	2
97	100004222	Bush Ø8 × Ø12 × 6	1
98	100009405	Charge Coil	1
99	100011270-0002	Flange Bolt M6 × 30	2
100	100009463	Pressing Plate	1
101	100011213-0001	Flange Bolt M6 × 8	1
102	100009572	Flywheel	1
103	100007043	Cooling Fan	1
104	100007562	Pulley, Starter	1
105	100011460-0001	Flange Nut M16 × 1.5	1
106	100007347-0003	Recoil Starter Assembly	1
107	100007583-0003	Fan Cover	1
108	100007410-0004	Recoil Starter	1
109	100010894-0001	Washer Ø6	3
110	100011528-0004	Flange Bolt M6 × 10	3
111	100000667	Clamp Ø8 × 8	1
112	100000655	Wire Clip B	1
113	100127018	Cylinder Head Assembly	1

#	Part Number	Description	Qty.
114	100085766	Fuel Bowl O-Ring	1
	100089153	Main Jet Standard	1
115	100155681	Main Jet Altitude 1000-2000m	/
	100062835	Main Jet Altitude 2000-3000m	/
116	100134226	0-Ring, Solenoid Valve Base	1
117	100134227	0-Ring, Solenoid Valve	1

Wiring Diagram



TROUBLESHOOTING

Problem	Cause	Solution
	No fuel.	Add fuel.
Generator will not start.	Faulty spark plug.	Replace spark plug.
	Unit loaded during start up.	Remove load from unit.
	Low oil level.	Fill crankcase to the proper level.
Generator will not start;	Low on level.	Place generator on a flat, level surface.
Generator starts but runs roughly.	Choke in the wrong position.	Adjust choke.
	Spark plug wire loose.	Attach wire to spark plug.
Congretor will not start electrically	Generator battery is dead.	Recharge generator battery.
Generator will not start electrically.	Battery switch is in the OFF position.	Turn battery switch to ON position.
	Out of fuel.	Fill fuel tank.
Generator shuts down during operation.	Low oil level.	Fill crankcase to the proper level. Place
	Low on level.	generator on a flat, level surface.
	Generator is overloaded.	Review load and adjust. See "Connecting
Generator cannot supply enough power		Electrical Loads."
or overheating.	Insufficient ventilation.	Check for air restriction. Move to a well
		ventilated area.
	Cable not properly connected.	Check all connections.
	Connected device is defective.	Replace defective device.
	Circuit breaker is open.	Reset circuit breaker
No AC output.	Faulty brush assembly.	Replace brush assembly (Service Center).
	Faulty AVR (auto voltage regulator).	Replace AVR (Service Center).
	Loose wiring.	Inspect and tighten wiring connections.
	Other.	Contact the help line.
Generator gallops.	Engine governor defective.	Contact the help line.
Panastad circuit breaker tripping	Overload.	Review load and adjust. See "Connecting Electrical Loads."
Repeated circuit breaker tripping.	Faulty cords or device.	Check for damaged, bare or frayed wires. Replace defective device.

For further technical support:

Technical Support Team
Mon-Fri 8:30 AM-5:00 PM (PST/PDT)
Toll Free 1-877-338-0999
support@championpowerequipment.com

WARRANTY*

CHAMPION POWER EQUIPMENT 3 YEAR LIMITED WARRANTY

Warranty Qualifications

To register your product for warranty and FREE lifetime call center technical support please visit:

https://www.championpowerequipment.com/register

To complete registration you will need to include a copy of the purchase receipt as proof of original purchase. Proof of purchase is required for warranty service. Please register within ten (10) days from date of purchase.

Repair/Replacement Warranty

CPE warrants to the original purchaser that the mechanical and electrical components will be free of defects in material and workmanship for a period of three years (parts and labor) from the original date of purchase and 270 days (parts and labor) for commercial and industrial use. Transportation charges on product submitted for repair or replacement under this warranty are the sole responsibility of the purchaser. This warranty only applies to the original purchaser and is not transferable.

Do Not Return The Unit To The Place Of Purchase

Contact CPE's Technical Service and CPE will troubleshoot any issue via phone or e-mail. If the problem is not corrected by this method, CPE will, at its option, authorize evaluation, repair or replacement of the defective part or component at a CPE Service Center. CPE will provide you with a case number for warranty service. Please keep it for future reference. Repairs or replacements without prior authorization, or at an unauthorized repair facility, will not be covered by this warranty.

Warranty Exclusions

This warranty does not cover the following repairs and equipment:

Normal Wear

Products with mechanical and electrical components need periodic parts and service to perform well. This warranty does not cover repair when normal use has exhausted the life of a part or the equipment as a whole.

Installation. Use and Maintenance

This warranty will not apply to parts and/or labor if the product is deemed to have been misused, neglected, involved in an accident, abused, loaded beyond the product's limits, modified, installed improperly or connected incorrectly to any electrical component. Normal maintenance is not covered by this warranty and is not required to be performed at a facility or by a person authorized by CPE.

Other Exclusions

This warranty excludes:

- Cosmetic defects such as paint, decals, etc.
- Wear items such as filter elements, o-rings, etc.
- Accessory parts such as starting batteries, and storage covers.
- Failures due to acts of God and other force majeure events beyond the manufacturer's control.
- Problems caused by parts that are not original Champion Power Equipment parts.

When applicable, this warranty does not apply to products used for prime power in place of a utility.

Limits of Implied Warranty and Consequential Damage

Champion Power Equipment disclaims any obligation to cover any loss of time, use of this product, freight, or any incidental or consequential claim by anyone from using this product. THIS WARRANTY AND THE ATTACHED U.S. EPA and/or CARB EMISSION CONTROL SYSTEM WARRANTIES (WHEN APPLICABLE) ARE IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

A unit provided as an exchange will be subject to the warranty of the original unit. The length of the warranty governing the exchanged unit will remain calculated by reference to the purchase date of the original unit.

This warranty gives you certain legal rights which may change from state to state or province to province. Your state or province may also have other rights you may be entitled to that are not listed within this warranty.

Contact Information

Address

Champion Power Equipment, Inc. 12039 Smith Ave. Santa Fe Springs, CA 90670 USA www.championpowerequipment.com

Customer Service

Toll Free: 1-877-338-0999

info@championpowerequipment.com

Fax no.: 1-562-236-9429

Technical Service

Toll Free: 1-877-338-0999

tech@championpowerequipment.com 24/7 Tech Support: 1-562-204-1188

^{*}Except as otherwise stipulated in any of the following enclosed Emission Control System Warranties (when applicable) for the Emission Control System: U.S. Environment Protection Agency (EPA) and/or California Air Resources Board (CARB).

CHAMPION POWER EQUIPMENT, INC. (CPE), THE UNITED STATES ENVIRONMENTAL PROTECTION AGENCY (U.S. EPA) AND THE CALIFORNIA AIR RESOURCES BOARD (CARB) EMISSION CONTROL SYSTEM WARRANTY

Your Champion Power Equipment (CPE) engine complies with both the U.S. EPA and state of California Air Resources Board (CARB) Exhaust and Evaporative emissions regulations.

YOUR WARRANTY RIGHTS AND OBLIGATIONS:

The US EPA, California Air Resources Board, and CPE are pleased to explain the Federal and California Exhaust and Evaporative Emission Control Systems Warranty on your 2020 small off-road engine (SORE) and engine powered equipment. In California, new equipment that use small off-road engines (SORE) must be designed, built and equipped to meet the State's stringent anti-smog standards.

CPE must warrant the exhaust and evaporative emission control system on your small off-road engine (SORE) for the period listed below, provided there has been no abuse, neglect, unapproved modification, or improper maintenance of your equipment leading to the failure of the exhaust and evaporative emission control systems.

Your evaporative emission control system may include parts such as: carburetors, fuel tanks, fuel lines, (for liquid fuel and fuel vapors), fuel caps, valves, canisters, filters, clamps, connectors, and other associated components. Also included for your exhaust emission control system may be the fuel-injection system, the ignition system, catalytic converter and other exhaust emission related assemblies. Where a warrantable condition exits, CPE will repair your small off-road engine (SORE) at no cost to you including diagnosis, parts and labor.

MANUFACTURER'S WARRANTY COVERAGE:

This exhaust and evaporative emission control system is warranted for two years. If any exhaust and evaporative, emission related part on your engine or equipment is defective in, the part will be repaired or replaced by CPE.

OWNER WARRANTY RESPONSIBILITIES:

As the small off-road engine (SORE) owner, you are responsible for the performance of the required maintenance listed in your Owner's Manual. CPE recommends that you retain all your receipts covering maintenance on your small off-road engine (SORE), but CPE cannot deny warranty coverage solely for the lack of receipts.

As the small off-road engine (SORE) owner, you should be aware that CPE may deny you warranty coverage if your small off-road engine (SORE) or a part has failed due to abuse, neglect, improper maintenance or unapproved modifications.

You are responsible for presenting your small off-road engine to an Authorized CPE distribution center, service center or alternate service outlet as described in (3)(f) below or CPE dealer or CPE, Santa Fe Springs, Ca. as soon as the problem exists. The warranty repairs shall be completed in a reasonable amount of time, not to exceed 30 days.

If you have any questions regarding your warranty coverage, you should contact:

Champion Power Equipment, Inc.
Customer Service
12039 Smith Ave.
Santa Fe Springs, CA 90670
1-877-338-0999
tech@championpowerequipment.com

EXHAUST AND EVAPORATIVE EMISSION CONTROL SYSTEM WARRANTY

The following are specific provisions relative to your Exhaust and Evaporative Emission Control System (ECS) Warranty Coverage.

 APPLICABILITY: This warranty shall apply to 1995 and later model year California small off-road engines (SORE) (for other states, 1997 and later model year engines). The ECS Warranty Period shall begin on the date the new engine or equipment is delivered to its original, end-use purchaser, and shall continue for 24 consecutive months thereafter.

2. GENERAL EMISSIONS WARRANTY COVERAGE

CPE warrants to the original, end-use purchaser of the new engine or equipment and to each subsequent purchaser that each of its small off-road engines (SORE) is:

- 2a. Designed, built and equipped to conform to U.S. EPA emissions standards for spark-ignited engines at or below 19 kilowatts and all applicable regulations adopted by the California Air Resources Board and
- 2b. Free from defects in materials and workmanship that cause the failure of a warranted part to be identical in all material respects to the part as described in the engine manufacturer's application for certification for a period of two years.

3. THE WARRANTY ON EXHAUST AND EVAPORATIVE EMISSION-RELATED PARTS WILL BE INTERPRETED AS FOLLOWS:

- 3a. Any warranted part that is not scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the ECS Warranty Period. If any such part fails during the ECS Warranty Period, it shall be repaired or replaced by CPE according to Subsection "d" below. Any such part repaired or replaced under the ECS Warranty shall be warranted for any remainder of the ECS Warranty Period.
- 3b. Any warranted, exhaust and evaporative emissions-related part which is scheduled only for regular inspection as specified in the Owner's Manual shall be warranted for the ECS Warranty Period. A statement in such written instructions to the effect of "repair or replace as necessary", shall not reduce the ECS Warranty Period. Any such part repaired or replaced under the ECS Warranty shall be warranted for the remainder of the ECS Warranty Period.
- 3c. Any warranted, exhaust and evaporative emissions-related part which is scheduled for replacement as required maintenance in the Owner's Manual shall be warranted for the period of time prior to the first scheduled replacement point for that part. If the part fails prior to the first scheduled replacement, the part shall be repaired or replaced by CPE according to Subsection "d" below. Any such exhaust and evaporative emissions-related part repaired or replaced under the ECS Warranty, shall be warranted for the remainder of the ECS Warranty Period prior to the first scheduled replacement point for such emissions-related part.
- 3d. Repair or replacement of any warranted, exhaust and evaporative emissions-related part under this ECS Warranty shall be performed at no charge to the owner at a CPE Authorized Service Outlet.
- 3e. The owner shall not be charged for diagnostic labor which leads to the determination that a part covered by the ECS Warranty is in fact defective, provided that such diagnostic work is performed at a CPE Authorized Service Outlet.
- 3f. CPE shall pay for covered exhaust and evaporative emissions warranty repairs at non-authorized service outlets under the following circumstances:
 - i. The service is required in a population center with a population over 100,000 according to U.S. Census 2000 without a CPE Authorized Service Outlet AND
 - ii. The service is required more than 100 miles from a CPE Authorized Service Outlet. The 100 mile limitation does not apply in the following states: Alaska, Arizona, Colorado, Hawaii, Idaho, Montana, Nebraska, Nevada, New Mexico, Oregon, Texas, Utah and Wyoming.
- 3g. CPE shall be liable for damages to other original engine components or approved modifications proximately caused by a failure under warranty of an emission-related part covered by the ECS Warranty.
- 3h. Throughout the ECS Warranty Period, CPE shall maintain a supply of warranted exhaust and evaporative emission-related parts sufficient to meet the expected demand for such exhaust and evaporative emission-related parts.
- 3i. Any CPE Authorized and approved exhaust and evaporative emission-related replacement part may be used in the performance of any ECS Warranty maintenance or repair and will be provided without charge to the owner. Such use shall not reduce CPE's warranty obligation.
- 3j. Unapproved add-on or modified parts may not be used to modify or repair a CPE engine. Such use voids this ECS Warranty and shall be sufficient grounds for disallowing an ECS Warranty claim. CPE shall not be liable hereunder for failures of any warranted parts of a CPE engine caused by the use of such an unapproved add-on or modified part.

EMISSION-RELATED PARTS INCLUDE THE FOLLOWING: (using those portions of the list applicable to the engine)

Systems covered by this warranty	Parts Description
Fuel Metering System	Carburetor and internal parts (and/or pressure regulator or fuel injection system), Air/fuel ratio feedback and control system, Cold start enrichment system.
Air Induction System	Controlled hot air intake system, Intake manifold, Air filter.
Ignition System	Spark plug, Magneto or electronic ignition system, Spark advance/retard system.
Exhaust Gas Recirculation (EGR) System	EGR valve body, and carburetor spacer if applicable, EGR rate feedback and control system.
Air Injection System	Air pump or pulse valve, Valves affecting distribution of flow, Distribution manifold.
Catalyst or Thermal Reactor System	Catalytic Converter, Thermal Reactor, Exhaust Manifold.
Particulate Controls	Traps, Filters, Precipitators, and any other device used to capture particulate emissions.
Miscellaneous items used in Above Systems	Vacuum, Temperature, and time sensitive valves and switches, Electronic Controls, Hoses, Belts, Connectors, and Assemblies.
Evaporative Controls	Fuel Tank, Fuel Cap, Fuel Lines (for liquid fuel and fuel vapors), Fuel Line Fittings, Clamps, Pressure Relief Valves, Control Valves, Control Solenoids, Electronic Controls, Vacuum Control Diaphragms, Control Cables, Control Linkages, Purge Valves, Gaskets, Liquid/Vapor Separator, Carbon Canister, Canister Mounting Brackets, Carburetor Purge Port Connector.

TO OBTAIN WARRANTY SERVICE:

You must take your CPE engine or the product on which it is installed, along with your warranty registration card or other proof of original purchase date, at your expense, to any Champion Power Equipment dealer who is authorized by Champion Power Equipment, Inc. to sell and service that CPE product during his normal business hours. Alternate service locations defined in Section (3)(f) above must be approved by CPE prior to service. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you have any questions regarding your warranty rights and responsibilities, or to obtain warranty service, please write or call Customer Service at Champion Power Equipment, Inc.

Champion Power Equipment, Inc.

12039 Smith Ave. Santa Fe Springs, CA 90670 1-877-338-0999

Attn.: Customer Service tech@championpowerequipment.com