


HOW TO USE THE CONTROL PANEL



A) TEMPERATURE INCREASE BUTTON:
Press to increase the temperature setting by 5-degree increments.

B) TEMPERATURE DECREASE BUTTON:
Press to decrease the temperature setting by 5-degree increments.

C) POWER/START BUTTON:
Tap this button once to START or CANCEL cooking.

D) TIMER INCREASE BUTTON:
Each press increases cooking time by one minute.

E) TIMER DECREASE BUTTON:
Each press decreases cooking time by one minute.

F) MENU FUNCTION BUTTON:
Use this button to toggle through the different menu functions.

PREPARING YOUR AIR FRYER FOR USE

1. Before using your *Digital Air Fryer* for the first time, carefully remove all packaging materials and recycle appropriately.
2. Remove the parts from the box and wash the Drawer Pan (2) and Basket (1) with warm, soapy water and a non-abrasive sponge.
IMPORTANT: DO NOT IMMERSE THE MAIN HOUSING IN WATER. Wipe the interior and exterior of appliance clean with a damp cloth.
IMPORTANT: THIS IS NOT A DEEP FRYER. DO NOT FILL THE APPLIANCE OR ITS DRAWER (2) WITH OIL OR FRYING FAT.
3. Place the appliance on a flat, horizontal and stable surface (make sure surface is heat-resistant). Place away from walls and other appliances. Leave approximately 4 inches of space from nearby objects (see Figure 1).
4. Pull the Drawer Pan (2) out by the Handle (5). Push the Protective Cover (3) and press down on the Basket Release Button (4) to lift out the Basket (1) (see Figure 2).
TIP: Never place food directly into the Drawer Pan (2).




FIGURE 1




FIGURE 2

HOW TO USE YOUR AIR FRYER

1. Carefully pull out the Drawer Pan (2) from the Main Fryer Base by pulling forward on the basket handle (3).
2. Remove the Basket (1) from the Drawer Pan (2), push the Protective Cover (3), and press down on the Basket Release Button (9) and lift up on the basket. (see Figure 3).
3. Place ingredients into Basket (1).
TIP: - Do not fill the Basket (1) over the MAX fill position. - If cooking food that expands, make sure the cooked capacity will not exceed the MAX fill position.
4. Insert Basket (1) back into the Drawer Pan (2) by inserting into the basket slot. (see Figure 4).
5. Slide Drawer Pan (2) back into the Main Fryer Base (see Figure 5). Once in place, the Air Fryer will beep to let you know it is in position.




FIGURE 3




FIGURE 4




FIGURE 5

HOW TO USE YOUR AIR FRYER (CONT.)

HOW TO MANUALLY PROGRAM FRYING TIME AND TEMPERATURE:

1. Plug Power Cord (15) into an electrical outlet.
2. Gently tap the **POWER** button, you will hear a beep and the LED screen will illuminate. The Digital Display will default to 360° F and 15-minute setting.

***TIP:** It is recommended to preheat the air fryer on empty at 360° F for 3 min. if the appliance is cold. The initial 15 minutes of use may result in minimal smell and smoke. This is normal and harmless and comes from the protective substance applied to the heating elements during manufacturing.*

3. Press the +/- button for the Temperature setting to adjust to the desired temperature. Temperature will increase or decrease in 5-degree increments.
4. Press the +/- button for the Timer setting to adjust to the desired cooking time. Timer will increase or decrease in 1-minute increments.
5. Tap the **START** Button once to begin cooking.

HOW TO SELECT A QUICK MENU FUNCTION:

QUICK MENU CHART

	MENU	DEFAULT TEMPERATURE	DEFAULT COOK TIME
----	DEFAULT	360°F	15 min
	FRIES	395°F	25 min
	CHEESE	360°F	10 min
	SEAFOOD	395°F	10 min
	BAKE	320°F	20 min
	CHICKEN	400°F	25 min
	STEAK	360°F	12 min
	VEG	320°F	10 min

1. Plug Power Cord (15) into an electrical outlet.
2. Gently tap the **POWER** button, you will hear a beep and the LED screen will illuminate. The Digital Display will default to 360° F and 15-minute setting.

***TIP:** It is recommended to preheat the air fryer on empty at 360° F for 3 min. if the appliance is cold. The initial 15 minutes of use may result in minimal smell and smoke. This is normal and harmless and comes from the protective substance applied to the heating elements during manufacturing.*

HOW TO USE YOUR AIR FRYER (CONT.)

3. Press the (M) button to cycle through the different Menu functions. Default Menu Temperatures and Times will appear.
4. To select desired Menu function, tap the **START** Button to begin cooking.
5. Use the +/- buttons to adjust Menu function temperatures or times if you wish to change the programmed settings.
Note: *The initial 15 minutes of use may result in minimal smell and smoke. This is normal and harmless and comes from the protective substance applied to the heating elements during manufacturing.*

CANCELING A SELECTION:

1. To Cancel any programmed selection, simply tap the **POWER** button to cancel the selection.
2. To change a selection, simply press the M button to cycle through the other Menu functions.
NOTE: *There is no need to press POWER button again when changing a setting during the cooking process.*

DURING THE COOKING/FRYING PROCESS:

1. Once you tap the **START** Button, the Timer will begin counting down and begin the cooking process.
NOTE: *Any excess oil from food will collect at the bottom of the Pan (2).*
2. Some recipes require stirring/mixing/flipping the contents mid-way through cooking (see Cooking Time Chart on page 10). You can do this in the middle of the cooking process by simply pulling out the basket by grasping the Handle (5) and pull forward the entire Drawer Pan (2). The built-in auto sensors will automatically pause the heating system to allow you to attend to the food.
3. Shake, stir or flip the contents of the basket using a non-metallic utensil and then slide Drawer Pan (2) back into the Main Fryer Base.
CAUTION: *During cooking, the Drawer Pan (2) and Basket (1) will be very hot, only use the cool-touch handles or oven mitts.*

WHEN COOKING/FRYING IS COMPLETE:

1. When the timer completes its countdown, the air fryer will beep and stop heating - this signals it is time to remove your food. (Please note that the fan motor will continue to operate in order to cool down the Drawer Pan (2) and the Basket (1), this will stop within approximately 30 seconds).
NOTE: *You can also switch off the appliance manually by pressing POWER at any time during the cooking process.*
2. Carefully pull out the Drawer Pan (2) from the Main Fryer Base by pulling forward on the basket handle (5).
3. Remove the Basket (5) from the Drawer Pan (2) by pressing down on the Basket Release Button (4) and lifting up on the basket.
CAUTION: *When sliding out the Drawer Pan (2), be careful of hot air and steam. Keep hands and face away from the opening.*
CAUTION: *After cooking, the Drawer Pan (2) and Basket (1) will be extremely hot to the touch. Do not touch surfaces of the Drawer Pan (2) or Basket (1) directly.*
4. Check that your foods are ready. If not, then place the Basket (1) back into the Drawer Pan (2) and set the timer for a few more minutes.

HOW TO USE YOUR AIR FRYER (CONT.)

5. Empty the contents of the Basket (1) into a bowl or onto a plate. If necessary, you can also use Tongs to remove foods from the Basket (1).
TIP: If food contents within Basket (1) are too heavy to lift using the Basket Handle (5), use oven mitts to carefully pull out the whole Drawer Pan (2) and Basket (1) together. Place on a flat, heat-resistant surface and use Tongs to remove contents from the Basket (1).
TIP: Do not turn the Basket (1) and Drawer Pan (2) upside down together, as any excess oil that has collected in the bottom of the Drawer Pan (2) will be poured onto the foods.
6. When the next batch of ingredients is ready, the air fryer is instantly ready to use again.
7. When cooking is complete, the display will show "OFF." Remove the Power cord (15) from the electrical outlet.

CLEANING & MAINTENANCE

The **Digital Air Fryer** should be cleaned thoroughly after every use.

1. Make sure the Power cord (15) is disconnected from the electrical outlet and that the appliance has cooled down before attempting to clean.
2. The Drawer Pan (2), Basket (1) and the inside of the appliance have a nonstick coating. Do not use metal utensils or abrasive cleaning materials on them, as this can damage the non-stick coating.
3. Wipe the outside of the appliance with a damp cloth.
CAUTION: Do not allow water to seep into the LED control panel as that may damage the appliance.
4. Clean the Drawer Pan (2) and Basket (1) with hot water, dishwashing soap and a non-abrasive sponge.
5. You can use a degreaser to remove any stuck-on residue.
NOTE: The Drawer Pan (2) and Basket (1) are dishwasher-safe (top rack only).
TIP: If food residue is stuck to the Basket (1) or the bottom of the Drawer Pan (2), place the Basket (1) into the Drawer Pan (2) and fill with dishwashing soap and water and let soak for 10 minutes.
6. Clean the inside of the appliance with hot water and a non-abrasive sponge.
7. Never immerse the power cord, plug or the appliance body in water or any other liquids.
8. Dry all parts after each use, re-assemble and store in a cool, dry location.