



1.1 CUBIC FOOT 1000-WATT DIGITAL MICROWAVE OVEN

INSTRUCTION MANUAL
MODEL # BMO11ABTPLC



Read these instructions carefully before using your microwave oven and maintain its upkeep. If you follow the instructions, your oven will provide you with many years of good service.

KEEP THESE INSTRUCTIONS IN A SAFE PLACE



Table of Contents

Precautions.....	4
Specifications.....	4
Safety Instructions	5
Grounding	6
Radio Interference	6
Usage Safety.....	7
Utensils.....	7
Materials Use Guide.....	8
Setting Up Your Oven	9 to 10
Control Panel.....	11
Operation.....	12 to 15
Maintenance.....	16
Warranty Information.....	17

PRECAUTIONS

TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY

- (a) Do not attempt to operate this oven with the door open since open-door operation can result in harmful exposure to microwave energy.
It is important not to tamper with the safety interlocks.
- (b) Do not place any object between the front face of the oven and the door. Do not allow cleaner or food residue to accumulate on sealing surfaces of the microwave.
- (c) Do not operate the oven if it is damaged. It is particularly important that the oven door close properly and that there is no damage to the:
 - (1) DOOR – do not use the microwave if the door is at all bent or won't fully close.
 - (2) HINGES AND LATCHES – do not use if the hinges or latches are broken or loosened.
 - (3) DOOR SEALS AND SEALING SURFACES – do not use if the door seals or sealing surfaces are damaged.
- (d) The oven should not be adjusted or repaired by anyone except properly qualified service personnel.

SPECIFICATIONS

Model:	BMO11ABTPLC
Rated Voltage:	120V~60Hz
Rated Input Power (Microwave):	1500W
Rated Output Power (Microwave):	1000W
Oven Capacity:	1.1 cubic feet
Turntable Diameter	12.4 inches
External Dimensions:	22.8 (W) x 18.11 (D) x 14.25 (H) inches
Net Weight:	Approx 35.78 lbs

SAVE THESE INSTRUCTIONS

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances basic safety precautions should be followed, including the following:

WARNING – To reduce the risk of burns, electric shock, fire, injury to persons or exposure:

1. Read all instructions before using the appliance.
2. Read and follow the specific: "PRECAUTIONS TO AVOID POSSIBLE EXPOSURE TO EXCESSIVE MICROWAVE ENERGY" found on page 4.
3. This appliance must be grounded. Connect only to properly grounded outlet. See "GROUNDING INSTRUCTIONS" found on page 6.
4. Install or locate this appliance only in accordance with the provided installation instructions.
5. Some products such as whole eggs and sealed containers - for example, closed glass jars - are able to explode and should not be heated in this oven.
6. Use this appliance only for its intended use as described in the manual. Do not use corrosive chemicals or vapors in this appliance. This type of oven is specifically designed to heat, cook or dry food. It is not designed for industrial or laboratory use.
7. As with any appliance, close supervision is necessary when used by children.
8. Do not operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been damaged or dropped.
9. This appliance should be serviced only by qualified service personnel. Contact nearest authorized service facility for examination, repair, or adjustment.
10. Do not cover or block any openings on the appliance.
11. Do not store this appliance outdoors. Do not use this product near water - for example, near a kitchen sink, in a wet basement, near a swimming pool, or similar location.
12. Do not immerse cord or plug in water.
13. Keep cord away from heated surface.
14. Do not let cord hang over edge of table or counter.
15. When cleaning surfaces of door and oven that comes together on closing the door, use only mild, nonabrasive soaps, or detergent applied with a sponge or soft cloth.
16. To reduce the risk of fire in the oven cavity:
 - a). Do not overcook food. Carefully monitor appliance when paper, plastic, or other combustible materials are placed inside the oven to facilitate cooking.
 - b). Remove wire twist-ties from paper or plastic bag before placing bag in oven.
 - c). If material inside of the oven ignites, keep oven door closed, turn oven off, and disconnect the power cord, or shut off power at the fuse or circuit breaker panel.
 - d). Do not use the cavity for storage purposes. Do not leave paper products, cooking utensils, or food in the cavity when not in use.

17. Liquids, such as water, coffee, or tea are able to be overheated beyond the boiling point without appearing to be boiling. Visible bubbling or boiling when the container is removed from the microwave oven is not always present. **THIS COULD RESULT IN VERY HOT LIQUID SUDDENLY BOILING OVER WHEN THE CONTAINER IS DISTURBED OR A UTENSIL IS INSERTED INTO THE LIQUID.**
18. To reduce the risk of injury to persons:
 - (a) Do not overheat the liquid.
 - (b) Stir the liquid both before and halfway through heating it.
 - (c) Do not use straight-sided containers with narrow necks.
 - (d) After heating, allow the container to stand in the microwave oven for a short time before removing the container.
 - (e) Use extreme care when inserting a spoon or other utensil into the container.

GROUNDING INSTRUCTIONS

This appliance must be grounded. In the event of an electrical short circuit, grounding reduces the risk of electric shock by providing an escape wire for the electric current. This appliance is equipped with a cord having a grounding wire with a grounding plug. The plug must be plugged into an outlet that is properly installed and grounded.

WARNING – Improper use of the grounding can result in a risk of electric shock. Consult a qualified electrician or serviceman if the grounding instructions are not completely understood, or if doubt exists as to whether the appliance is properly grounded. If it is necessary to use an extension cord, use only a 3-wire extension cord that has a 3-blade grounded plug, and 3-slot receptacle that will accept the plug on the appliance. The marked rating of the extension cord shall be equal to or greater than the electrical rating of the appliance.

DANGER – Electric Shock Hazard

Touching some of the internal components can cause serious personal injury or death. Do not disassemble this appliance.

WARNING – Electric Shock Hazard

Improper use of the grounding can result in electric shock. Do not plug into an outlet until appliance is properly installed and grounded.

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer cord sets or extension cords are available and may be used if care is exercised in their use.

RADIO INTERFERENCE

1. Operation of the microwave oven may cause interference to your radio, TV or similar equipment.
2. When there is interference, it may be reduced or eliminated by taking the following measures:
 - (a) Clean door and sealing surface of the oven.
 - (b) Reorient the receiving antenna of radio or television.
 - (c) Relocate the microwave oven with respect to the receiver.
 - (d) Move the microwave oven away from the receiver.
 - (f) Plug the microwave oven into a different outlet so that microwave oven

USAGE SAFETY GUIDE

1. The oven must be on a leveled surface.
2. The turntable and turntable roller rest must be in the oven during cooking. Place the cookware gently on the turntable and handle it carefully to avoid possible breakage.
3. Incorrect use of browning dish may cause the turntable to break.
4. Use only the specified bag size when using Direct Access Popcorn.
5. The oven has several built-in safety switches to ensure that the power remains off when the door is open. Do not tamper with these switches.
6. Do not operate the microwave oven empty. Operating the oven with no food or food that is extremely low in moisture can cause fire, charring or sparking.
7. Do not cook bacon directly on the turntable. Excessive local heating of the turntable may cause the turntable to break.
8. Do not heat baby bottles or baby food in the microwave oven. Uneven heating may occur and could cause physical injury.
9. Do not heat narrow-necked containers, such as syrup bottles.
10. Do not attempt to deep-fry in your microwave oven.
11. Do not attempt home canning in this microwave oven, as it is impossible to be sure all contents of the jar have reached boiling temperature.
12. Do not use this microwave oven for commercial purpose. This microwave oven is made for household use only.
13. To prevent delayed eruptive boiling of hot liquids and beverages or scalding yourself, stir liquid before placing the container in the oven and again halfway through cooking time. Let stand in the oven for a short time and stir again before removing the container.
14. Use care when cooking food in the microwave oven to avoid burning due to excessive cooking.
15. When the appliance is operated in the combination mode, children should only use the oven under adult supervision due to the temperatures generated.
16. Failure to maintain the oven in a clean condition could lead to deterioration that could adversely affect the life of the appliance and possibly result in a hazardous situation.

UTENSILS



Personal Injury Hazard

Tightly-closed utensils could explode. Closed containers should be opened and plastic pouches should be pierced before cooking.

See the instructions on "Materials you can use in microwave oven or to be avoided in microwave oven."

There may be certain non-metallic utensils that are not safe to use for microwaving. If in doubt, you can test the utensil in question following the procedure below.

Utensil Test:

1. Fill a microwave-safe container with 1 cup of cold water (250ml) along with the utensil in question.
2. Cook on maximum power for 1 minute.
3. Carefully feel the utensil. If the empty utensil is warm, do not use it for microwave cooking.
4. Do not exceed 1 minute cooking time.

MATERIALS YOU CAN USE IN YOUR MICROWAVE OVEN

Utensils	Remarks
Aluminum foil	Shielding only. Small smooth pieces can be used to cover thin parts of meat or poultry to prevent overcooking. Arcing can occur if foil is too close to oven walls. The foil should be at least 1 inch (2.5cm) away from oven walls.
Browning dish	Follow manufacturer* instructions. The bottom of browning dish must be at least 3/16 inch (5mm) above the turntable. Incorrect usage may cause the turntable to break.
Dinnerware	Microwave-safe only. Follow manufacturer's instructions. Do not use cracked or chipped dishes.
Glass jars	Always remove lid. Use only to heat food until just warm. Most glass jars are not heat resistant and may break.
Glassware	Heat-resistant oven glassware only. Make sure there is no metallic trim. Do not use cracked or chipped dishes.
Oven cooking bags	Follow manufacturer* instructions. Do not close with metal tie. Make slits to allow steam to escape.
Paper plates and cups	Use for short term cooking/warming only. Do not leave oven unattended while cooking.
Paper towels	Use to cover food for reheating and absorbing fat. Use with supervision for a short-term cooking only.
Parchment paper	Use as a cover to prevent splattering or a wrap for steaming.
Plastic wrap	Microwave-safe only. Follow the manufacturer* instructions. Should be labeled "Microwave Safe." Some plastic containers soften, as the food inside gets hot. "Boiling bags" and tightly closed plastic bags should be slit, pierced or vented as directed by package.
Thermometers	Microwave-safe only (meat and candy thermometers).
Wax paper	Use as a cover to prevent splattering and retain moisture.

MATERIALS TO AVOID IN MICROWAVE OVEN


Utensils	Remarks
Aluminum tray	May cause arcing. Transfer food into microwave-safe dish.
Food carton with metal handle	May cause arcing. Transfer food into microwave-safe dish.
Metal or metal-trimmed utensils	Metal shields the food from microwave energy. Metal trim may cause arcing.
Metal twist ties	May cause arcing and could cause a fire in the oven.
Paper bags	May cause a fire in the oven.
Plastic foam	Plastic foam may melt or contaminate the liquid inside when exposed to high temperature.
Wood	Wood will dry out when used in the microwave oven and may split or crack.

SETTING UP YOUR OVEN

Names of Oven Parts and Accessories

Remove the oven and all materials from the carton and oven cavity. Your oven comes with the following accessories:


Glass try (turntable)
Turntable ring assembly
Instruction manual



- A) Control panel
- B) Turntable shaft
- C) Turntable ring assembly
- D) Glass tray
- E) Observation window
- F) Door assembly
- G) Safety interlock system

Turntable Installation

- a) Never place the glass tray upside down. The glass tray should never be restricted.
- b. Both glass tray and turntable ring assembly must always be used during cooking.
- c. All food and containers of food are always placed on the glass tray for cooking.
- d. If glass tray or turntable ring assembly cracks or breaks, contact your nearest authorized service center.




Counter-top Installation

Remove all packing material and accessories. Examine the oven for any damage such as dents or broken door. Do not install if oven is damaged.

Cabinet: Remove any protective film found on the microwave oven cabinet surface. Do not remove the light brown Mica cover that is attached to the oven cavity to protect the magnetron.

1. Select a level surface that provides enough open space for the intake and/or outlet vents.




A minimum clearance of 3.0 inches (7.5cm) is required between the oven and any adjacent walls. One side must be open.

- (a) Leave a minimum clearance of 12 inches (30cm) above the oven.
 - (b) Do not remove the legs from the bottom of the oven.
 - (c) Blocking the intake and/or outlet openings can damage the oven.
 - (d) Place the oven as far away from radios and TV as possible. Operation of microwave oven may cause interference to your radio or TV reception.
2. Plug your oven into a standard household outlet. Be sure the voltage and the frequency is the same as the voltage and the frequency on the rating label.

WARNING – Do not install oven over a range cook-top or other heat-producing appliance. If installed near or over a heat source, the oven could be damaged and the warranty would be void.

Control Panel

- (1) Time Cook
- (2) Time Defrost
- (3) Weight Defrost
- (4) Power (10 power levels available)
- (5) Clock
- (6) Kitchen Timer
- (7) Auto Cook Menu
 - Popcorn
 - Potato,
 - Pizza
 - Frozen Vegetable
 - Beverage,
 - Dinner Plate
- (8) Express Cook (Number Pad 1-6)
- (9) Number Pad (0-9)
- (10) START/ADD 30 SEC (Begin cooking time or add time to cooking)
- (11) Stop/CANCEL (Before cooking starts press to clear all previous settings; during cooking, press once to stop oven; press twice to stop oven and clear all settings)
- (12) Memory function



OPERATION

1. POWER LEVEL

10 power levels are available.

LEVEL	10	9	8	7	6	5	4	3	2	1
POWER	100%	90%	80%	70%	60%	50%	40%	30%	20%	10%
DISPLAY	PL10	PL9	PL8	PL7	PL6	PL5	PL4	PL3	PL2	PL1

2. CLOCK SETTING

- (1) Press "Clock", "00:00" will display.
- (2) Press the number keys and enter the current time. For example, time is 10:12 now, please press "1,0,1,2" in turn.
- (3) Press "Clock" to finish clock setting. ":" will flash and the clock will illuminate.
- (4) If the numbers input are not within the range of 1:00-12:59, the setting will be invalid until valid numbers are input.

Note: * In the process of clock setting, if the "STOP/CANCEL" button is pressed or if there is no operation within 1 minute, the oven will go back to the former setting automatically. ** If the clock needs to be reset, please repeat step 1 to step 3.

3. MICROWAVE COOKING

- (1) Press "TIME COOK" once, the screen will display "00:00".
- (2) Press number keys to input the cooking time; the maximum cooking time is 99 minutes and 99 seconds.
- (3) Press "POWER" once, screen will display "PL10". The default power is 100% power. Now you can press number keys to adjust the power level.
- (4) Press "START/ADD 30sec" to start cooking.

Example: To cook the food with 50% microwave power for 15 minutes.

- (a) Press once. "00:00" displays.
- (b) Press "1", "5", "0", "0" in order.
- (c) Press "POWER" once, then press "5" to select 50% microwave power.
- (d) Press "START/ADD 30sec" to start cooking.

Note: * In the process of setting, if the "STOP/CANCEL" button is pressed or if there is no operation within 1 minute, the oven will go back to the former setting automatically. ** You can skip the step of "c" and cook at 100% microwave power.

4. KITCHEN TIMER

- (1) Press "Kitchen Timer" once, the screen will display 00:00.
- (2) Press the number keys and enter the timer time. (The maximum cooking time is 99 minutes and 99 seconds.)
- (3) Press "START/ADD 30sec" to confirm setting.

(4) When the timer time finishes, the buzzer will ring 3 times and the screen display will go back to the time mode.

Note: * The kitchen timer is separate from and won't interfere with the 12-hour clock on your microwave. ** Kitchen Timer and cooking (including microwave, defrosting, Auto menu) are independent, all the cooking for functions can be set while running the Kitchen Timer. Kitchen Timer can be set while other cooking functions are in process.

Example: When oven is cooking and you want to set timer to 10 minutes without interrupting the cook cycle follow these steps:

- (a) Press "Kitchen Timer" once, the screen will display 00:00
- (b) Press the number keys and enter the timer time.
- (c) Press "START/ADD 30sec" to start the time. If you don't press "START/ADD 30sec" in 10 seconds the timer will cancel automatically.

5. EXPRESS COOKING

(1) In waiting state, instant cooking at 100% power level with 30 seconds cooking time can be started by pressing "START/ADD 30sec". Each press on the same button will increase cooking time by 30 seconds. The maximum cooking time is 99 minutes and 99 seconds.

(2) Start the microwave instantly, at 100% power by pressing number pads 1-6. Press "START/ADD 30 sec" to increase the cooking time; the maximum cooking time is 99 minutes and 99 seconds.

Note: *During microwave cooking, time defrost and auto menu time can be added by pressing the "START/ADD 30sec" button.

6. CANCEL QUICKLY

During setting or running procedure, pressing "STOP/CANCEL" can stop current states and turn back to the waiting states instantly.

7. WEIGHT DEFROST FUNCTION

(1) Press "Weight Defrost" once, screen will display "DEF1";

(2) Press numerical buttons to input weight to be defrosted. Input the weight ranged between 4~100oz. If the weight input is not within 4~100, the input will be invalid.

(3) Press "START/ADD 30sec" to start defrosting and the cooking time remaining will be displayed.

8. TIME DEFROST FUNCTION

(1) Press "Time Defrost", screen will display "DEF2".

(2) Press number pads to input defrosting time. The effective time range is 00:00~99:99.

(3) The default microwave power is power level 3 and it cannot be changed.

(4) Press "START/ADD 30sec" to start defrosting. The remained cooking time will be displayed.

9. QUICK COOK CONTROL

POPCORN

- (1) Press "POPCORN" repeatedly until the number in OUNCES you need appears in the display: "1.75", "3.0", "3.5" will display in order.
- (2) Press "START/ADD 30sec" to cook, buzzer sounds once. When cooking completes the buzzer sounds five times and screen and the screen will display the correct time.

BEVERAGE

- (1) Press "BEVERAGE" repeatedly until the size you need in CUPS appears in the display, "1", "2", or "3" will display in order.
- (2) Press "START/ADD 30sec" to cook when you have chosen a size. The buzzer sounds once. When cooking completes, the buzzer sounds five times and screen and the screen will display the correct time.

PIZZA REHEAT

- (1) Press "PIZZA" repeatedly until the number of OUNCES you need appears in the display, "4.0", "8.0", or "14.0" will display in order.
- (2) Press "START/ADD 30sec" to cook, buzzer sounds once. When cooking completes, the buzzer sounds five times and the screen will display the correct time.

POTATO

- (1) Press "POTATO" repeatedly until the number of POTATOS you need appears in the display, "1", "2", or "3" will display in order.
- (2) Press "START/ADD 30sec" to cook, buzzer sounds once. When cooking completes, the buzzer sounds five times and the screen will display the correct time.

FROZEN VEGETABLE

- (1) Press "FROZEN VEGETABLE" repeatedly until the number in OUNCES you need appears in the display, "4.0", "8.0", or "16.0" will display in order.
- (2) Press "START/ADD 30sec" to cook, buzzer sounds once. When cooking completes, the buzzer sounds five times and screen and the screen will display the correct time.

DINNER PLATE

- (1) Press "DINNER PLATE" repeatedly until the number in OUNCES appears in the display, "9.0", "12.0", or "18.0" will display in order. (2) Press "START/ADD 30sec" to cook, buzzer sounds once. When cooking completes, the buzzer sounds five times and screen and the screen will display the correct time.

15. MEMORY FUNCTION

- (1) Press "0/MEMORY" to choose memory 1-3 procedure. The screen will display 1,2,3.
- (2) If the procedure has been set, press "START/ADD 30sec" to use it. If not, continue to set the procedure. Only one or two stages can be set.
- (3) If the procedure has not been set, after finishing the setting, press "Favorite" once to save the procedure and turn back to the waiting states. If you press "START/ADD 30sec" it will start cooking at once and save the procedure also.

Example: To set the following procedure as Memory 2--to cook the food with 80% microwave power for 3 minutes and 20 seconds follow these steps:

- (a) In waiting states, press "0/MEMORY" twice, stop pressing until the screen displays "2".
- (b) Press " TIME COOK " once, then press "3","2","0" in order.
- (c) Press "POWER" once, "PL10" display, then press "8" and "PL8" displays.
- (d) Press "Favorite" to save the setting. Buzzer sounds once then returns to waiting state. If you press "START/ADD 30sec" again, the procedure will be saved as the memory 2 and operated.
- (e) If the electricity is not cut off, the procedure will be saved permanently. If it is, the procedure will need to be reset.
- (f) When you want to run the saved procedure, in waiting states, press "Favorite" twice, when the screen displays "2" press " START/ADD 30sec " to start cooking.

Note: Auto menu can not be set in memory function.

16. MULTI-STAGE COOKING

Multi-Stage Cooking allows you to set the microwave power level to adjust during the cook cycle automatically. For example, with Multi-Stage cooking you can cook with 80% microwave power for 5 minutes + 60% microwave power for 10 minutes.

The cooking steps are as follows:

- (a) Press once, then press "5","0","0" to set the cooking time;
- (b) Press "POWER" once, then press "8" to select 80% microwave power.
- (c) Press once, then press "1","0","0","0" to set the cooking time;
- (d) Press "POWER" once, then press "6" to select 60% microwave power.
- (e) Press "START/ADD 30sec" to start cooking.

Note: * Auto menu cannot work in the multi-stage cooking. ** At most 2 stages can be set for cooking.

17. ADDITIONAL FUNCTIONS

INQUIRING FUNCTION In the microwave cooking state, press "POWER" to display the microwave power level. After three seconds, the oven will turn back to the previous state. The same method can be used to find power in the multi-stage cooking state.

LOCK FUNCTION FOR CHILDREN

Lock: In waiting state, press "STOP/CANCEL" for 3 seconds, there will be a long "beep" denoting the entering into the children-lock state, and the lock indicator will illuminate. The screen will display the current time or "0:00".

Unlock: In locked state, press "STOP/CANCEL" for 3 seconds, there will be a long "beep" denoting that lock is released.

END OF COOKING REMINDER When the cooking is over, the buzzer will sound 5 times to alert the user.

STANDBY If set, the clock displays the current time. If not set the clock shows "0:00".

SETTING FUNCTION STATE The screen displays corresponding setting.

WORKING STATE The screen displays surplus cooking time.

COOKING COMPLETE STATE When cooking is finished, the screen displays the time.

STOP or CANCEL COOKING Press "STOP/CANCEL" or open the door.

MAINTENANCE

TROUBLE SHOOTING

Check your problem by using the chart below and try the solutions for each problem. If the microwave oven still does not work properly, contact the nearest authorized service center.

Trouble	Possible Cause	Possible Remedy
Oven will not start	a. Electrical cord for oven is not plugged in. b. Door is open. c. Wrong operation is set.	a. Plug into the outlet. b. Close the door and try again. c. Check instructions.
Arcing or sparking	a. Materials to be avoided in microwave oven were used. b. The oven is operated when empty. c. Spilled food remains in the cavity	a. Use microwave-safe cookware only. b. Do not operate with oven empty. c. Clean cavity with wet towel.
Unevenly cooked foods	a. Materials to be avoided in microwave oven were used. b. Food is not defrosted completely. c. Cooking time, power level is not suitable. d. Food is not turned or stirred.	a. Use microwave-safe cookware only. b. Completely defrost food. c. Use correct cooking time, power level. d. Turn or stir food.
Overcooked foods	Cooking time, power level is not suitable.	Use correct cooking time, power level.
Undercooked foods	a. Materials to be avoided in microwave oven were used. b. Food is not defrosted completely. c. Oven ventilation ports are restricted. d. Cooking time, power level is not suitable.	a. Use microwave-safe cookware only. b. Completely defrost food. c. Check to see that oven ventilation ports are not restricted. d. Use correct cooking time, power level.
Improper defrosting	a. Materials to be avoided in microwave oven were used. b. Cooking time, power level is not suitable. c. Food is not turned or stirred.	a. Use microwave-safe cookware only. b. Use correct cooking time, power level. c. Turn or stir food.



ONE-YEAR Limited Warranty

This warranty applies to products purchased and used in the U.S. and Canada.

This is the only express warranty for this product and is in lieu of any other warranty or condition,

This product is warranted to be free from defects in material and workmanship for a period of one (1) year from the date of original purchase. This warranty is valid for the original retail purchaser or gift recipient from the date of initial retail purchase and is not transferable.

Keep your original sales receipt as proof of purchase is required to make a warranty claim.

IMPORTANT: This warranty does not cover damages resulting from use not in conformity with the printed directions, accident, misuse or abuse, alteration, the affixing of any attachments not provided with the product, loss of parts, or subjecting the appliance to any[thing] but specified voltage. (Read directions carefully.) This warranty is void if the product is used for [anything] other than single-family household use or subjected to any voltage and waveform other than as specified on the rating label (e.g., 120V~60 Hz).

Edge Consumers Brands, LLC excludes all claims for special, incidental, and consequential damages caused by breach of express or implied warranty. All liability is limited to the amount of the purchase price. **Every implied warranty, including any statutory warranty or condition of merchantability of fitness for a particular purpose, is disclaimed except to the extent prohibited by law, in which case such warranty or condition is limited to the duration of this written warranty.** This warranty gives you specific legal rights. You may have other legal rights that vary depending on where you live. Some states or provinces do not allow limitations on implied warranties or special, incidental, or consequential damages, so the foregoing limitations may not apply to you.

To make a warranty claim or if service is required, please call our CUSTOMER SERVICE NUMBER.

For faster service, please have the model, type, and series numbers ready for the operator to assist you.

Customer Service Number

Edge Consumer Brands, LLC

In the US 1-877-648-5974

Email: Support@EDGECEB.com



For customer service
questions or comments
1-877-648-5974

Bella is a registered trademark of Sensio Inc, Montreal, Canada H3B 3x9
Manufactured and sold pursuant to a license from Sensio Inc., Montreal, Canada H3B 3x9
©2016 Sensio Inc., Montreal, Canada H3B 3x9 All Rights Reserved.