

# NINJA®

MC510 Series

OWNER'S GUIDE

## 2-in-1 Slow Cooker



[ninjakitchen.com](http://ninjakitchen.com)

1-877-646-5288

# IMPORTANT SAFEGUARDS

## For Household Use Only

**WHEN USING ELECTRICAL APPLIANCES, BASIC SAFETY PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:**

**READ ALL INSTRUCTIONS BEFORE USING YOUR NINJA® 2-IN-1 SLOW COOKER.**

### POLARIZED PLUG

**⚠ WARNING:** To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. **DO NOT** modify the plug in any way.

**⚠ WARNING:** Extension cords are not recommended for use with this product.

**⚠ WARNING:** To reduce the risk of fire, electric shock, serious injury, death or damage when using this appliance, follow these basic safety precautions.

- ⚠ CAUTION:** To reduce the risk of electric shock, cook only in the pot provided or in a container recommended by SharkNinja placed in the provided pot. **DO NOT** use the appliance without the removable cooking pot inside.
- Read all instructions prior to using the appliance and its accessories.
- DO NOT** allow young children to operate this appliance or use as a toy. Close supervision is necessary when any appliance is used near children.
- To protect against electrical shock, **DO NOT** submerge the unit or allow the power cord to come into contact with water or any other liquid. If the unit falls into liquid, unplug the power cord from the electrical outlet immediately. **DO NOT reach into the liquid.**
- Please note that the appliance will become hot during use. **DO NOT** touch hot surfaces; **ALWAYS** use the side handles on the cooking system to relocate. **ALWAYS** use oven mitts or pot holders when removing the pot.
- Remove the power cord from the electrical outlet when not in use, before assembling or disassembling parts and before cleaning. To unplug, grasp the plug and pull from the electrical outlet. **NEVER** pull from the power cord. Allow the appliance to cool before adding or removing parts.
- DO NOT** abuse the power cord. **NEVER** carry the appliance by the power cord or yank it to disconnect from electrical outlet; instead grasp the plug and pull to disconnect.
- DO NOT** operate any appliance with a damaged cord or plug, or after the appliance malfunctions, or has been dropped or damaged in any manner. Return the appliance to SharkNinja Operating LLC for examination, repair or adjustment.
- Please refer to the Cleaning & Maintenance section for regular maintenance of the appliance. Return the appliance to SharkNinja Operating LLC for any other servicing.
- DO NOT** let the power cord touch hot surfaces such as the stove.



- 11 **ALWAYS** use the appliance on a dry, level surface.
- 12 **Extreme caution must be used when moving an appliance containing hot oil or other hot liquids. ALWAYS use oven mitts or pot holders when moving the cooking system. Allow hot oil to cool prior to removal or cleaning the appliance.**
- 13 To avoid possible steam damage, place the cooking system away from walls and cabinets during use.
- 14 When using this appliance, provide adequate air space above and on all sides for air circulation. On surfaces where heat may cause a problem, use of an insulated heat pad or trivet is recommended.
- 15 **Use extreme caution when removing the lid after cooking. Serious burns can result from the steam inside. ALWAYS lift and tilt the lid away from you when removing, using care to ensure water does not drip back into the appliance.**
- 16 **DO NOT** use outdoors or anywhere the cord or unit housing might come into contact with water while in use.
- 17 **DO NOT** use the appliance for anything other than its intended use.
- 18 **DO NOT** obstruct the steam release vent during use.
- 19 **ALWAYS** position the steam vent hole in the lid away from you.
- 20 **DO NOT** place or operate this appliance on or near any hot surfaces (such as a gas or electric burner or stove or in a heated oven).
- 21 The use of attachments or accessories not recommended by the manufacturer may result in fire, electric shock, or personal injury.
- 22 **DO NOT** use this appliance for deep frying.
- 23 To disconnect, press the Power button to turn the appliance off, then remove the plug from the wall outlet.
- 24 This appliance has a cutoff switch that will not allow the appliance to heat if the cooking pot is not inserted into the housing or removed while cooking.
- 25 **DO NOT** use an extension cord. A short power-supply cord is used to reduce the risk of children grabbing the cord or becoming entangled in it, and to reduce the risk of people tripping over a longer cord.
- 26 To avoid the possibility of the cooking system accidentally being pulled off the countertop or tabletop, which could result in damage to the cooking system or personal injury, **DO NOT** let the power cord hang over the edge of the counter or table.
- 27 Leaving food out too long at room temperature can cause bacteria to grow to dangerous levels that can cause illness. In the event of a loss of power, your unit will shut completely off. It is recommended to dispose of any food that has sat at room temperature for 1 hour without cooking.
- 28 Outlet voltages can vary affecting the performance of your product. To prevent possible illness, use a thermometer to check that your food is cooked to the temperatures recommended by the Food and Drug Administration.
- 29 **THIS PRODUCT IS INTENDED FOR HOUSEHOLD USE ONLY. DO NOT** use this appliance for anything other than its intended use. **DO NOT** use outdoors.
- 30 Intended for countertop use only.
- 31 **WARNING.** Spilled food can cause serious burns. Keep appliance and cord away from children. **NEVER** drape cord over edge of counter, never use outlet below counter, and **NEVER** use with an extension cord.

# SAVE THESE INSTRUCTIONS



## REGISTER YOUR PURCHASE



registeryourninja.com



1-877-646-5288



Scan QR code using mobile device



**TIP:** You can find the model and serial numbers on the QR code label which is located on the back of the unit by the power cord.

## RECORD THIS INFORMATION

Model Number: \_\_\_\_\_

Serial Number: \_\_\_\_\_

Date of Purchase (Keep receipt): \_\_\_\_\_

Store of Purchase: \_\_\_\_\_

## TECHNICAL SPECIFICATIONS

Voltage: 120V, 60Hz

Watts: 1200W

## PLEASE READ CAREFULLY AND KEEP FOR FUTURE REFERENCE.

These instructions are designed to help you get a complete understanding of your new Ninja 2-in-1 Slow Cooker.

If you have any questions, please call our customer service line at 1-877-646-5288.




## Contents

Thank you for  
purchasing the  
Ninja® 2-in-1 Slow  
Cooker.

Getting to Know Your Ninja 2-in-1 Slow Cooker .....	5
Getting to Know Your Ninja 2-in-1 Slow Cooker Control Panel .....	7
Preparing to Use Your Ninja 2-in-1 Slow Cooker.....	7
Using the Different Functions .....	8
Hints & Tips .....	9
Troubleshooting Guide .....	9
Cleaning & Maintenance .....	9
Replacement Parts.....	9
Warranty & Registration .....	10

# Getting To Know Your Ninja® 2-in-1 Slow Cooker



**a** Glass Lid


**b** Cooking Pot

**c** Main Housing

**d** Control Panel

**e** Power Cord (not shown)

The Ninja® 2-in-1 Slow Cooker offers a revolutionary new way to cook your foods faster and easier. The easy 1-2-3 electronic controls allow you the flexibility for true one-pot cooking.



**FEATURES:**

- **Stove Top Settings: LOW (simmer), HIGH (sear)**
- **ACCUTEMP Slow Cook Settings: LOW, HIGH**
- **Stay Warm (for Slow Cook function only)**
- **Auto Shutoff**

## Getting to Know Your Ninja® 2-in-1 Slow Cooker Control Panel



### Control Panel

Press the Power button to turn the appliance on. Press STOVE TOP or ACCUTEMP SLOW COOK to select your desired mode.

**Stove Top** - Use the Ninja 2-in-1 Slow Cooker as you would a stove top. You can simmer, sauté, or sear.

**ACCUTEMP Slow Cook** - Use the Ninja 2-in-1 Slow Cooker as a slow cooker. Select the temperature—Low or High—and let the cooking system do all the work. When it has finished cooking, it will automatically switch to Stay Warm mode.

### LED Display Screen

The LED screen displays the timer settings for the Stove Top and Slow Cook modes.

### Adjustment Buttons

Use the Adjustment buttons (“+” or “-”) to set the countdown timer in Slow Cook mode.

### Stay Warm

The Ninja 2-in-1 Slow Cooker will go into Stay Warm mode when the set cooking time in **ACCUTEMP** Slow Cook mode is over.


## Preparing to Use Your Ninja 2-in-1 Slow Cooker

Before using the slow cooker for the first time:

- 1 Review **ALL** warning and caution statements on pages 1 and 2 before proceeding to Step 2.
- 2 Carefully remove all the parts from the box. Wash the cooking pot and lid with warm, soapy water. The cooking pot and lid may also be washed in the dishwasher. **DO NOT** place the main housing in water or in the dishwasher. Wipe it clean with a damp cloth.
- 3 When ready to use, place the cooking pot inside the main housing. **NEVER** use the slow cooker without the cooking pot inserted in the housing.

- 4 Plug the unit into a wall outlet, the Power button will illuminate.
- 5 Press the Power button. The Temp/Time display will show 0:00 and the Power button will illuminate.
- 6 The Temp/Time display will continue to show 0:00 until you select a function. If no selection is made within 5 minutes, the operation will time out.
- 7 When you are ready to cook, select the cooking mode you want to use (STOVE TOP or ACCUTEMP SLOW COOK) and press that button.
- 8 See the detailed instructions for using the different functions on the following pages.

## Using the Different Functions



### Stove Top:

- 1 Place the cooking pot into the unit's main housing. Plug in the unit and press the Power button to turn it on.
- 2 Place the ingredients you want to sear, saute, brown, or simmer into the pot in an even layer.
- 3 Press the STOVE TOP button, and then press either the LOW or HIGH button.  
**TIP:** To sear meats or saute vegetables, set to HIGH.
- 4 Once you have selected Stove Top Low or High, the cooking cycle will start in 3 seconds.
- 5 When you have finished cooking your ingredients, press the Power button to stop cooking.  
**NOTE:** If you press the Power button accidentally, you can press it again within 5 seconds to resume cooking.  
**NOTE:** The Stay Warm and timer functions are not available when using the unit in Stove Top mode.
- 6 When you are ready to turn off the unit, press the Power button. The Temp/Time display will show the word OFF.  
**NOTE:** If you accidentally press the Power button, you can press it again within 5 seconds to resume all prior settings.

### Auto Shutoff for Stove Top:

As a safety feature, the unit will automatically shut off based on the setting that has been selected.

When set to Stove Top High, the unit will automatically shut off after 1 hour. When set to Stove Top Low, the unit will automatically shut off after 4 hours.

### ACCUTEMP Slow Cook:

- 1 Place the cooking pot into the unit's main housing. Plug in the unit and press the Power button to turn it on.
- 2 Place your ingredients in the cooking pot. Cover the pot with the lid.  
**NOTE:** DO NOT fill the pot more than 2/3 full.
- 3 Press the ACCUTEMP SLOW COOK button, then press either the LOW or HIGH button.  
**NOTE:** The display will default to 4:00 (hours) on the High setting and 8:00 on the Low setting. Press the "+" button to increase the cooking time or the "-" button to decrease it. The time adjusts in 15-minute increments down to 30 minutes and up to 12 hours.  
**NOTE:** If you lift the lid while cooking, it could result in heat loss that will require a longer cooking time.
- 4 Once you have set the cooking time, the cooking cycle will start after 3 seconds.
- 5 When the countdown timer reaches zero, the unit will beep 3 times and then switch to Stay Warm for up to 12 hours. Alternately, you can press the Power button to stop cooking prior to the end of your set time (the unit will NOT switch to Stay Warm in this case).  
**NOTE:** If you press the Power button accidentally, you can press it again within 5 seconds to resume the set cooking time.
- 6 When you are ready to turn off the unit, press the Power button. The Temp/Time display will show the word OFF.  
**NOTE:** If you accidentally press the Power button, you can press it again within 5 seconds to resume all prior settings.

### Stay Warm and Auto Shutoff for ACCUTEMP Slow Cook:

As a safety feature, the unit will shut off automatically based on the setting that has been selected.

When in the ACCUTEMP Slow Cook Low or High modes, at the end of the cooking cycle the unit will automatically switch to Stay Warm for 12 hours. At the end of the 12 hours, the unit will automatically shut off.

## Hints & Tips

- 1 Cooking times may vary based on the selected temperature, the current temperature of the cooking pot, and the temperature of the ingredients.
- 2 **ALWAYS** use nonstick utensils in the cooking pot. Metal utensils may damage the nonstick coating.
- 3 For even browning, make sure ingredients are arranged in an even layer on the bottom of the cooking pot.
- 4 Cooking time and temperature can be adjusted at any time during the cooking cycle in Slow Cook. Press the Adjustment buttons “+” or “-” to adjust.
- 5 Multiple modes may be required to cook recipes. To change modes during cooking cycles, simply press the corresponding button to select the new desired mode. Once the new mode is selected, begin the programming process.
- 6 If the cooking pot is removed during the cooking cycle and then placed back into the main housing, the cooking process will continue as though it was not interrupted.

## Troubleshooting Guide

PROBLEM	POSSIBLE SOLUTION
“Pot” Appears on the LED Display Screen	Cooking pot is not inside the main housing. Insert the cooking pot.
“E02” or “E03” Appears on the LED Display Screen	Ninja® 2-in-1 Slow Cooker is not functioning. Please contact customer service at <b>1-877-646-5288</b> .

## Cleaning & Maintenance

The Ninja 2-in-1 Slow Cooker should be cleaned thoroughly after every use.

- 1 Unplug the unit from the wall outlet.
- 2 **NEVER** immerse the main housing in water or any other liquid.
- 3 To clean the main housing and the control panel, wipe them clean with a damp cloth.
- 4 The cooking pot and lid can be washed in the dishwasher.
- 5 Dry all parts after each use.
- 6 If food residue is stuck on the cooking pot, fill the pot with water and allow to soak before cleaning. **DO NOT** use scouring pads. If scouring is necessary, use a non-abrasive cleanser or liquid detergent with a nylon pad or brush.
- 7 Please return the unit to SharkNinja Operating LLC for any other servicing.

**NOTE:** After usage, the exterior of the cooking pot may produce a black film when cleaned. This is due to oxidation and occurs from normal usage.

## Replacement Parts

To order additional parts and accessories, please visit [ninjaaccessories.com](http://ninjaaccessories.com) or contact customer service at 1-877-646-5288.

# Shark | NINJA

The 1-Year Limited Warranty applies to purchases made from authorized retailers of SharkNinja Operating LLC. Warranty coverage applies to the original owner and to the original product only and is not transferable.

SharkNinja warrants that the unit shall be free from defects in material and workmanship for a period of 1 year from the date of purchase when it is used under normal household conditions and maintained according to the requirements outlined in this instruction manual, subject to the following conditions and exclusions.

## **What is covered by my warranty?**

1. The original unit and/or non-wearable components deemed defective, in SharkNinja's sole discretion, will be repaired or replaced for up to 1 year from the original purchase date.
2. In the rare event that a replacement unit is issued, the warranty coverage ends six months after the receipt date of the replacement unit or the remainder of the existing warranty, whichever is greater. If the unit is replaced, SharkNinja reserves the right to replace the unit with one of equal or greater value.

## **What is not covered by my warranty?**

Our Customer Service and Product Specialists are available to provide all the warranty service options available to you, including the possibility of upgrading to our VIP Warranty Service Options for select product categories.

1. Normal wear and tear of wearable parts (including lid, removable pot, rack, pan) which require regular maintenance and/or replacement to ensure the proper functioning of your unit are not covered by your warranty.
2. Any unit that has been tampered with or used for commercial purposes.
3. SharkNinja will cover the cost for the customer to send the unit to us for repair or replacement. A fee of \$19.95 for return shipping costs will be charged at the time of return shipment of the repaired or replacement unit.
4. Damage caused by misuse, abuse, or negligent handling, or damage due to mishandling in transit.
5. Consequential and incidental damages.
6. Defects caused by or resulting from damages from shipping or from repairs, service, or alteration to the product or any of its parts which have been performed by a repair person not authorized by SharkNinja.
7. Products purchased, used or operated outside of North America.

## **Problems with your unit/How to get service:**

If your appliance fails to operate properly while in use under normal household conditions within the warranty period, visit [ninjakitchen.com](http://ninjakitchen.com) for product care/maintenance self-help. Our Customer Service and Product Specialists are also available at 1-877-646-5288 to assist with product support and warranty service options.

## **How to initiate a warranty claim:**

You can call 1-877-646-5288 to have a Customer Service specialist assist you. Please note, you must call 1-877-646-5288 to initiate a warranty claim. Return and packing instruction information will be provided at that time.

For Customer Service hours, visit [ninjakitchen.com](http://ninjakitchen.com)

Replacement parts are available for purchase at [ninjaaccessories.com](http://ninjaaccessories.com). For more information on what is classified as wearable and non-wearable parts, please visit [ninjakitchen.com/warranty](http://ninjakitchen.com/warranty)

This warranty gives you specific legal rights, and you may also have other rights that vary from state to state.

Some states do not permit the exclusion or limitation of incidental or consequential damages, so the above may not apply to you.



**SharkNinja Operating LLC**  
**US: Needham, MA 02494**  
**CAN: Ville St-Laurent, QC H4S 1A7**  
**1-877-646-5288**  
**ninjakitchen.com**

Illustrations may differ from actual product. We are constantly striving to improve our products; therefore the specifications contained herein are subject to change without notice.

Ninja, is a registered trademark of SharkNinja Operating LLC.

AUTO-IQ is a trademark of SharkNinja Operating LLC.

For SharkNinja U.S. Patent information visit [sharkninja.com/USPatents](http://sharkninja.com/USPatents).

© 2017 SharkNinja Operating LLC  
MC510\_15\_IB\_E\_170711\_2  
PRINTED IN CHINA / IMPRIMÉ EN CHINE / IMPRESO EN CHINA



**@ninjakitchen**