

NEW200 series

Wet/Dry vacuum cleaner; household type

Owner's Guide

Thank you for purchasing your new Eureka vacuum!

Important instructions

For easy assembly, please take a few moments to read this owner's guide.

If you have questions about your new vacuum, please contact our customer service HELPLINE at 1-800-282-2886.


We're here to help!



Eureka stands by our
Clean Promise seal.

Learn more at
www.eureka.com/cleanpromise

www.eureka.com



eureka

Where to find important vacuum information

Keep this information


Write the model, type and serial number here:

Date of purchase (keep your receipt) _____

Model number and type _____

Serial number _____

Find these numbers on a label on the middle back side of the vacuum cleaner. Refer to these numbers when ordering parts and accessories or if service is needed.




This Owner's Guide provides important instructions to prolong the life of your Eureka vacuum cleaner.

Registration: To register your product visit www.eureka.com and click on the 'Register Your Product' link in the top right corner.

Inspection: Carefully unpack and inspect your new Eureka vacuum cleaner for shipping damage. Each unit is tested and thoroughly inspected before shipping. For instructions regarding any shipping damage, call Eureka Customer Service **HELPLINE 1-800-282-2886** immediately.

Contents

Important safeguards.	3
What comes in the carton	4
How to identify parts of your vacuum cleaner	5
How to assemble your vacuum cleaner.	6
How to clean hard floors	7
How to clean area rugs	8
Using self-cleaning function.	9
Maintenance: Emptying dirty water tank	10
How to clean the brushroll and cover	11
Problem solving.	12
The Eureka limited warranty	13
How to order replacement parts	14

 Follow caution information wherever you see this symbol.

IMPORTANT SAFEGUARDS

When using an electrical appliance, basic precautions should always be followed, including the following:

READ ALL INSTRUCTIONS BEFORE USING THIS VACUUM CLEANER WARNING



To reduce the risk of fire, electric shock, or injury:

- Do not use outdoors.
- **Do not leave vacuum cleaner when plugged in.**

Turn off the switch and unplug the electrical cord when not in use and before servicing.

- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If vacuum cleaner is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, call the Eureka Customer Service **HELPLINE** at **1-800-282-2886**.
- Do not pull or carry by cord. Do not use cord as a handle. Do not close a door on cord or pull cord around sharp edges or corners. Do not run vacuum cleaner over cord. Keep cord away from heated surfaces.
- Do not use extension cords or outlets with inadequate current carrying capacity.
- Turn off all controls before unplugging.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or vacuum cleaner with wet hands.
- Do not put any object into openings. Do not use with any openings blocked; keep free of dust, lint, hair, and anything that may reduce airflow.
- This vacuum cleaner creates suction and contains a revolving brush roll. Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.
- Do not place vacuum cleaner on furniture or stairs as the brush roll may cause damage. Use extra care when cleaning stairs.
- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.

- Do not use without tanks, filters, lids, float, brushroll and brushroll cover in place.
- Belt pulleys can become hot during normal use. To prevent burns, avoid touching the belt pulley when servicing the drive belt.
- Do not use to pick up flammable or combustible liquids such as gasoline, or use in areas where they may be present.
- Store your vacuum cleaner indoors in a cool, dry area.
- Keep your work area well lit.
- Unplug electrical appliances before vacuuming them.
- Always use Eureka cleaning solution in your machine, other cleaning solutions may damage the machine and void the warranty.
- Do not use an excessive amount of cleaning solution or it may cause internal damage to the machine.
- Do not immerse in liquid. Use only on surfaces moistened by the cleaning process.
- Use only on level surfaces for optimal cleaning results.
- Do not use to pick up toxic substances (solvents, ammonia, gasoline, chlorine bleach, acidic substances, drain cleaner, etc.).
- Do not lift, carry or shake appliance while in use.
- When in use do not lay the machine down flat or on its side to prevent the dirty water from flowing into the motor.
- **WARNING:** This product can expose you to chemicals including Styrene, which is known to the State of California to cause cancer, and Bisphenol-A, which is known to the State of California to cause birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

SAVE THESE INSTRUCTIONS


To reduce the risk of electric shock, this appliance has a polarized plug (one blade is wider than the other). This plug will fit in a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way.



Motor

Do Not Oil the motor or the brush roll at any time. The bearings are permanently lubricated and sealed.

What Comes in the Carton




Important safeguards




Filter




Brushroll




Storage Base




Vacuum




Cleaning Solution



Brushroll Cleaning Tool




Accessory Drying Rack




Tank Cleaning Brush

Accessories may vary depending on which model was purchased.

How to Identify Parts of Your Vacuum Cleaner




How to Assemble Your Vacuum Cleaner




Insert handle into opening at top of vacuum until you hear a click.


To remove handle, press button under the covering on back of vacuum and pull the handle up at the same time.




The clean water tank is located on the upper front of the vacuum and the dirty water tank is located on the lower back of the vacuum.




Remove the clean water tank by lifting it straight up off the vacuum.




Twist to unscrew the cap on the clean water tank.



Fill the clean water tank have to the Max fill line with warm water and add **ONE** capful of cleaning solution.



Screw the cap firmly back on the water tank.



Align the water tank with the holder and slide down until it clicks into place.


Note: Use warm water and Eureka cleaning solution. Always use Eureka cleaning solution in your machine, other cleaning solutions may damage the machine and void the warranty.

Caution: Do not use water warmer than 140 degrees Fahrenheit. Do not use boiling water or heat water or tank in microwave.


How to Clean Hard Floors

⚠ CAUTION


Never operate vacuum cleaner without tanks, filter, brushroll and brushroll cover in place.



Plug power cord into outlet.




To start cleaning your hard floors turned the vacuum on pressing the **HARD FLOOR** button once.




Step on the floor nozzle and pull handle to lower into position for vacuuming. Brushroll will only spin only when handle is lowered into reclined position.


Please note: When vacuum is upright the brushroll will not spin.



Locate spray trigger on underside of the handle. Before each use hold the solution spray trigger for 10 seconds to get cleaning solution flowing to the brushroll.



To clean hold the solution spray trigger to apply solution on both forward and backward strokes. To dry hard floors faster do not hold down the spray trigger on the second pass.



To turn off press **HARD FLOOR** button a second time.


Suggestion: For challenging and stuck on messes on your hard floors use the **AREA RUG** mode and hold the vacuum over the mess. Use short strokes while holding the spray trigger to allow for a concentrated clean.

How to Clean Area Rugs


CAUTION

Never operate vacuum cleaner without tanks, filter, brushroll and brushroll cover in place.


Note: Before cleaning area rugs test a small area of the rug for color fastness. Also please check manufacturers cleaning instructions before cleaning area rugs. Do not use for on silk or delicate rugs or wall to wall carpeting.



Plug power cord into outlet.




To start cleaning your hard floors turned the vacuum on pressing the **AREA RUG** button once.




Step on the floor nozzle and pull handle to lower into position for vacuuming. Brushroll will only spin only when handle is lowered into reclined position.


Please note: When vacuum is upright the brushroll will not spin.



Locate spray trigger on underside of the handle. Before each use hold the solution spray trigger for 10 seconds to get cleaning solution flowing to the brushroll.



To clean hold the solution spray trigger to apply solution on both forward and backward strokes. For an optimal clean, make a few wet passes followed by a few dry passes over each area of you clean on your rugs.



To turn off press **AREA RUG** button a second time.

Note: The **AREA RUG** mode dispenses twice the solution of the **HARD FLOOR** mode for optimized cleaning on area rugs.



CAUTION: Do not over wet the carpet. Be careful not to run the vacuum over large solid debris or edges of area rugs as this may stall the brushroll and result in premature belt failure.

Using Self-Cleaning Function

⚠ CAUTION


Never operate vacuum cleaner without tanks, filter, brushroll and brushroll cover in place.

Do not remove the dirty water tank until after using the self-cleaning function empty as this will allow remaining debris under the brushroll and suction tube to be sucked into the dirty water tank.




After use, keep machine plugged into a power source and place the machine back onto the base and press the **SELF CLEANING** button on the front of the handle to start the self-cleaning function.


Note: **SELF CLEANING** function runs for 40 seconds and stops on its own.



After running the **SELF CLEANING** function disconnect the power cord from the wall and wrap the cord around the cord and wrap the cord around the cord hooks on the back of the machine.



Remove machine from base to access brushroll and when reinstalling the brushroll cover.




Before putting machine back onto the base, be sure to wipe the base to remove any remaining water or debris.


Maintenance: Emptying Dirty Water Tank

⚠ CAUTION


Never operate vacuum cleaner without tanks, filter, brushroll and brushroll cover in place.




Empty and clean The Dirty water tank after every use.
To remove The Dirty water tank press down on the release button on the top of the tank.
Grasp the front handle while pressing down on button and pull the dirty water tank straight out of machine.




Remove the filter from the top of The Dirty water tank by pulling it straight up.




Fully remove the dirty water tank from the machine and grasp the recessed areas on top of the lid and pull straight up to remove the lid.




Pour dirty water and debris out. Rinse the inside of the dirty water tank ensuring no debris remains in the tank.




Rinse the vacuum filter and screen with warm water.
Rinse the whole lid and float with warm water ensuring no debris remains.




Wipe the area where the dirty water tank sits clean with a towel.



Leave parts out to dry thoroughly before reinstalling.



Once parts are dry, place filter back into top of tank lid and place the lid back on top of the tank ensuring it is fully installed



Align the water tank with the holder and slide down until it clicks into place.

Note: Empty and rinse out the clean water tank and allowed to dry before reinstalling. Do not store machine with water and or cleaning solution in the tanks.

How to Clean the Brushroll and Cover








CAUTION

Never operate vacuum cleaner without tanks, filter, brushroll and brushroll cover in place.

1. To remove the brushroll cover grasp the release button and pull up and forward.
2. Remove brushroll by pulling up on the tab located on the left side.
3. Rinse brushroll and brushroll cover. Use brushroll cleaning tool to help remove debris and hair on the roller.
4. Wipe the brushroll chamber thoroughly to remove any debris.
5. Put the brush roll upright in the drying stand let your brush roll and cover dry thoroughly for 24 hours before reassembling.

Note: The brushroll, brushroll cover, dirty water tank, clean water tank, lids and filters are not dishwasher safe. Please follow cleaning instructions in this manual.

6. Install brushroll by inserting the right end of the roller into the right side of the floor nozzle. Then insert by aligning the tab on the left side with the slot and pressing into place.
7. To reinstall the brushroll cover, tilt the window back and align both tabs on the lower edges of the cover with the slots on the floor nozzle then push in and downwards until it clicks into place.



Machine Storage

Store the machine on its base in a dry, protected area. Ensure machine is not exposed to freezing temperatures or internal components could be damaged and warranty will be void.

Problem solving



Make sure vacuum is turned off and power cord is unplugged.

NOTICE : Thermal cut-off

This vacuum cleaner has a special thermostat that protects the vacuum in case of motor overheating.

If the vacuum suddenly shuts off, proceed as follows: 1) Push the power switch to off and unplug the vacuum. 2) Check the vacuum for a possible source of overheating such as a full dirty water tank, blocked intake passage or or clogged filter. If these conditions are found, fix them and wait at least 30 minutes before attempting to use the vacuum. 3) After the 30 minute period, plug the vacuum back in and turn on the switch. If the vacuum still does not work, call the Eureka Customer Service **HELPLINE** at **1-800-282-2886**.

Problem	Possible Reasons	Solutions
Brushroll not spinning	The brushroll is entangled with debris, brushroll is not properly installed or vacuum is locked in the upright position.	Check brushroll chamber for debris Recline machine to make sure brushroll is activated
Loss of suction power	The dirty water tank has reached its capacity	Empty dirty water tank
	Brushroll, brushroll cover and/or dirty water tank are not properly installed	Turn machine off and reinstall making sure all parts fit properly and securely in place
	The roller brush is entangled with debris	Check brushroll chamber for debris
	The suction nozzle or pipe is blocked	Clean the debris in the suction nozzle or pipe
	Strainer above the dirty water tank float is dirty	Empty dirty water tank and clean lid/float, filter and filter screen
	Filter is clogged	Remove debris from filter, rinse clean and dry thoroughly before reinstalling
Abnormal sound	The suction nozzle is blocked	Remove clogs/debris from pipe and/or brushroll chamber
	The dirty water tank has reached its capacity	Empty dirty water tank
Limited or no spray	Clean water tank is empty	Refill clean water tank
	The clean water tank is not properly installed	Turn machine off and reinstall making sure all parts fit properly and securely in place
Air is leaking out	The float in the dirty water tank is not properly installed	Turn machine off and reinstall making sure all parts fit properly and securely in place
	The dirty water tank filter is not completely dry	After cleaning filter let dry for at least 24 hours

The Eureka two-year limited warranty

Midea America Corp. (“Eureka”), subject to the terms and conditions herein, warrants this vacuum cleaner to be free from defects in material and workmanship for a term of two years from the date of original purchase when used in accordance with the Eureka operating and maintenance instructions and under normal household usage. This warranty is granted only to the original purchaser and members of immediate household, and is applicable only to original purchases from Eureka authorized resellers.

What Eureka will do:

Eureka will, at its option, repair or replace a defective vacuum or vacuum part that is covered by this warranty. Repairs may be performed using new or refurbished parts that meet or exceed Eureka specifications for new parts. If Eureka elects to replace the vacuum, the replacement may be a reconditioned unit. Depending on availability of products, Eureka reserves the right to provide you with a replacement product that is the same or similar, or substitute equivalent of the original product. As a matter of warranty policy, Eureka will not refund the consumer’s purchase price.

This warranty does not cover:

- Normal wear and tear of the vacuum and vacuum parts that require replacement under normal use such as disposable dust bags, filters, drive belts, light bulbs, brush-roll, bristles, impellers and cleaning.
- Damages or malfunctions resulting from: improper or unreasonable use or maintenance, abuse, negligence, failure to follow instructions contained in any written materials that accompany the product, deterioration by reason of excess moisture, corrosive atmosphere, lightning, power surges, connections to improper voltage supply, unauthorized alteration, or other external causes such as extremes in temperature or humidity, modifications, scratches or discoloration, accidents, misuse, or acts of God. This warranty also does not cover damage resulting from repair or attempted repair by anyone other than Eureka or an authorized Eureka Warranty Station. This warranty is not applicable to any product that has been altered or on which the serial number has been defaced, modified or removed. Altering, erasing, or forging any proof-of-purchase documents voids any applicable product warranty.

Obtaining warranty service:

To obtain warranty service you must contact the Eureka Service Team, toll free, at 1-800-282-2886 or email customerserviceusa@midea.com, to discuss the warranty claim and procedures to be followed. All warranty claims must include submission of proof-of-purchase documentation. For additional information, you may also visit www.eureka.com.

Shipping charges:

You will be responsible for any initial shipping and insurance charges if the defective product(s) must be shipped for warranty service or warranty evaluation; however, Eureka or a Eureka Authorized Warranty Station will pay the return shipping charges if repairs are covered by the warranty. When returning parts for repair, you must include the model, type and serial number located on the rating plate on the lower backside of the vacuum. If any product submitted for warranty service is found to be ineligible, an estimate of repair cost will be furnished and the repair performed only if requested by the owner and upon receipt of payment or acceptable arrangements for payment.











Further limitations and exclusions:

Any warranty that may be implied in connection with your purchase or use of the vacuum, including any warranty of Merchantability or any warranty of Fitness For A Particular Purpose is limited to the duration of this limited warranty. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you.

Your relief for the breach of this warranty is limited to the relief expressly provided above. In no event shall the manufacturer be liable for any consequential or incidental damages you may incur in connection with your purchase or use of the vacuum. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.

This warranty gives you specific legal rights. You may also have other rights, which may vary by state.

Midea America Corp.
Parsippany, NJ
USA

Image	Part name	Part # (Fits models)
	Brushroll	XXX
	Brushroll cleaning tool	W0003
	Filter	W0006
	Filter top	W0007
	Dirty water tank	W0008
	Storage base	W0010
	Accessory drying rack	W0011
	Cleaning brush	W0009
	1L Cleaning solution <small>Please note: machine comes with 236ml bottle of cleaning solution</small>	W0002
	Clean water bottle	W0005


Owner's Guide

Do not return to the store, call
Eureka Customer Service
HELPLINE 1-800-282-2886

www.eureka.com



Eureka stands by
our Clean Promise seal.
Learn more at
www.eureka.com/cleanpromise



eureka