

LG7 SIDE RAIL KIT-9625 LG10-LG900 SIDE RAIL KIT-9626

LG7-PART NO. 109625 LG10-PART NO. 109626 LG900-PART NO. 109626 INSTRUCTIONS NO.-104742-C

NOTICE: Once used, this kit cannot be returned to the store. If you have a warranty claim, please read and follow Warranty Information directions below.

WARRANTY INFORMATION

CLAM OUTDOORS INC. warrants to the original retail purchaser its product be free from manufacturers defects for (5) years from the date of the original purchase. Clam Outdoors Inc will replace or repair any part found defective within the (5) years time limit. All parts must be returned to Clam Outdoors Inc. Before returning any parts, you must first call or write and acquire a return authorization. All returns must be returned postage-prepaid and include the original cash register receipt (date and purchase price).

To submit a warranty claim request, please use one of the following methods:

Customer Service Hrs: 9am to 4pm, Monday – Friday Central Standard Time

Clam Corporation

Attn: Customer Service - Warranty Department

12135 Brockton Lane Rogers, MN 55369 Phone: 763-231-4120 Fax: 763-231-4121

Email: <u>customerservice@clamcorp.com</u>

Website: <u>Clamoutdoors.com</u>

The warranty does not apply to any Polar Trailer accessory which has been subjected to an accident, improper installation, modification, adjustment, repair, misuse, misapplication, neglect, including but not limited to improper maintenance, or use of unauthorized parts or attachments.

LIMITATION OF LIABILITY

It is expressly understood that Clam Outdoors Inc. liability for its products, whether due to breach of warranty, negligence, strict liability, or otherwise, is limited to the repair of the product as stated above. Clam Outdoor Inc. is not liable for any injury, loss, damage, or expense, whether direct or consequential, including but not limited to loss of use, income, profit, or damage to material arising in connection with the sale, installation, use of, inability to use, or the repair or replacement of Clam Outdoor Inc. products. Clam Outdoor Inc. reserves the right to make alterations or modifications in its products at any time, which in its opinion, may improve the performance and efficiency of the product. It shall not be obligated to make such alterations or modifications to products already in service.

WARNING:

- THIS ATTACHMENT IS INTENDED FOR USE IN LAWN CARE AND HOME APPLICATIONS.
- DO NOT TOW BEHIND A VEHICLE ON A HIGHWAY OR IN ANY HIGH SPEED APPLICATION.
- THIS PRODUCT HAS BEEN DESIGNED FOR OFF-ROAD USE ONLY.
- MAXIMUM TOW SPEED IS 10 MPH.

THE FOLLOWING STATEMENTS ARE SUGGESTIONS AND DO NOT SUPERCEDE OR ELIMINATE ANY TOWING AND SAFETY INSTRUCTIONS LISTED IN ANY OWNERS MANUALS FOR ANY PRODUCT BEING USED FOR THE PURPOSE OF TOWING ANY CLAM OUTDOORS INC. PRODUCTS. ALWAYS REFER TO THE TOWING VEHICLES MANUAL, GUIDELINES OR INSTRUCTIONS.

Towing Loads Safely

- Stopping distance increases with speed and weight of towed load. Travel slowly and allow extra time and distance to stop.
- Total towed weight must not exceed limits specified in towing vehicle operator's manual.
- Excessive towed load can cause loss of traction and loss of control on slopes. Reduce towed weight when
 operating on slopes.
- Never allow children or others in or on towed equipment.
- Use only approved hitches. Tow only with a machine that has a hitch designed for towing. Do not attach towed equipment except at the approved hitch point.
- Follow the manufacturer's recommendations for weight limits for towed equipment and towing on slopes.
- Do not turn sharply. Use additional caution when turning or operating under adverse surface conditions. Use care when reversing.
- · Do not shift to neutral and coast downhill.

Protect Bystanders

- Keep bystanders away when you operate a towed attachment.
- Before you back machine and attachment, look carefully behind attachment for bystanders.

Keep Riders off Towed Attachment


- Keep riders off of a towed attachment.
- Riders on a towed attachment are subject to injury, such as being struck by objects and being thrown off the attachment during sudden starts, stops and turns.
- Riders obstruct the operator's view, resulting in the attachment being used in an unsafe manner.
- Keep riders off of the hitch bracket or trailer tongue.


- Replacement Parts

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	104067 <i>LG10 Front</i>	FRONT RAIL	1
1	104059 <i>LG7 Front</i>	FRONT RAIL	1
2	104063	SIDE RAIL	2
3	101230	1/4-20 X 2" SCREW	4
4	101081	WASHER, 1/4" FLAT	10
5	101163	NUT, 1/4-20 NYLOCK	10
6	101473	1/4-20 X 1.50" SCREW	6

- Assembly Instructions -

Assemble the side rails to the front rail as shown.





- Install the Rail kit by setting the assembled kit on top of the plastic base.
- Mark the (6) Holes to be drilled.
- Drill the marked spots with a 5/16" (8mm) drill bit.
- Set the assembled rail kit on top and bolt together as shown.

