Upgrade Air Vent Covers for Home Floor Use Guide

1. Before Installation

Measure Your Vent: Use a measuring tape to accurately measure the width of your existing sidewall, floor, or ceiling vent. Ensure that the width falls within the 9″ - 15″ range that our air vent covers can adjust to.

- **Prepare the Area**: Clean the surface around the vent thoroughly. Remove any dust, debris, or old adhesive residue to ensure a secure and stable fit for the new cover.

2. Installation Steps

For Sidewall Vents

. **Adjust the Cover**: Hold the air vent cover and locate the adjustment mechanism. Gently slide the sides of the cover to widen or narrow it until it matches the width of your sidewall vent.

. **Position the Cover**: Align the edges of the adjusted cover with the edges of the vent opening. Make sure it is centered and fits snugly.

. **Secure in Place**: Some models may come with clips or screws. If using clips, press them firmly onto the vent frame to lock the cover in position. If using screws, insert the screws through the pre - drilled holes in the cover and into the vent frame, then tighten them with a screwdriver.

For Floor and Ceiling Vents

. **Adjust as Above**: Similar to sidewall vents, adjust the width of the cover to fit your floor or ceiling vent.

. **Place the Cover**: Carefully lower the cover onto the floor vent or lift it up to position over the ceiling vent. Ensure it covers the entire vent opening evenly.

. **Lock in Position**: Use the provided securing elements (clips or screws) to firmly attach the cover to the vent, ensuring it doesn't move or rattle.

3. Adjusting Airflow

- **Open and Close Louvers**: Most of our air vent covers feature adjustable louvers. Use your fingers to gently tilt the louvers up or down, left or right. This allows you to control the direction of the airflow, directing it towards the areas of the room that need heating or cooling the most.

4. Cleaning and Maintenance

- **Regular Cleaning**: Periodically remove the air vent cover for cleaning. You can use a soft brush or a vacuum cleaner with a brush attachment to remove dust and debris from the cover and the vent itself.
- **Deep Cleaning**: For a more thorough clean, wash the cover in warm, soapy water. Rinse it thoroughly and let it dry completely before reinstalling it on the vent. This helps maintain optimal airflow and keeps your home environment clean.