2 Pack Air & Heat Deflector Instructions

1. Unpacking

Open the package and take out the 2 deflectors. Check for any damage; if found, contact the seller promptly.

2. Adjustment (if needed)

Slide the adjustable sections to fit your vent size—range from 8.5" to 15". Ensure it aligns with the vent width before installation.

3. Installation

For vents/sidewalls: Place the deflector over the vent, making sure it sits flat. Use the included adhesive strips (if provided) to secure it in place.

For ceiling registers: Position the deflector under the register, adjusting to fit, then press gently to attach (adhesive or clips may apply).

4. Final Check

Ensure the deflector is stable and covers the vent properly. Adjust angles slightly to direct airflow as desired.

Your air & heat deflectors are ready to use.