Outdoor Furniture Care & Use Manual

√ Ensuring Longevity, Safety, and Optimal Performance

Thank you for choosing our premium outdoor furniture! Proper care and maintenance will help preserve its beauty and functionality for years. This manual covers general guidelines for various materials and product types.

1. Material-Specific Care Instructions

A. Metal Furniture (Aluminum, Steel, Wrought Iron)

Cleaning:

- Wipe regularly with a damp cloth and mild soap solution.
- For stubborn stains, use a non-abrasive cleaner.
- Rinse thoroughly with clean water to prevent soap residue.

Maintenance:

- Apply a protective wax or automotive polish (for aluminum) to maintain shine.
- Check for rust spots periodically; sand and touch up with matching paint if needed.

- Lubricate moving parts (e.g., rocking chairs, recliners) with silicone spray.

Storage:

- Cover with **weatherproof furniture covers** when not in use.

- Store indoors during **harsh winters or extreme weather**.

B. Wood Furniture (Teak, Cedar, Eucalyptus, Acacia)

Cleaning:- Use a soft brush and wood cleaner (avoid bleach or harsh detergents).

- Rinse with water and let dry completely.

Maintenance:

- Apply **teak oil or sealant** (1-2 times per year) to prevent drying and cracking.

- Sand lightly if surface becomes rough, then reapply sealant.

Storage:

- Elevate furniture to avoid ground moisture absorption.

- Cover or store indoors in humid or freezing conditions.

C. Plastic/Resin/Rattan/Wicker Furniture

Cleaning:

- Wash with warm, soapy water and a soft cloth.

- For mildew, use a vinegar-water solution (50/50).

Maintenance:

- Avoid abrasive scrubbing to prevent surface scratches.

- Store or cover during prolonged sun exposure to prevent fading.

Storage:

- If possible, store indoors during off-season months.

- Use UV-resistant covers for added protection.

D. Fabric & Cushions (Outdoor-Grade Textiles)

Cleaning:

- Remove loose dirt with a soft brush or vacuum.

- Spot clean with mild detergent and warm water.

- Machine wash (if removable) on gentle cycle (check label first).

Maintenance:

- Allow cushions to dry completely before storage to prevent mold.

- Store in a dry, ventilated area when not in use.

2. General Usage & Safety Tips

☑ **Proper Setup:**

- Assemble furniture on a **flat, stable surface** to prevent tipping.

- Tighten screws/bolts **every few months** to maintain stability.

☑ **Weight Limits:**

- Do not exceed the **maximum recommended weight** (check product label).

☑ **Weather Protection:**

- Use **breathable, waterproof covers** to shield from rain, snow, and UV rays.

- Avoid leaving furniture uncovered in **extreme heat, hail, or heavy storms**.

☑ **Avoid:**

- Dragging furniture (lift instead to prevent leg damage).

- Placing hot items directly on surfaces (use trivets for grills/heaters).

3. Seasonal Care Checklist

Spring/Summer:

Deep clean furniture before use.

Reapply protective coatings (oil, sealant, wax).

Check for loose screws or structural wear.

Fall/Winter:

Clean and dry furniture thoroughly.

Store cushions indoors or in sealed containers.

Cover or move furniture to a sheltered area.

4. Warranty & Support

Our products are built for durability, but if you encounter **manufacturing defects**, contact our support team within **90 days of purchase:

Email:

ray.a.coleman@outlook.com

Include: Order number, photos, and a description of the issue.

Enjoy Your Outdoor Living Space!

ray.a.coleman@outlook.com

Noted:

For product-specific instructions, refer to the manual included with your purchase.

Illustrations/diagrams (e.g., assembly tips) can be added for clarity.