1. SAFETY WARNINGS & PRECAUTIONS

WARNING: TO AVOID SERIOUS INJURY:

ADULT ASSEMBLY REQUIRED: This product contains small parts, sharp points, and sharp edges prior to assembly. Keep children away until fully assembled.

CONSTANT ADULT SUPERVISION REQUIRED: Direct adult supervision is required at all times while children are using this product. Never leave children unattended.

WEIGHT LIMITS: [Important Note to User: Please insert the specific weight limits here based on your engineering specs. A typical standard for this size is often 100 lbs (45 kg) per swing station/slide. Do not exceed the specified weight limits.]

ANCHORING IS MANDATORY: This unit must be securely anchored to the ground to prevent tipping or instability during vigorous play.

STRANGULATION HAZARD:

NEVER attach items to the playground equipment that are not specifically designed for use with the equipment, such as, but not limited to, jump ropes, clotheslines, pet leashes, cables, and chains, as they may cause a strangulation hazard.

DRESS CHILDREN APPROPRIATELY: Remove hooded jackets with drawstrings, scarves, mittens connected by cords, and loose-fitting clothing that could get caught on the equipment. Ensure children wear well-fitting closed-toe shoes.

FALL HAZARD:

DO NOT install this equipment over concrete, asphalt, packed earth, grass, carpet, or any other hard surface. A fall onto a hard surface can result in serious head or other injuries.

Protective surfacing material (such as wood chips, mulch, fine sand, or fine gravel) of an appropriate depth is recommended under and around the playset.

2. CRITICAL INSTALLATION & PLACEMENT GUIDELINES

Proper placement is critical for safe play.

Level Ground: Install the set on flat, level ground. Installing on sloping ground will cause

the unit to lean or tip.

Safety Zone: Create an obstacle-free safety zone of at least 6 feet (1.83 meters) in all directions from the equipment. This area must be free of fences, trees, electrical wires, laundry lines, garages, or houses.

Swing Clearance: In front of and behind the swings, the safety zone must extend a distance equal to twice the height of the top bar.

Overhead Clearance: Ensure there are no overhead obstructions like tree branches or electrical wires.

3. PRODUCT SPECIFICATIONS & PARTS LIST

Specifications:

Assembled Length: 152.49 inches (approx. 12.7 ft / 387 cm)

Assembled Width: 53.55 inches (approx. 4.5 ft / 136 cm)

Assembled Height: 70.87 inches (approx. 5.9 ft / 180 cm)

Mini Slide Length: Approx. 47 inches (1.2 meters)

Color Palette: Deep Blue and Gray

Features List:

Heavy-duty metal frame

1 x Standard Swing Seat

1 x Large Canvas Saucer Swing

1 x Face-to-Face Glider Swing

1 x Mini Slide

1 x Basketball Hoop Attachment

1 x Soccer Net Attachment

(Note: Before beginning assembly, please refer to the detailed parts checklist included in the hardware box to ensure all components, nuts, and bolts are present.)

4. ASSEMBLY OVERVIEW

Please refer to the separate step-by-step diagrammatic instructions included with the product for detailed assembly.

Tools Required: Wrench set (usually provided), Phillips screwdriver, and possibly a rubber mallet.

General Steps:

Lay out all parts and verify against the parts list.

Assemble the main A-frame structure first, initially keeping bolts finger-tight.

Attach the top bar support.

Securely tighten all frame bolts.

Assemble and attach the Mini Slide to the designated side.

Attach the swing hangers, then hang the Swing Seat, Saucer Swing, and Face-to-Face Glider. Ensure ropes/chains are not twisted.

Attach the Basketball Hoop and Soccer Net accessories.

Final Step: Install ground anchors (stakes) securely into the soil at the base of the legs.

5. USAGE GUIDELINES

Teach children the following safety rules:

Slide Feet First: Always slide down feet first, sitting up. Never slide headfirst or on the stomach.

No Climbing Up the Slide: Do not climb up the slide chute.

Stay Clear of Moving Swings: Do not walk close to, in front of, behind, or between moving swings.

Sit Properly: Sit in the center of the swings with full weight on the seat. Do not stand or kneel on swing seats.

Wait Until Stopped: Do not get off the swing or slide until it has completely stopped.

Wet Weather: Do not use the equipment when it is wet, as surfaces will be slippery.

6. MAINTENANCE & CARE INSTRUCTIONS

Regular maintenance is essential for the safety and longevity of the playset, especially in variable North American climates.

At the Beginning of Each Play Season & Monthly During Use:

Tighten Hardware: Check all nuts, bolts, and screws. Tighten them if loose. Replace any worn or corroded hardware immediately.

Inspect Protective Covers: Check all bolt caps and sharp edge covers. Replace if missing or cracked.

Check Swing Seats & Ropes: Inspect the canvas saucer swing for tears, fraying, or UV degradation. Check swing ropes/chains for wear. Replace immediately if any damage is found.

Lubricate: Apply a light coat of metallic lubricant to the swing hangers (where the metal rubs against metal) to prevent squeaking and wear.

Check Rust: Inspect metal tubing for scratches in the paint. Sand lightly and touch up with non-lead-based paint to prevent rust.

Check Anchors: Ensure ground stakes are still securely seated in the ground.

Winterization / End of Season Care:

Remove Soft Parts: In areas with cold winters, remove the canvas saucer swing, plastic swing seats, basketball net, and soccer net. Store them indoors in a dry place. Exposure to freezing temperatures and heavy snow can shorten the lifespan of fabrics and plastics.

Cleaning:

Clean the slide and frame with mild soap and water. Do not use abrasive cleaners.