

INSTALLATION INSTRUCTIONS

1. Slide nut **(A)** and washer **(B)** or **(E)** on tailpiece (Use 1 1/2 in x 1 1/4 in washer **(B)** if necessary)
2. Slide J-bend **(C)** onto tailpiece and tighten nut **(A)**
3. Measure and cut floor tube **(D)** to length. Floor tube **(D)** should go into fitting 1 in minimum
4. Slide nut **(H)** and washer **(G)** on end of floor tube **(D)** and attach to sink trap **(I)**
5. Attach floor tube **(D)** and sink trap **(I)** to J-bend **(C)** by tightening nut **(F)**
6. Tighten nuts. **CHECK FOR LEAKS**

INSTRUCCIONES DE INSTALACIÓN

1. Desliza la tuerca **(A)** y la arandela **(B)** o **(E)** en el tubo de conexión (usa una arandela de 1 1/2 plg x 1 1/4 plg **(B)** si es necesario)
2. Desliza el codo en **(C)** en el tubo de conexión y ajusta la tuerca **(A)**
3. Mide y corta el tubo de piso **(D)** al largo requerido. El tubo de piso **(D)** debe entrar en el acoplamiento 2.5 cm, como mínimo
4. Desliza la tuerca **(H)** y la arandela **(G)** en el extremo del tubo de piso **(D)** y conéctalo al sifón del fregadero **(I)**
5. Conecta el tubo de piso **(D)** y el sifón del fregadero **(I)** al codo en **(C)** ajustando la tuerca **(F)**
6. Ajusta las tuercas. **VERIFICA QUE NO HAYA FILTRACIONES**

