

# Cuisinart®

## INSTRUCTION/ RECIPE BOOKLET



**Smart Stick® Two Speed Hand Blender**

**CSB-75 Series**

For your safety and continued enjoyment of this product,  
always read the instruction book carefully before using.

---

# IMPORTANT SAFEGUARDS

When using an electrical appliance, basic safety precautions should always be followed including the following:

- 1. READ ALL INSTRUCTIONS.**
- 2. Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning. To unplug, grasp plug and pull from electrical outlet. Never pull cord.**
3. To protect against electrical shock, do not put the motor body, cord or electrical plug of this hand blender in water or other liquid. The detachable blending shaft of this appliance has been designed for immersion into water or other liquids. Never submerge any other portion of this unit. If hand blender falls into liquid, unplug the unit first, then remove blender immediately. Do not reach into the liquid without unplugging the unit first.
4. This appliance should not be used by children. To avoid possible accidental injury, close supervision is necessary when any appliance is used by or near children.
5. Avoid contacting moving parts.
6. During operation keep hands, hair, clothing, as well as spatulas and other utensils away from attachments and any mixing container, to reduce risk of injury to persons, and/or damage to the appliance. A spatula may be used, but must be used only when the unit is not operating.
7. Do not operate any appliance with a damaged cord or plug, or after the appliance has malfunctioned or has been dropped or damaged in any way or is not operating properly. Return the appliance to the nearest Cuisinart Repair Center for examination, repair, or mechanical or electrical adjustment.
8. Remove detachable shaft from the blender before washing the blades or shaft.
- 9. Blades are SHARP. Handle carefully when removing, inserting or cleaning the blending shaft.**
10. When mixing liquids, especially hot liquids, use a tall container or make small quantities at a time to reduce spillage, splattering and possibility of injury from burning.
11. The use of attachments or accessories not recommended by Cuisinart may cause fire, electrical shock, or risk of injury.
12. Do not use outdoors, or use for other than intended use.
13. Do not let any cord hang over the edge of the table or counter. Do not let cord contact hot surfaces, including stovetop.

- 
14. Make sure the appliance is off, the motor has stopped completely, and the appliance is unplugged from outlet before putting on or taking off attachments, and before cleaning.
  15. To reduce the risk of injury, never place cutting blade on base without first putting bowl properly in place.
  16. Be certain cover is securely locked in place before operating appliance.
  17. Do not operate your appliance in an appliance garage or under a wall cabinet. **When storing in an appliance garage always unplug the unit from the electrical outlet.** Not doing so could create a risk of fire, especially if the appliance touches the walls of the garage or the door touches the unit as it closes.
  18. Maximum rating is based on the 200W food processor attachment that draws the greatest power.

# SAVE THESE INSTRUCTIONS FOR HOUSEHOLD USE ONLY

## NOTICE

This appliance has a polarized plug (one blade is wider than the other). As a safety feature, this plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to defeat this safety feature.

## CONTENTS

Important Safeguards . . . . .	2
Unpacking Instructions . . . . .	4
Parts and Features . . . . .	4
Assembly . . . . .	5
Operation . . . . .	6
Cleaning and Maintenance . . . . .	6
Tips and Hints . . . . .	7
Recipes . . . . .	8
Warranty . . . . .	21

---

## UNPACKING INSTRUCTIONS

Place the package containing the Cuisinart® Smart Stick® Two Speed Hand Blender on a sturdy surface. Unpack the Smart Stick® Two Speed Hand Blender from its box by removing the upper protective insert. Gently slide the unit from the box. Remove all support materials from the box and replace the upper insert. Save packaging for possible repacking of the unit.

**Note: The blending blade is extremely sharp. Use caution when removing.**

Before using the Cuisinart® Smart Stick® Two Speed Hand Blender for the first time, we recommend that you wipe the unit with a clean, damp cloth to remove any dirt or dust. Dry it thoroughly with a soft absorbent cloth. Handle carefully. Never submerge motor body housing in water or any other liquid; wash mixing container and detachable shaft by hand or in the dishwasher. Dry thoroughly before use. Read all instructions completely for detailed operating procedures.

## PARTS AND FEATURES

### 1. Lock/Unlock Button

Must be pressed to unlock before power handle will operate.

**2. Low/High Two Speed Power Button:** Allows you to activate the hand blender at the touch of a button. Simply press and hold down the Low or High button to blend or pulse. Once the button is released, blending will stop.

**3. Comfort Handle:** The handle allows you to control the hand blender with ease.

### 4. Motor Body Housing

**5. Detachable Shaft:** By pressing the release button on the back of the unit, the shaft will detach for easy cleaning.

### 6. Blending Attachment with Stainless Steel Blade and Blade Guard:

This attachment easily snaps into the motor body housing.

The stainless blade is partially covered by a stainless housing that keeps splashing to a minimum.

**7. Mixing Cup:** 2-cup mixing cup is microwave- and dishwasher- safe. Use this container to blend drinks, shakes, salad dressings and more. Designed for easy gripping and drip-free pouring.

**8. BPA Free:** All materials that come in contact with food or liquid are BPA free.

---

## PARTS

1. Lock/Unlock Button
2. Low/High Button
3. Comfort Handle
4. Motor Body Housing
5. Detachable Blending Shaft
6. Blade Guard
7. Mixing Cup

## ASSEMBLY

Align the motor body with the blending shaft and slide the pieces together until you hear and feel the pieces click together. It may be helpful to press the release button when assembling.



---

## OPERATION

The specially designed blade is for mixing and stirring all kinds of foods, including salad dressings, powdered drink products, and sauces. It is ideal for combining dry ingredients, and can be used to emulsify mayonnaise, too.

This blade mixes and stirs while adding only a minimum of air to your mixture. A gentle up-and-down motion is all you need to make the most flavorful, full-bodied liquid recipes. Be careful never to remove the Cuisinart® Smart Stick® Two Speed Hand Blender from the liquid while in operation.

1. Insert the blending attachment into the motor body. (See Assembly, page 5.)
2. Plug electrical cord into an electrical wall socket.
3. Place blending shaft into mixture that will be blended.
4. Press and hold the desired speed. Press and hold the Lock/Unlock button on top of the motor housing and press the power button to turn motor on. Once motor is on, you can release the Lock/Unlock button but continue to hold in the speed button. You can also press the speed button first, holding it down as you press the Lock/Unlock button to turn motor on. Do not hold power button down for more than 60 seconds at a time..
5. Do not hold the button ON for longer than 60 seconds at a time.
6. Unplug immediately after use.

## CLEANING AND MAINTENANCE

Always clean the Smart Stick® motor body and blending shaft thoroughly after using.

Remove the blending shaft from the motor body. Clean the motor body only with a sponge or damp cloth. Do not use abrasive cleaners which could scratch the surface. To clean the blending shaft, wash by hand in hot water using mild detergent, or in dishwasher.

### **Never immerse the motor body in water.**

When the appliance has malfunctioned or has been dropped or damaged in any way or it is not operating properly, return the appliance to the nearest Cuisinart Repair Center for examination, repair or mechanical or electrical adjustment.

Any other servicing should be performed by an authorized service representative.

---

## TIPS AND HINTS

### FOR HAND BLENDER

- Be sure that blending blade guard is fully submerged before blending ingredients.
- To purée a soup, use the hand blender to blend the soup ingredients to the desired consistency, using a gentle up-and-down motion right in the saucepan or pot.
- When blending ingredients right in a pot or pan tilt the pan away from you to create a deeper area for blending to prevent splatter.
- When using a nonstick cooking surface, be careful not to scratch the coating with the hand blender.
- When blending into the blending cup, for example when making a fruit smoothie, cut most solid foods into ½ inch pieces for easy blending.
- Use the hand blender to make smooth gravies and pan sauces.
- Do not immerse motor body housing in water or any other liquid.
- When blending in the mixing cup, pour liquid ingredients in first, unless recipe instructs otherwise.
- The hand blender is perfect for frothing milk for cappuccino or lattes. Just warm milk in a small saucepan, and then pulse the hand blender gently, being sure to keep the blending blade guard fully submerged.
- Do not let hand blender stand in a hot pot on stove while not in use.
- Do not attempt to blend fruit pits, bones or other hard materials as these are liable to damage the blades.
- Do not fill mixing containers too full. The level of mixture will rise when blending and can overflow.
- To whip air into a mixture, always hold the blade just under the surface.
- Using a gentle up-and-down motion is the best way to blend and incorporate ingredients uniformly.
- Liquid should not come closer than 1-inch of where the shaft attaches to the motor housing.

---

## Limited Three-Year Warranty (U.S. and CANADA only)

This warranty is available to consumers only. You are a consumer if you own a Cuisinart® Smart Stick® Two Speed Hand Blender that was purchased at retail for personal, family or household use. Except as otherwise required under applicable law, this warranty is not available to retailers or other commercial purchaser or owners.

We warrant that your Cuisinart® Smart Stick® Two Speed Hand Blender will be free of defects in materials and workmanship under normal home use for 3 years from the date of original purchase.

We recommend that you visit our website, [www.cuisinart.com](http://www.cuisinart.com) for a fast, efficient way to complete your product registration. However, product registration does not eliminate the need for the consumer to maintain the original proof of purchase in order to obtain the warranty benefits. In the event that you do not have proof of purchase date, the purchase date for purposes of this warranty will be the date of manufacture.

If your Cuisinart® Smart Stick® Two Speed Hand Blender should prove to be defective within the warranty period, we will repair it, or if we think necessary, replace it. To obtain warranty service, simply call our toll-free number 1-800-726-0190 for additional information from our Customer Service Representatives or send the defective product to Customer Service at Cuisinart, 7475 North Glen Harbor Blvd., Glendale, AZ 85307.

To facilitate the speed and accuracy of your return, please enclose \$10.00 for shipping and handling of the product.

Please pay by check or money order (California residents need only supply proof of purchase and should call 1-800-726-0190 for shipping instructions).

**NOTE:** For added protection and secure handling of any Cuisinart® product that is being returned, we recommend you use a traceable, insured delivery service. Cuisinart cannot be held responsible for in-transit damage or for packages that are not delivered to us. Lost and/or damaged products are not covered under warranty.

Please be sure to include your return address, daytime phone number, description of the product defect, product model # (located on bottom of product), original date of purchase, and any other information pertinent to the product's return.

### CALIFORNIA RESIDENTS ONLY

California law provides that for In-Warranty Service, California residents have the option of returning a nonconforming product

(A) to the store where it was purchased or

(B) to another retail store which sells Cuisinart products of the same type.

The retail store shall then, at its discretion, either repair the product, refer the consumer to an independent repair facility, replace the product, or refund the purchase price less the amount directly attributable to the consumer's prior usage of the product.



---

If either of the above two options does not result in the appropriate relief to the consumer, the consumer may then take the product to an independent repair facility if service or repair can be economically accomplished. Cuisinart and not the consumer will be responsible for the reasonable cost of such service, repair, replacement, or refund for nonconforming products under warranty.

California residents may also, according to their preference, return nonconforming products directly to Cuisinart for repair, or if necessary, replacement, by calling our Consumer Service Center toll-free at 1-800-726-0190.

Cuisinart will be responsible for the cost of the repair, replacement, and shipping and handling for such products under warranty.

### **BEFORE RETURNING YOUR CUISINART® PRODUCT**

If your Cuisinart® Smart Stick® Two Speed Hand Blender should prove to be defective within the warranty period, we will repair or, if we think necessary, replace it. To obtain warranty service, please call our Customer Service Center toll-free at 1-800-726-0190 or write to: Cuisinart, 7475 North Glen Harbor Blvd. Glendale, AZ 85307. To facilitate the speed and accuracy of your return, enclose \$10.00 for shipping and handling. (California residents need only supply a proof of purchase and should call 1-800-726-0190 for shipping instructions.) Please be sure to include your return address, description of the product's defect, product serial number, and any other information pertinent to the return. Please pay by check or money order. NOTE: For added protection and secure

handling of any Cuisinart® product that is being returned, we recommend you use a traceable, insured delivery service. Cuisinart cannot be held responsible for in-transit damage or for packages that are not delivered to us. Lost and/or damaged products are not covered under warranty.

Your Cuisinart® Smart Stick® Two Speed Hand Blender has been manufactured to the strictest specifications and has been designed for use only in 120 volt outlets and only with authorized accessories and replacement parts. This warranty expressly excludes any defects or damages caused by attempted use of this unit with a converter, as well as use with accessories, replacement parts or repair service other than those authorized by Cuisinart. This warranty does not cover any damage caused by accident, misuse, shipment or other than ordinary household use. This warranty excludes all incidental or consequential damages. Some states do not allow the exclusion or limitation of these damages, so these exclusions may not apply to you. You may also have other rights, which vary from state to state.

**Important:** If the nonconforming product is to be serviced by someone other than Cuisinart's Authorized Service Center, please remind the servicer to call our Consumer Service Center at 1-800-726-0190 to ensure that the problem is properly diagnosed, the product is serviced with the correct parts, and to ensure that the product is still under warranty.

---

# NOTES

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

©2015 Cuisinart  
150 Milford Road  
East Windsor, NJ 08520

Printed in China  
15CE016630

Any trademarks or service marks of third parties used herein are  
the trademarks or service marks of their respective owners.

**IB-11131-ESP-B**

# Cuisinart®

## MANUAL DE INSTRUCCIONES/ LIBRO DE RECETAS



Licuada de mano con dos velocidades Smart Stick®

Serie CSB-75

Para su seguridad y para disfrutar plenamente de este producto, siempre lea las instrucciones cuidadosamente antes de usarlo.

---

# MEDIDAS DE SEGURIDAD IMPORTANTES

Siempre que use aparatos eléctricos, debe tomar precauciones básicas de seguridad, incluso las siguientes:

- 1. LEA TODAS LAS INSTRUCCIONES.**
- 2. Desconecte el aparato cuando no esté en uso, antes de instalar o remover piezas y antes de limpiarlo. Para desconectar el aparato de la toma de corriente, agarre el cable por la clavija; nunca jale el cable.**
3. Para reducir el riesgo de electrocución, no ponga la base, el cable o la clavija en agua u otro líquido. Sólo la cuchilla y la varilla desmontable son sumergibles. No sumerja ninguna otra parte del aparato en agua u otro líquido. Si el aparato cayera en líquido, desconéctelo y luego retírelo del líquido. No trate de alcanzar el aparato sin haberlo desconectado.
4. Este aparato no debería ser usado por niños. Supervise el uso de este aparato cuidadosamente cuando esté usado por o cerca de niños.
5. Evite el contacto con las piezas móviles.
6. Para evitar el riesgo de heridas y/o daños al aparato, mantenga los dedos, cabello, ropa, espátulas y otros utensilios lejos de los batidores durante el funcionamiento.  
Se podrá usar una espátula de goma, siempre que el aparato esté apagado.
7. No utilice este aparato si el cable o la clavija estuviesen dañados, si no funcionase debidamente, si estuviese dañado, o después de que se hubiese caído al piso o al agua. Regrese el aparato a un centro de servicio autorizado para su revisión, reparación o ajuste.
8. Retire la varilla desmontable del aparato antes de lavar las cuchillas o la varilla.
- 9. Las cuchillas son MUY FILOSAS. Manipúlela con cuidado al retirar, instalar o limpiar la varilla.**
10. Para reducir el riesgo de salpicadura o quemadura al mezclar líquidos, especialmente líquidos calientes, utilice un recipiente alto o procese pequeñas cantidades a la vez.
11. El uso de accesorios no recomendados o proveídos por Cuisinart presenta un riesgo de incendio, electrocución o herida.
12. No lo utilice en exteriores, ni para ningún otro fin que no sea el indicado.
13. No permita que el cable cuelgue del borde de la encimera o de la mesa, ni que haga contacto con superficies calientes.

- 
14. Asegúrese que el aparato esté apagado y desconectado, y de que el motor se haya detenido completamente, antes de instalar/retirar accesorios o limpiar el aparato.
  15. Para reducir el riesgo de heridas, asegúrese de que el bol esté debidamente ensamblado antes de instalar la cuchilla.
  16. Asegúrese de que la tapa esté debidamente cerrada antes de encender el aparato.
  17. No haga funcionar el aparato bajo o adentro de un armario. **Siempre desconecte el aparato antes de guardarlo en un armario.** Dejar el aparato conectado presenta un riesgo de incendio, especialmente si éste toca las paredes o la puerta del armario cuando cierra.
  18. La potencia nominal máxima (200 vatios) está basada en el accesorio que consume más electricidad (el accesorio procesador).

# GUARDE ESTAS INSTRUCCIONES PARA USO DOMÉSTICO SOLAMENTE

## AVISO

El cable de este aparato está dotado de una clavija polarizada (una pata es más ancha que otra). Como medida de seguridad, se podrá enchufar de una sola manera en la toma de corriente polarizada. Si no entrara en la toma de corriente, invíértala. Si aún no entrara completamente, comuníquese con un electricista. No intente ir en contra de esta función de seguridad.

## ÍNDICE

Medidas de seguridad importantes . . . . .	2
Instrucciones de desembalaje . . . . .	4
Piezas y características . . . . .	4
Ensamblaje . . . . .	5
Funcionamiento . . . . .	6
Limpieza y mantenimiento . . . . .	6
Consejos . . . . .	7
Recetas . . . . .	8
Garantía . . . . .	21

---

## DESEMBALAJE

Coloque la caja de su licuadora de mano con dos velocidades Smart Stick® de Cuisinart® sobre una superficie llana y segura. Abra la caja y retire e inserto de cartón ubicado encima del aparato. Deslice el aparato fuera de la caja. Retire el manual de instrucciones y otros folletos de la caja y regrese el inserto adentro de la caja. Le aconsejamos que guarde el material de embalaje.

**Nota: la cuchilla licuadora es muy filosa; tenga cuidado al retirarla.**

Le aconsejamos que limpie el aparato con un paño limpio y ligeramente humedecido antes del primer uso. Seque todas las piezas con un paño suave y absorbente. Manipular con sumo cuidado. Nunca sumerja el bloque-motor en agua u otro líquido. Lave el vaso y la varilla desmontable a mano o en el lavavajillas. Seque todas las piezas antes de usar el aparato. Lea cuidadosamente las instrucciones antes de usar el aparato.

## PIEZAS Y CARACTERÍSTICAS

### 1. Botón de desbloqueo:

Evita poner el aparato en marcha sin querer. Siempre lo deberá presionar para que el motor se encienda.

**2. Interruptor con dos velocidades:** Permite encender la licuadora al toque de un botón. Simplemente mantenga oprimido u oprima repetidamente el botón LOW (bajo) o HIGH (alto) para licuar. El aparato se apagará al soltar el botón.

**3. Cómodo mango:** Permite controlar fácilmente la licuadora de mano.

### 4. Bloque-motor

**5. Varilla desmontable:** Facilita la limpieza. Simplemente oprima el botón de liberación ubicado en la parte trasera del aparato para desmontar la varilla.

**6. Accesorio licuador con cuchillas y protector de cuchillas de acero inoxidable:** Fácil de instalar.

El protector de cuchillas de acero inoxidable evita las salpicaduras.

**7. Vaso:** Vaso con capacidad de 475 ml, apto para microondas y lavavajillas. Ideal para licuar bebidas, batidos, aderezos y mucho más. Cuenta con un pico anti-goteo y es fácil de agarrar.

**8. Sin BPA:** Ninguna de las piezas en contacto con los alimentos/líquidos contiene bisfenol A (BPA).

## PIEZAS

1. Botón de desbloqueo
2. Interruptor con dos velocidades
2. Cómodo mango
3. Bloque-motor
4. Varilla desmontable
5. Protector de cuchillas
6. Vaso

## ENSAMBLAJE

Haga coincidir la varilla con el bloque motor y conecte ambas piezas hasta que se bloqueen. Puede que se le haga más fácil oprimiendo el botón de liberación de la varilla.





---

## FUNCIONAMIENTO

La cuchilla ha sido diseñada para procesar una gran variedad de alimentos, incluso aderezos, bebidas en polvo y salsas. Es ideal para combinar ingredientes secos, y también puede usarse para emulsionar mayonesa.

La cuchilla mezcla los alimentos sin incorporar mucho aire a la mezcla. Un movimiento suave hacia arriba y abajo es todo lo que necesita para preparar las más sabrosas recetas. Para evitar las salpicaduras, tenga cuidado de no retirar la cuchilla del líquido durante el uso.

1. Conecte el accesorio licuador al bloque-motor. Véase las instrucciones en la página 5.
2. Enchufe el cable en una toma de corriente
3. Sumerja la varilla en la mezcla.
4. Oprima y mantenga oprimido el botón de velocidad deseado. Mantenga oprimido el botón de desbloqueo arriba de la empuñadura para encender el motor. Una vez encendido el motor, puede soltar el botón de desbloqueo, pero deberá seguir oprimiendo el botón de velocidad. Nota: también puede hacer el contrario, oprimiendo primero el botón de velocidad y luego el botón de desbloqueo. No presione el botón de velocidad durante más de 60 segundos seguidos.
5. No haga funcionar el aparato durante más de 60 segundos seguidos.
6. Desconecte el aparato inmediatamente después del uso.

## LIMPIEZA Y MANTENIMIENTO

Limpie el aparato cuidadosamente después de cada uso.

Retire el accesorio licuador del bloque-motor. Limpie el bloque-motor con una esponja o un paño ligeramente humedecido. No utilice limpiadores abrasivos, los cuales podrían dañarlo. Lave la varilla a mano o en el lavavajillas, usando detergente suave.

### **Nunca sumerja el bloque-motor en agua.**

No utilice el aparato después de se hubiese caído, si estuviese dañado o si no estuviese funcionando correctamente. Regrese el aparato a un centro de servicio autorizado para su revisión, reparación o ajuste.

Cualquier otro servicio debe ser realizado por un técnico autorizado.

---

# CONSEJOS ÚTILES

## ACCESORIO LICUADOR

- Asegúrese de que el protector de cuchillas esté completamente sumergido antes de empezar a licuar.
- Licue las sopas directamente en la cacerola/olla, usando un movimiento suave hacia arriba y abajo, hasta obtener la consistencia deseada.
- Cuando licua los ingredientes directamente en la olla, incline ligeramente la olla para evitar las salpicaduras.
- Si usa cacerolas/ollas antiadherentes, no permita que la licuadora haga contacto con el revestimiento antiadherente.
- Cuando licua directamente en el vaso, por ejemplo para preparar batidos de frutas, corte los alimentos en cubitos de 1.5 cm (½ pulgada).
- Utilice la licuadora de mano para preparar salsas suaves y homogéneas.
- No sumerja el bloque-motor en agua u otro líquido.
- Cuando licua directamente en el vaso, siempre agregue los ingredientes líquidos primero, salvo indicación contraria en la receta.
- La licuadora de mano es perfecta para espumar la leche, para servir con capuchino o café con leche. Simplemente caliente la leche en una cacerola, y luego lícuela suavemente, oprimiendo el botón de velocidad repetidamente y manteniendo la cuchilla sumergida.
- No deje el aparato adentro de una cacerola/olla caliente.
- No licue alimentos que contienen materias duras como huesos, pepas, etc. Esto podría dañar las cuchillas.
- No sobrellene los recipientes en los cuales licua. La mezcla se expande durante el licuado y puede desbordarse.
- Para incorporar aire a una mezcla, mantenga la cuchilla justo debajo de la superficie.
- Un movimiento suave hacia arriba y abajo es la mejor manera de conseguir resultados uniformes y homogéneos.
- No sumerja la varilla hasta más de 1 pulgada (2.5 cm) del bloque-motor.

---

# GARANTÍA

## Garantía limitada de tres años (válida en los EE.UU. y en Canadá solamente)

Esta garantía es para los consumidores solamente. Usted es un consumidor si ha comprado su aparato Cuisinart® en una tienda, para uso personal o casero. A excepción de los estados donde la ley lo permita, esta garantía no es para los detallistas u otros comerciantes.

Cuisinart garantiza este aparato contra todo defecto de materiales o fabricación durante 3 años después de la fecha de compra original, siempre que el aparato haya sido utilizado para uso doméstico y según las instrucciones.

Le aconsejamos que llene el formulario de registro disponible en **www.cuisinart.com** a fin de facilitar la verificación de la fecha de compra original. Sin embargo, registrar el producto no es necesario para recibir servicio bajo esta garantía. En ausencia del recibo de compra, el período de garantía será calculado a partir de la fecha de fabricación.

Si este aparato presentara algún defecto de materiales o fabricación durante el período de garantía, la repararemos o reemplazaremos (a nuestra opción). Para obtener servicio bajo esta garantía, llame a nuestra línea directa gratuita al 1-800-726-0190 o regrese el aparato defectuoso a: Cuisinart, Service Department, 7475 North Glen Harbor Blvd., Glendale, AZ 85307.

Regrese el aparato defectuoso, junto con su recibo de compra y un cheque o giro postal de US\$10.00 por gastos de manejo y envío.

Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al 1-800-726-0190 para recibir instrucciones de envío.

**NOTA:** para mayor seguridad, le aconsejamos que mande su paquete por un método de entrega con seguro y seguimiento. Cuisinart no será responsable por los daños ocurridos durante el transporte o por los paquetes mandados a una dirección equivocada. Los productos perdidos y/o lastimados durante el envío no serán cubiertos bajo esta garantía.

Recuerde incluir su nombre, dirección y teléfono, la descripción del problema, así como cualquier información pertinente.

### RESIDENTES DE CALIFORNIA SOLAMENTE

La ley del estado de California ofrece dos opciones bajo el período de garantía. Los residentes del estado de California pueden

(A) regresar el producto defectuoso a la tienda donde lo compraron o

(B) a otra tienda que venda productos Cuisinart® de este tipo.

La tienda, a su opción, reparará el producto, referirá el consumidor a un centro de servicio independiente, cambiará el producto o reembolsará el consumidor por el precio original del producto, menos la cantidad imputable al uso del producto por el consumidor hasta que éste se dañe.

Si estas dos opciones no satisfacen al consumidor, podrá llevar el aparato a un centro de servicio independiente, siempre que se pueda ajustar o reparar el aparato de manera económica. Cuisinart será responsable por los gastos de servicio, reparación, reemplazo o reembolso de los productos defectuosos durante el período de garantía.

---

Los residentes de California también pueden, si lo desean, mandar el aparato defectuoso directamente a Cuisinart para que lo reparen o lo cambien. Para esto, se debe llamar a nuestro servicio posventa al 1-800-726-0190.

Cuisinart será responsable por los gastos de reparación, reemplazo, manejo y envío de los productos defectuosos durante el período de garantía.

### **ANTES DE HACER REPARAR SU APARATO**

Si este aparato presentara algún defecto de materiales o fabricación durante el período de garantía, la repararemos o reemplazaremos (a nuestra opción). Para obtener servicio bajo esta garantía, llame a nuestra línea directa gratuita al 1-800-726-0190 o regrese el aparato defectuoso a: Cuisinart, 7475 North Glen Harbor Blvd., Glendale, AZ 85307. Regrese el aparato defectuoso, junto con su recibo de compra y un cheque o giro postal de US\$10.00 por gastos de manejo y envío. Los residentes de California sólo necesitan dar una prueba de compra y deben llamar al 1-800-726-0190 para recibir instrucciones de envío. Recuerde incluir su nombre, dirección y teléfono, la descripción del problema, así como cualquier información pertinente. Sentimos no poder aceptar otras formas de pago. NOTA: para mayor seguridad, le aconsejamos que mande su paquete por un método de entrega con seguro y seguimiento. Cuisinart no será responsable por los daños ocurridos durante el transporte o por los paquetes mandados a una dirección equivocada. Los productos perdidos y/o lastimados durante el envío no serán cubiertos bajo esta garantía.

Este aparato satisface las más altas exigencias de fabricación y ha sido diseñado para uso sobre corriente de 120V, usando accesorios y piezas de repuesto autorizados solamente. Esta garantía excluye expresamente los daños causados por accesorios, piezas o reparaciones no autorizados por Cuisinart, así como los daños causados por el uso de un convertidor de voltaje. Esta garantía no cubre el uso institucional o comercial del producto, y no es válida en caso de daños causados por mal uso, negligencia o accidente. Esta garantía excluye expresamente todos los daños incidentales o consecuentes. Algunos Estados no permiten la exclusión o limitación de daños incidentales o consecuentes, de modo que las limitaciones mencionadas pueden no regir para usted. Usted puede tener otros derechos que varían de un Estado a otro.

**Importante:** si debe llevar el aparato defectuoso a un centro de servicio no autorizado, por favor informe al personal del centro de servicio que deberían llamar al servicio posventa de Cuisinart al 1-800-726-0190 a fin de diagnosticar el problema correctamente, usar las piezas correctas para repararlo y asegurarse de que el producto esté bajo garantía.



©2015 Cuisinart  
150 Milford Road  
East Windsor, NJ 08520

Impreso en China  
15CE016630

Todas marcas registradas o marcas de comercio mencionadas  
en ésta pertenecen a sus titulares respectivos.

**IB-11131-ESP-B**