StyleWell™

Item #1004 439 773
Model #FTS61191

USE AND CARE GUIDE

42 IN. STEEL ROUND DINING TABLE



Questions, problems, missing parts?
Before returning to the store, call Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

THANK YOU

We appreciate the trust and confidence you have placed in StyleWell through the purchase of this table.We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing StyleWell!

Table of Contents

Table of Contents 2
Important Safety Instructions 2
Save These Instructions 2
Read All Instructions Before Use 2
Warranty 3
What is covered 3
What is not covered 3
Pre-Assembly 3
Planning Assembly 3
Hardware Included 4
Package Contents 4
Assembly 5
Care and Cleaning 7

Important Safety Instructions

SAVE THESE INSTRUCTIONS

WARNING: THIS TABLE WAS MADE FOR THE EXPLICIT PURPOSE OF PROVIDING OUTDOOR FUNCTIONS AND IS NOT TO BE USED AS A TOY. THIS PRODUCT IS INTENDED FOR NORMAL OUTDOOR USE. HOWEVER, THE MANUFACTURER RECOMMENDS STORING AND/OR COVERING THIS PRODUCT WHEN ANY FORMIDABLE/SEVERE WEATHER IS APPROACHING.

WARNING: DO NOT LOCATE THIS PRODUCT NEAR OPEN FLAMES. DO NOT USE THIS PRODUCT AS A SUPPORT. DO NOT SHAKE, LEAN OR CLIMB ON THE PRODUCT. CHILDREN UNDER THE AGE OF 10, NEAR THE PRODUCT, SHOULD BE SUPERVISED BY A COMPETENT ADULT AT ALL TIMES. THIS PRODUCT IS NOT INTENDED FOR COMMERCIAL USE AND WILL VOID THE WARRANTY.

READ ALL INSTRUCTIONS BEFORE USE

To reduce the risk of injury to persons:

1. Close supervision is necessary when this furnishing is used by or near children, or disabled persons, if applicable.
2. Use this furnishing only for its intended use as described in these instructions. Do not use attachments not recommended by the manufacturer.
3. Do not move the table while it is occupied. Failure to obey this caution could result in injury.
4. This table is not intended to support an umbrella. Umbrellas must have a suitable base or stand.

CAUTION: When not in use, secure the product in a cool and covered location.

CAUTION: Do not locate the product near any heat sources.

WARNING: Please keep children out of the assembly area before assembly.

WARNING: This table unit is heavy, and may require two adults for safe assembly.

WARNING: Never use this product as a support. Do not shake, lean, or climb on the product at any time.

WARNING: Do not place heavy objects on the table.

Warranty

1 YEAR FRAME WARRANTY

WHAT IS COVERED

We warrant the frames to be free of manufacturing defects to the original purchaser for one year.

WHAT IS NOT COVERED

It remains the customer's responsibility for freight and packaging charges to and from our service center. This warranty does not cover commercial use, hardware, acts of nature, fire, freezing and abusive use. In addition, purchased parts are not covered under this warranty. We reserve the right to make substitutions with similar merchandise, if the model in question is no longer in production.

Contact the Customer Service Team at 1-877-527-0313 or visit HOMEDEPOT.COM.

Pre-assembly

PLANNING ASSEMBLY

Read all instructions before assembly.
To avoid damaging this product, assemble it on a soft, non-abrasive surface such as carpet or cardboard.




NOTE: More than one person may be required to assemble this product.

Pre-assembly (continued)


HARDWARE INCLUDED

NOTE: Hardware not shown to actual size.



Part	Description	Quantity
AA	M6x25 Combination Bolt	8+1
BB	ST4.8x12 Screw	4+1
CC	Hex Wrench	1

PACKAGE CONTENTS




Part	Description	Quantity
A	Table Top	1
B	Table Leg	4
C	Leg Connector	1

Assembly


1 Attaching the Table Legs to the Table Top

- □ Place the table top (A) upside down on a soft surface.
- □ Attach the table legs (B) to the table top (A), as shown below.



2 Connecting the Leg Connector to the Table Legs

- □ Connect the leg connector (C) to the table legs (B) using M6x25 combination bolts (AA).
- □ Do not tighten all bolts at this step.




Please contact 1-877-527-0313 for further assistance.

Assembly (continued)

3 Secure the Table Top and the Table Legs

- □ Secure the table top (A) and the table legs (B) using ST4.8x12 screws (BB).



4 Checking the Table

- □ Once all of the bolts are in place, fully tighten all the bolts using the hex wrench (CC).
- □ Turn the table right side up.
- □ Ensure all connections are secure before use.



Care and Cleaning

- For best results, clean the frame with a damp cloth and dry thoroughly. This will help prevent mildew by removing dirt particles that may accumulate.
- Do not clean with abrasive materials, bleach or solvents.
- Store the table in a dry, sheltered place when not in use.
- Keep the table away from fire, extreme heat, freezing conditions, and inclement weather such as rain, hail, sleet, snow, or wind.

StyleWell™

Questions, problems, missing parts? Before returning to the store,
call StyleWell Customer Service
8 a.m. - 7 p.m., EST, Monday - Friday, 9 a.m. - 6 p.m., EST, Saturday

1-877-527-0313

HOMEDEPOT.COM

Retain this manual for future use.

For certification use only
Factory table ID # FTS61191