

TROUBLE SHOOTING

PROBLEM	CAUSE	SOLUTION
Heating element does not glow red	Stainless steel elements won't glow red to produce heat.	Heater is operating correctly
Do not feel heat or air flow	No power to heater	Check power connection to heater
	Desired room temperature reached.	Thermostat will shut off heater once desired room temperature is reached.
	Auto-Reset has tripped	Unplug heater allow to cool down for 10 minutes, then restart.
	Heater has fan only setting.	Set to run on full power for heating.

GUÍA DE SOLUCIÓN DE PROBLEMAS.

Problema	Causa	Solución
El elemento del calefactor no se ilumina de rojo.	El elemento del calefactor está hecho de acero inoxidable y no se iluminará de rojo al producir calor.	El calefactor está funcionando correctamente.
No se siente el calor o el flujo de aire.	No hay alimentación al calentador.	Compruebe las conexiones de energía/conecte el calefactor a una fuente eléctrica.
	La temperatura deseada de la habitación se ha alcanzado.	Termostato se apagará el calentador una vez que se alcanza la temperatura ambiente deseada.
	Auto-Reset se ha disparado.	Desenchufe el calentador deje que se enfríe durante 10 minutos, a continuación, reinicie
	Calentador tiene ventilador sólo configuración.	Ajuste para funcionar a máxima potencia para la calefacción