

JUMBO

Heavy-duty bungee cords

HDX

- **PREMIUM MATERIAL** - Premium braided yarn with all natural rubber core for an excellent elasticity and durability - **LASTS LONGER** than conventional bungee cords!
- **EXTRA WIDE HEAVY DUTY HOOKS** - Reinforced steel hooks with cord length indicator and plastic coating - protects from marks and scratches and holds twice as strong.
- **VERSATILE** - The wide opening hooks are designed to secure quickly and easily to a broad range of attachment points.
- **WIDE APPLICATION** - An essential tool for securing cargo and loads on cars, trucks, trailers, RVs, motorcycles, bicycles, and also ideal for outdoor use to secure camps, tents, tarps, canopies.

HOLDS STRONGER • LASTS LONGER Than conventional bungee cords!



WARNING: Read and observe all warnings carefully. Failure to do so could cause personal injury and damage to the user and other property.

1. Bungee cords should be stretched carefully. To avoid rebound, never exceed 50% of its original length. Example: a 24 in cord should be stretched no more than a total of 36 in, including hooks. Overstretching could cause hook failure resulting in a sudden uncontrolled release that could cause severe injury to unprotected body parts, especially eyes. Protective eyewear (that meets or exceeds ANSI safety standard Z87.1) should be worn when stretching or releasing bungee cords.
2. Keep face out of the direct path of a bungee cord in case it suddenly snaps back.
3. Do not use worn or frayed bungee cords or those with damaged hooks. Inspect all cords and hooks before each use.
4. Always attach the hook securely to a stable object.
5. Always keep cords away from sharp or rough edges. Damage of this sort may affect the integrity of the cord.
6. Always disconnect electric power sources before using cords on or around conductive metal. Cords are not shock resistant or insulated against electrocution.
7. Never use bungee cords on flat items that could rise with air pressure created while traveling. Tie-Down and anchor points must be checked every 25 miles.
8. Never use bungee cords or straps on any human or animal.
9. Keep bungee cords and plastic storage bags away from children at all times.
10. Use cords in a manner consistent with how they were designed and with good sense and safety.
11. When not in use, store cords in a safe, dry environment out of the reach of children.
12. Bungee cords will deteriorate through use and exposure to weather.
13. Secure hooks carefully. Do not attach hook by its tip.

ADVERTENCIA: Lea y cumpla todas las advertencias con mucho cuidado. Si no lo hace, puede provocar lesiones físicas o daños al producto y a la propiedad.

1. Debe estirar las cuerdas elásticas cuidadosamente. Para evitar que éstas reboten, nunca exceda el 50% de su longitud original. Ejemplo: una cuerda de 60 cm no se debe estirar más de 90 cm en total, incluidos los ganchos. Si estira demasiado las cuerdas, y las cuerdas pueden liberarse inesperadamente, lo que podría provocar lesiones graves a las partes del cuerpo sin protección, especialmente los ojos. Debe utilizar protector para ojos (que cumpla o excede la norma de seguridad Z87.1 de ANSI) cuando estire o suelte las cuerdas elásticas.
2. Mantenga a todas las personas alejadas del paso directo de una cuerda elástica cuando la esté utilizando para evitar que sean golpeadas por un gancho o una cuerda que rebote.
3. No use cuerdas elásticas gastadas o deshilachadas o que tengan ganchos dañados. Revise todas las cuerdas y ganchos cada vez que vaya a usarlos.
4. Siempre debe sujetar el gancho de modo que quede seguro y en un objeto firme.
5. Mantenga siempre las cuerdas alejadas de bordes afilados o ásperos. Este tipo de daños puede afectar la integridad de la cuerda.
6. Siempre desconecte las fuentes de alimentación eléctrica antes de utilizar las cuerdas en un metal conductor o alrededor de éste. Las cuerdas no son resistentes a descargas eléctricas ni protegen contra electrocución.
7. Nunca utilice las cuerdas elásticas en artículos planos que puedan elevarse con la presión del aire que se produce durante el viaje. Los amarres y los puntos de anclaje se deben revisar cada 40 km.
8. Nunca utilice cuerdas o correas elásticas en personas o animales.
9. Siempre mantenga las cuerdas elásticas y las bolsas plásticas fuera del alcance de los niños.
10. Utilice las cuerdas según los objetivos para los que fueron diseñadas, además de usarlas con sentido común y en forma segura.
11. Cuando no las utilice, guárdelas en un lugar seco y seguro, fuera del alcance de los niños.
12. Las cuerdas elásticas son consumibles. Se deteriorarán debido al uso y a las condiciones climáticas.
13. Asegure firmemente los ganchos. No los enganche solamente por la punta.