Comfort Zone®
America's Heating and Cooling Choice

CZHV201 Series

POWR CURVE™ TECHNOLOGY

POWR CURVE TECHNOLOGY with its 6-blade fan design has 30% higher airflow for maximum cooling.

The TRIPLE-ZONE tri-curve grille eliminates turbulence for a stronger airflow with 20% less noise!*

*Note: Compared to a non-curved fan grille
Patent Pending



20″ Turbo Performance Fan

Features:

- 2-In-1 Fan Design: Floor or Wall-Mountable
- On/Off Control Dial with 3 Speed Settings
- Tri-Curve Plastic Safety Grille
- 6 Fan Blades
- Adjustable Tilt Head
- 120V A.C. / 60Hz

C ETL US LISTED Intertek

INTENDED USE:

This product is intended for indoor residential and office use only, not for industrial or other commercial applications. Use only with electrical wiring that is in good working order and that meets applicable codes and ordinances. If you have any questions whether your wiring is adequate, consult a qualified electrician.

While using your fan, you should follow the IMPORTANT INSTRUCTIONS listed below. As part of those instructions, we have used the word **"WARNING"** to indicate the level of hazard: **WARNING** indicates a hazard which, if not avoided, could result in injury or death

IMPORTANT INSTRUCTIONS

As with all electrical appliances, basic safety precautions should always be followed to reduce the risk of electric shock, fire, or injury to persons, including the following precautions:

- Read all the instructions before using this fan.
- Use this fan only as described in this manual. Any other use not recommended by the manufacturer may cause electrical shock, fire or injury to persons.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.
- Use of extreme caution is necessary when any fan is used by or near children, disabled persons or pets and whenever the fan is left operating unattended.
- Do not place the fan on a small, unlevel, uneven or any surface which might allow fan to tip or fall.
- For proper operation, fan should be placed on a smooth, non-combustible, level surface.
- Always unplug fan when not in use, when moving from place to place, when assembling or disassembling parts, and before cleaning.
- The use of attachments, not recommended or sold by the manufacturer, may cause hazards.
- Do not use outdoors.
- Do not use fan in window. Rain may cause electrical hazard (for non-window models).
- Do not operate the fan with blade guards or any safety device removed.
- Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts.
- Do not run power cord under carpeting. Do not cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over.
- Do not insert or allow any object to enter any openings on the fan. Doing so may cause electric shock and/or fire hazard. Avoid contact with moving parts.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure they do not play with the appliance.

⚠WARNING: ***SHOCK HAZARD***

Use your fan only in dry environments. This fan is not intended for use in a bathroom, laundry area, or similar locations, or near sinks, washing machines, swimming pools or other sources of water. Never locate fan where it may fall into a bathtub or other water receptacle. DO NOT use in damp environments such as flooded basements.

⚠WARNING: ***HOT SURFACES***

DO NOT touch fan motor when in use. This motor is hot when in use, to avoid burns, do not let bare skin touch hot surfaces.

⚠WARNING: ***FIRE HAZARD***

Fans have arcing or sparking parts inside. DO NOT use near combustible materials or flammable gases or sources of heat. DO NOT use in areas where gasoline, paint or flammable materials are used or stored. To prevent a possible fire, do not block air intakes or exhaust in any manner. DO NOT insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock, fire, or damage the fan.

⚠WARNING: ***ELECTRICAL SHOCK HAZARD***

DO NOT use with damaged cord or plug. Use with adequate electrical system that is up to code. DO NOT use this product with any solid-state speed control device.

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. DO NOT attempt to defeat this safety feature.


⚠WARNING: ***TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK,*** DO NOT operate any heater with a damaged cord or plug or after heater malfunctions, has been dropped or damaged in any manner. DO NOT operate heater with a broken heating element or ceramic cone or any visual imperfections. For repairs covered under warranty, see warranty statement. For all other repairs contact Comfort Zone® Customer Service by telephone or mail for information and assistance.

DO NOT run power cord under carpeting. DO NOT cover cord with throw rugs, runners or the like. Arrange cord away from traffic area where it will not be tripped over. Avoid the use of extension cords due to risk of fire. If an extension cord must be used, the cord must be minimum 14 AWG and rated not less then 1875 watts. DO NOT use an extension cord unless the plug can be completely inserted into its receptacle. Unplug the fan when not in use. DO NOT operate fan with its ventilation obstructed.

READ & SAVE THESE INSTRUCTIONS

PARTS IDENTIFICATION

1. Fan blades (mobile parts)
2. Safety grille
3. Fan Base
4. Head position adjusting knobs
5. Operation/Speed control panel
6. Cord winder




WALL MOUNTING

This fan comes with a wall mounting option.

NOTE: It is not recommended to install the wall support attachment on prefabricated walls or unstable walls. The fan should be level when mounted and at least one of the two mounting screw locations should be a wall stud.

1. Using a 1/4-inch drill bit (not included) make two holes horizontally aligned with 17.7 inches of separation between them into the wall (See Fig 1).
2. Insert in a 1/4-inch plastic dowel (included) into each hole. Next, insert in each plastic dowel a 1/64-inch x 1-inch screw (included) no more than 0.8 inches deep.
3. Insert the screw into the hole in the base and tighten. Mount the fan on the wall and make sure it is properly set.

Fig. 1



USAGE

Fan Operation: Always operate the fan on a stable surface. Do not set on a rug, over furniture, on an uneven floor or on a fabric surface. Always follow all instructions and recommendations listed in this manual.

Fan Location: Place the fan in the area of the room that will provide proper fan cooling. Do not set your fan closer than 4 inches from any surface such as the wall, curtains or any furniture which could block the air flow.

Fan Connection: Make sure the fan is in the OFF position on the control panel before plugging in. Plug the fan directly into 120 volt A.C., 60Hz wall outlet. Be sure plug fits tightly into the outlet. A loose connection may cause overheating and damage to the plug or fan.

Note: To prevent overloading a circuit, do not plug the fan into a circuit that is servicing other electrical needs.

Turning Fan On/Off: To start the fan, rotate the Control Dial from the OFF position to the desired fan speed: LOW, MEDIUM or HIGH (0-OFF, 1-Low, 2-Medium, 3-High). Rotate the dial to OFF to discontinue use. Unplug the fan when not in use.

CARE AND MAINTENANCE

Cleaning: CAUTION-Before cleaning the fan be sure to disconnect power cord from the plug. Clean the grille surface with a clean damp cloth. Do not use harsh chemical or abrasive cleaners. DO NOT IMMERSE THE FAN OR ANY WIRES IN WATER. Replace front grille before fan use. Allow fan to dry completely before use. Periodic grille cleaning with a vacuum will prevent dust build up. The motor is sealed and does not require any interior maintenance, cleaning or lubrication.


Periodic grille cleaning with a vacuum will prevent dust build up:

1. Using a screwdriver, unscrew the screws on the side of the front grille. (See Fig 2 and 3).
2. Use a screwdriver to remove the front grille.
3. Clean the fan blades with a soft, lightly wet soapy cloth.
4. Replace the front grille so that the locks match their respective joints in the back grille. Replace the screws and lower all the locks by pressing to complete the assembly. Wait until the fan is completely dry before operating again .

Fig. 2



Fig. 3



Maintenance: The internal motor bearings are permanently lubricated at the factory and do not require any additional lubrication.

Repair: DO NOT OPERATE THE FAN WITHOUT THE GRILLE IN PLACE. DO NOT USE THE FAN IF IT HAS MALFUNCTIONED OR BECOME DAMAGED IN ANY WAY.

Storage: Keep original carton for storage of the fan. Coil and tie the power cord to avoid damage during storage.

SAFETY FUSE

This product employs overload protection (fuse). A blown fuse indicates an overload or short-circuit situation. If the fuse blows, unplug the product from the outlet. Replace the fuse as per the user servicing instructions (follow product marking for proper fuse rating) and check the product. If the replacement fuse blows, a short-circuit may be present and the product should be discarded or returned to an authorized service facility for examination and/or repair.

Fuse Replacement:

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on cord.
2. Open fuse cover by sliding open fuse access cover on top of attachment plug towards blades (See Fig. 2).
3. Remove fuse carefully. Use a small tool to pry the end of the fuse from holder cavity. Be careful not to break glass window.
4. Replace fuse. WARNING: Risk of fire. Replace fuse only with identical 2.5 or 5.0 Amp, 125-volt fuse (3.6mm x 10mm). Be sure fuse is properly seated within its cavity.
5. Close fuse cover by sliding it back to its original closed position.

Fig. 1





Fig. 2



Fig. 3



LIMITED WARRANTY

This unit is guaranteed to the original retail purchaser against defects in quality or workmanship for a period of one year from the date of original purchase. If this unit fails because of a manufacturing defect within 30 days of purchase, return the unit, with your receipt, to the retailer. After 30 days, but within the warranty period, if the unit was purchased within the continental United States, return it, freight prepaid, to World and Main for repair or replacement. If the unit was purchased outside the continental United States, return the unit to the place of purchase. This warranty does not cover damage caused by misuse, abuse, overheating or alteration. Repairs made by anyone other than World and Main are not covered in this warranty. World and Main will not be held liable for any losses due to neglectful operation. All implied warranties, including the warranties of merchantability and of fitness of purpose, if applicable, are hereby limited in duration to the period of one year from the date of original retail purchase. Some states do not allow limitations on how long an implied warranty lasts, so the above limitations may not apply to you. Incidental or consequential damages arising from a breach of either express or implied warranties are hereby disclaimed and excluded. Some states do not allow the exclusion of limitation of incidental or consequential damages, so this limitation or exclusion may not apply to you. Upon the expiration of this warranty all such liability will terminate. No other warranties are expressed or implied.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. No informal dispute settlement mechanisms are available. This limited warranty is given in lieu of all other warranties.

Manufactured for:
World and Main (Cranbury), LLC
324A Half Acre Rd.
Cranbury, NJ 08512 USA
800-221-6895

www.comfortzoneproducts.com

Rev. 04/16/2021