ANIMATED AIRBLOWN® INSTRUCTIONS

⚠ WARNING: READ AND UNDERSTAND ALL INSTRUCTIONS.

Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

⚠ **WARNING:** ELECTRIC PRODUCT. Keep away from children. Not recommended for children under 3 years of age. As with all electrical products, precautions should be observed during handling and use to reduce the risk of electric shock. If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard. To avoid the risk of electrical shock, always make sure the figure is unplugged from the electrical outlet before assembling, disassembling, or relocating.

⚠ **WARNING:** This product is to be assembled by adults only.

IMPORTANT SAFETY INSTRUCTIONS WHEN USING ELECTRICAL PRODUCTS, BASIC PRECAUTIONS SHOULD ALWAYS BE FOLLOWED, INCLUDING THE FOLLOWING:

READ AND FOLLOW ALL SAFETY INSTRUCTIONS

1. This is an electrical product - not a toy! To avoid risk of fire, burns, personal injury, and electric shock, it should not be played with or placed where small children can reach it.
2. Do not use seasonal products outdoors unless marked suitable for indoor and outdoor use. When products are used in outdoor applications, connect the product to a Ground Fault Circuit Interrupting (GFCI) outlet. If one is not provided, contact a qualified electrician for proper installation.
3. This seasonal use product is not intended for permanent installation or use.
4. Do not mount or place near gas or electric heaters, fireplaces, candles, or other similar sources of heat.
5. Do not secure product wiring with staples or nails or place on sharp hooks or nails.
6. Do not let lamps rest on the supply cord or on any wire.
7. Unplug the product when leaving the house, when retiring for the night, or if left unattended.
8. Do not use this product for other than its intended purpose.
9. Do not hang ornaments or other objects from cord, wire, or light string.
10. Do not close doors or windows on the product, or extension cords, as this may damage the wire insulation.
11. Do not cover the product with a cloth, paper, or any material not part of the product when in use.
12. Do not place the product against carpeting, furniture, or any other fabric when in use.
13. This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If the plug still does not fit, contact a qualified electrician. Do not use an extension cord unless the plug can be fully inserted. Do not alter or replace the plug.
14. This product employs overload protection (fuse). A blown fuse indicates an overload or a short-circuit condition. If the fuse blows, unplug the product from the outlet. Also unplug any additional string or products that may be attached to the product. Replace the fuse as per the user servicing instructions (follow product markings for proper fuse rating) and check the product. If replacement fuse blows, a short-circuit may be present and the product should be discarded.
15. Read and follow all instructions that are on the product or provided with the product.

SAVE THESE INSTRUCTIONS

USE AND CARE INSTRUCTIONS

1. When the product is placed on a live tree, the tree should be well maintained and fresh. Do not place on live trees in which the needles are brown or break off easily. Keep the tree holder filled with water.
2. If the product is placed on a tree, the tree should be well secured and stable.
3. Before using and reusing, inspect the product carefully. Discard any products that have cut, damaged or frayed wire insulation cords, cracks, lamp holders or enclosures, loose connections, or exposed copper wire.
4. When storing the product, carefully remove the product from wherever it is placed, including trees, branches, or bushes, to avoid any undue strain or stress on the product conductors, connections and wires.
5. When not in use, store neatly in a cool, dry location protected from sunlight.

Congratulations! You're the proud owner of a Gemmy Animated Airblown® Inflatable. Please read over the directions carefully before using your Gemmy Animated Airblown® Inflatable.

CONTENTS

Animated Airblown® Inflatable Unit	1 piece
Nylon Tethers	4 pieces
Base Stakes	4 pieces
Tether Stakes	4 pieces
Extra C-7 Light Bulb	1 piece
5 Amp, 125V Fuse	1 piece

GENERAL INSTRUCTIONS

1. Remove contents from packaging. Lay out deflated Animated Airblown® Inflatable in a clear area.
2. Locate four clips on the bottom of the fabric and attach to the plastic legs (See illustration 1).



illustration 1

3. Turn unit upright. Make sure the air intake is clear of fabric or other obstruction and all zippers are fully closed.
4. Insert the base stakes through the legs into ground. (See illustration 2).



illustration 2

5. Plug into receptacle or other outlet device to inflate your Animated Airblown® Inflatable.
6. Once fully inflated, clip the tethers to each of the nylon loops on the side of the Animated Airblown® Inflatable (See illustration 3).



illustration 3

7. Insert the stakes into the ground and attach the tethers (See illustration 4).
8. To deflate, unplug fan. For faster deflation, unzip zipper on bottom after unplugging fan. Do not unplug by pulling on cord.



illustration 4

USER SERVICING INSTRUCTIONS

Lamp Replacement:

Disconnect the plug from the electrical outlet and allow the lamp to cool completely before replacing bulb. Do not touch the bulb when the power is "ON" as it is extremely hot and make cause electrocution.

1. Grasp plug and remove from receptacle or other outlet device. Do not unplug by pulling on the cord.
2. Open the zipper opening on the Animated Airblown® Inflatable.
3. Open the protective light cover carefully by pressing down on the two locking side tabs simultaneously.
4. Replace lamp with same type 7W maximum, candelabra base, UL classified.
5. Do not over-tighten the lamp as this may damage the lamp or lamp holder.

Replace only with same type C7, 7 Watt Max Candelabra-base 120 Volt UL Classified lamps.

CAUTION

Fuse Replacement

WARNING: **Risk of Fire:** Replace only with same size and type of fuse.



WARNING: **Risk of Fire:** Do not replace the attachment plug. Contains a safety device (fuse) that should not be removed. Discard product if attachment plug is damaged.

1. Grasp plug and remove from the receptacle or other outlet device. Do not unplug by pulling on the cord.
2. Open fuse cover. Slide open the fuse access cover on top of the attachment plug towards blades. (See illustration)
3. Remove fuse carefully.
4. Replace fuse only with 5 Amp Max, 125 Volt fuse (provided with product)
5. Close the fuse cover. Slide closed the fuse access cover on top of the attachment plug.

CAUTION

To reduce the risk of fire do not deliberately reposition either lamp holder contact.

Do not attempt to inflate your Animated Airblown® Inflatable during unusually strong winds. If it becomes too windy for safe operation, simply allow your Animated Airblown® Inflatable to deflate and wait for better conditions before re-inflating.

Protect the electric fan and power cord from direct exposure to water. This precaution will reduce the risk of electrical shock. When the temperature is below 14° F (-10° C), the motor may temporarily stop running. The motor will begin functioning again higher temperatures.

WARNING

Remove all plastic fasteners and tags. These are part of the packaging and should be discarded.

This item is not a toy and should be used for decorative purposes only.
For indoor and outdoor use.
120 V 60 Hz.

TROUBLE SHOOTING CHECKLIST

If your Animated Airblown® Inflatable is not inflating, the problem may be:
1. The power source is disabled or the cord may be unplugged.
2. Debris may be lodged in the motor.
3. The zipper may not be securely fastened, sealing the Animated Airblown® Inflatable.
4. The temperature may be below 14° F (-10° C).
5. Heavy rain or snow may have weighed down the unit. Unplug unit, remove any water or snow from inside fabric folds.

NOTE: ONCE FAN IS UNPLUGGED AND STOPS BLOWING, YOUR Animated Airblown® Inflatable WILL DEFLATE.

FREQUENTLY ASKED QUESTIONS (FAQ's)

1. Can I continually run my Animated Airblown® Inflatable?
Yes, you can run your Animated Airblown® Inflatable during the day and at night. We recommend that you turn off your Animated Airblown® Inflatable when leaving the immediate area and when retiring for the evening. Otherwise, your Animated Airblown® Inflatable is designed to run continually as you see fit.

2. What happens if my Animated Airblown® Inflatable becomes torn?
Rips in the Animated Airblown® Inflatable can be sewn by hand (no special thread is required) or taped with clear packing tape.

3. How can I clean my Animated Airblown® Inflatable?
Wipe clean with a damp cloth and allow to dry before storing away. Use mild detergent if necessary.

4. When I unplug my Animated Airblown® Inflatable, it deflates. Why is this?
Your Animated Airblown® Inflatable will not stay inflated unless it is plugged in and the fan is blowing air.

5. My Animated Airblown® Inflatable isn't moving. What can I do?
It is possible for the action components within your Animated Airblown® Inflatable to become slightly tangled. If there is no action, attempt to straighten your Animated Airblown® Inflatable to remove wrinkles and folds. Also, re-check all zippers to insure they are fully closed. Lastly, recheck the outlet, unplug and plug in again to insure it is properly plugged in. If this does not work, please contact Gemmy's Customer Service Department.

6. I see holes in the inside bottom of my Animated Airblown® Inflatable, what are these for?
These holes are designed to allow water collections to escape in the event of rain.

7. How much electricity does an Animated Airblown® Inflatable consume?
Please refer to the electrical approval label for wattage.

8. What is the best way to store my Animated Airblown® Inflatable?
Store in a bag, box or other storage container and keep in a cool, dry location.

9. Can I leave my Animated Airblown® up in extreme weather conditions or freezing temperatures?
We do recommend the consumer take appropriate precautions to protect the unit. The Animated Airblown® will operate at temperatures below freezing, but we do not recommend operating the Animated Airblown® if temperatures drop below 14° F (-10° C).

10. What if it is raining or snowing? Will this affect my Animated Airblown®?
Operation of your Animated Airblown® during light weather conditions, such as a gentle rain or snowfall is recommended. However, operation of your Animated Airblown® during extreme weather conditions is not recommended, as your item may become damaged or inundated with moisture. Do not store the Animated Airblown® when it is wet.

11. What if water has soaked my unit while unplugged?
Move the unit to a dry location and plug in the unit. The fan will dry the Animated Airblown®.

12. My Animated Airblown® has been deflated and it is covered with snow. Can I simply re-inflate it?
If your Animated Airblown® is covered in a light dusting of snow, simple re-inflation should not harm the unit. However, if the deflated unit has been subjected to a large amount of snow and/or ice, do NOT attempt to re-inflate. Rather, carefully remove the item from the extreme condition (i.e. bring it indoors) and allow the unit to thaw before re-inflating. This helps prevent cracks and/or tears in the materials.

13. What if it's raining or snowing? Will this affect my Animated Airblown®?
Operation of your Animated Airblown® during light weather conditions, such as a gentle rain or light snowfall is fine. However, operation of your Animated Airblown® during extreme weather conditions such as heavy snow, rain or windstorms is not recommended as it may become over-weighted and damage the unit.

THESE INSTRUCTIONS ARE FOR THESE ITEMS

23623	23881	24717	26345	26517	60208	60934
62145	62396	62466	62731	62744	62779	62930
62944	62994	63199	63338	63529	63532	63596
63599	63656	63720	63739	63790	82952	84511
85098	85153	85770	85932	85936	85939	85962
85964	85974	85984	86022	86090	86105	86143
86207	86232	86232	86235	86235	86252	86271
86272	86272	86274	86512	86515	86569	86768
86929	86933	86945	86947	86948	86950	86972
87073	87158					

Visit WWW.GEMMY.COM ***for more information.***
©2012 GEMMY INDUSTRIES CORP.
117 WRANGLER DRIVE. SUITE 100
COPPELL, TX 75019 U.S.A.
(972) 961-7000
MADE IN CHINA / PRINTED IN CHINA