WIDTH
54.8
INCHES

HEIGHT
40.3
INCHES



DEPTH
25.1
INCHES

LoCo®
COOKERS

WEIGHT
92.5
POUNDS

GRIDDLE TOP CAPACITY

24	78	24	12	28	12
BURGERS	HOTDOGS	EGGS	PANCAKES	BACON STRIPS	STEAKS



GRIDDLE TOP AREA & POWER

HEAT CONTROLS
2 ZONES

COOKING SURFACE
482
SQUARE INCHES

MAX OUTPUT
32,000
BTUS

LOCO

LIGHTING INSTRUCTIONS:
1. Read all instructions before lighting.
2. Open lid during lighting.
3. Push in and turn control knob to **LOW / 300F-500F / SEAR**.
4. Press and hold ignition switch until burner is lit.
5. Adjust control knob to desired temperature.
6. If ignition does not occur in 5 seconds, turn the burner control to **OFF**, wait 5 minutes, and repeat the lighting procedure.

INSTRUCTIONS D'ÉCLAIRAGE :
a) Lisez toutes les instructions avant d'allumer l'ap
b) Ouvrez le couvercle avant d'allumer l'appareil.
c) Si l'appareil ne s'allume pas en 5secondes, fermer le robinet du brûleur, attendre 5 minutes, et procéder de nouveau à l'allumage.

SureSpark
Electronic Ignition

Attached hood protects griddle surface

Integrated handle easily moves cart

XL Grease Catch
Built-in and oversized

SmartTemp™
Set your precise cooking temperature & it Stays Where Set



Cold Rolled Steel Cooktop

Side Shelf for Prep Space

Accessory Hooks hang your griddle tools

Upper & Lower Tank Support

Two Oversized Wheels

SureSpark®
Electronic Ignition Switch

LoCo® COOKERS GRIDDLE GEAR

Must have accessories, tools & more

Accessories not included.



5 PC Griddle Tool Set

322732536



Griddle Cover

329645408





Griddle Burger Kit

322732540







Griddle Cleaning Kit

322732542







Griddle Breakfast Kit

322732544