1 add rice

Use the cup provided to add rice (min 0.5 cup - max 1.5 cups) to mini rice cooker. Rice amount will double once cooked.

2 rinse & drain (optional)

To reduce starch, rinse and drain the rice until water is clear.

3 add water

Use the waterline as reference to add water properly. (i.e. for 0.5 cup of rice, add water to 0.5 cup waterline)

*Note: When cooking max capacity (1.5 cups) please make sure rice and water will not exceed the 1.5 cup water line.

4 select white or brown rice to cook

Press WHITE or BROWN rice to cook. Mini rice cooker indicator light will automatically switch to WARM when ready.

one-pot pasta

Ingredients:
1 cup pasta
(elbow macaroni, bow tie or corkscrew pasta)
1⅓ cup liquid (water or chicken broth)
½ cup pasta sauce
½ cup cheese of your choice
Basil leaves for garnish (optional)

Directions:
1. Combine all ingredients except the cheese, in the cooking pot.
2. Lock lid and press WHITE RICE to cook.
3. When cooker switches to WARM, open lid and stir in the cheese. Leave it on WARM for 5 minutes.
4. Serve hot and garnish with basil leaves.

*NOTE: Always use cup provided when adding ingredients.

easy omelette

Ingredients:
2 eggs,
1 slice turkey breast meat, chopped,
1 small tomato, chopped,
½ cup spinach,
½ cup shredded cheese,
Pinch of salt and pepper

Directions:
1. Combine all ingredients, mix well and pour into the cooking pot.
2. Lock lid and press WHITE RICE to cook.
3. When cooker switches to WARM, open lid and stir. Press down switch again.
4. Ready to serve when cooker switches to WARM again.

*NOTE: Always use cup provided when adding ingredients.

Questions or concerns about your Aroma mi™ Rice Cooker?

Before returning to the store: Aroma's customer service experts are happy to help. Call 1.800.276.6286 or e-mail us at CustomerService@AromaCo.com

20. Rice should not be left in the inner cooking pot with the WARM function on for more than 8 hours.
21. To prevent damage or deformation, do not use the inner cooking pot on a stove top or burner.
22. To disconnect, turn control to OFF, then remove the plug from the wall outlet.
23. To reduce the risk of eletrical shock, cook only in the removable inner cooking pot provided.

Short Cord Instructions

1. A short power-supply cord is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord.
2. Longer extension cords are available and may be used if care is exercised in their use.
3. If a longer extension cord is used:
   a. The marked eletrical rating of the extension cord should be at least as great as the eletrical rating of the appliance.
   b. The longer cord should be arranged so that it will not drape over the counter top or tabletop where it can be pulled by children or tripped over unintentionally.

Polarized Plug

This appliance has a **polarized plug** (one blade is wider than the other); follow the instructions below:
To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit fully into the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way. If the power cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified person in order to avoid a hazard.

THIS APPLIANCE IS FOR HOUSEHOLD USE ONLY

miAROMA
pronounced: |mē ə'rōmə|
it's minimalist.
it's mini.
it's mi.

Troubleshooting?

Visit
www.AromaCo.com
or Call
1-800-276-6286
M-F, 8:30AM - 4:30PM, Pacific Time

mini
rice cooker
MRC-903D

AROMA™
User Manual

a meal for you,
a meal for two.

"IMPORTANT SAFEGUARDS"

Basic safety precautions should always be followed when using electrical appliances, including the following:

1. Important: Read all instructions carefully before first use.
2. Do not touch hot surfaces. Use the handles or knobs.
3. Use only on a level, dry and heat-resistant surface.
4. To protect against fire, eletctric shock and injury to persons, do not immerse cord, plug or the appliance in water or any other liquid. See instructions for cleaning.
5. Close supervision is necessary when the appliance is used by or near children.
6. Unplug from outlet when not in use and before cleaning. Allow unit to cool before putting on or taking off parts and before cleaning the appliance.
7. Do not operate any appliance with a damaged cord or plug. Especially after the appliance malfunctions or has been damaged in any manner. Contact Aroma® customer service for examination, repair or adjustment.
8. The use of accessory attachments not recommended by Aroma® Housewares may result in fire, electrical shock or injury.
9. Do not use outdoors.
10. Do not let cord touch hot surfaces or hang over the edge of a counter or table.
11. Do not place on or near a hot gas, electric burner or in a heated oven.
12. Do not use the appliance for other than its intended use.
13. Extreme caution must be used when moving the appliance containing rice or other hot liquids.
14. Do not touch, cover or obstruct the steam vent on the top of the rice cooker, as it will be extremely hot and may cause scalding.
15. Use only with a 120V AC power outlet.
16. Always unplug from the base of the wall outlet. Never pull on the cord.
17. The rice cooker should be operated on a separate electrical circuit from other operating appliances. If the electrical circuit is overloaded with other appliances, the appliance may not operate properly.
18. Always make sure the outside of the inner cooking pot is dry prior to use. If the inner pot is returned to the cooker when wet, it may damage or cause the product to malfunction.
19. Use extreme caution when opening the lid during or after cooking. Hot steam will escape and may cause scalding.

"SAVE THESE INSTRUCTIONS"