Use and Care Manual

Opening and assembling: Follow the steps in the guide to open and assemble the camping chair step by step. Ensure that all components are properly installed for safe use.

Use: Please use the camping chair on a flat, hard ground, avoid using it on slopes, soft soil or uneven ground.

Load-bearing restrictions: Do not overload the camping chair. Use it according to the prescribed weight limit to prevent damage.

Cleaning: Clean camping chairs regularly, We suggest wipe it off with a towel or clean with soap and water. Avoid chemical cleaners.

Inspection and maintenance: Check the components of the camping chair regularly. If there is damage or loose, please repair or replace it in time.

Storage: When not in use, store the camping chair in a dry, ventilated place, away from direct sunlight and humidity.