INSTRUCTIONS

Install a **Quick Door Hanger** bracket directly behind the center of each hinge with the ½" screws (provided), make sure the bracket's clearance hole lines up directly behind one of the center screws of each hinge (FIG A). Install the other three **Quick Door Hanger** brackets directly across from the hinges on the opposite side of the door (FIG B).

Using a 6' or 4' level, draw a "LEVEL" line all the way down the drywall approximately ½" in from the rough opening on the hinge side. Must be a "LEVEL" line.

Place the door into the opening. Starting with the top bracket on the hinge side of the door, line up a reference notch on the bracket with the level line that was drawn in step 2 (FIG C). Screw into place using drywall screw. Use the same reference notch when screwing in the next 2 brackets on the hinge side. Door is now perfectly level. Screw in the remaining 3 brackets on the latch side, starting on the top, make sure the reveal (gap between door and door frame) stays the same. Check door operation. For added support, remove a center screw from each of the hinges and replace with a long set screw (2"or longer) that goes through the hinge, bracket clearance hole, and into the wall stud.* Trim/Casing can now be installed directly over brackets to complete installation.

* Note: Before the installation of the trim/casing and long hinge screws, you will notice the door can be slightly moved by bending the brackets, this is not a defect, this is to accommodate any imperfections in the wall, if needed. **This movement will go away** after the installation of the trim/casing, resulting in a very strong, sturdy, professional door installation.



These instructions are for interior pre-hung doors. For installation instructions without drywall yet installed, or other types of doors using these brackets (Exterior, Double/French, Split-jamb, slab), visit us at: www.TheQuickDoorHanger.com





