



## Synthetic Bamboo / PVC Fence Panel Installation Guide

This guide explains how to install Backyard X-Scapes synthetic bamboo or PVC fencing panels onto an existing support structure using zip ties. Suitable for wood fences, metal fences, railings, and similar frames.

### Tools & Materials Needed

- Synthetic bamboo / PVC fencing panels
- UV-resistant outdoor zip ties (included)
- Measuring tape
- Level (optional)
- Scissors or zip-tie cutter
- Work gloves (recommended)

### Installation Steps

- **1. Prepare the Surface:** Ensure the existing fence or structure is clean, stable, and free of sharp edges.
- **2. Position the Panel:** Hold the panel against the support structure. Use a level if desired.
- **3. Secure with Zip Ties:** Thread zip ties through the panel and around the support. Start at the top corners.
- **4. Evenly Space Fasteners:** Add zip ties every 12–18 inches along the top, middle, and bottom.
- **5. Adjust & Tighten:** Align the panel, then tighten zip ties snugly. Do not over-tighten.
- **6. Trim Excess:** Cut off extra zip-tie ends for a clean finish.

### Optional Tips for Best Results

- Use brown or tan UV-resistant zip ties for a discreet appearance
- Do not over-tighten; allow for natural expansion and contraction
- In high-wind areas or for larger panels, add extra zip ties for support

Designed for outdoor use. Periodically check fasteners and re-tighten if needed. Backyard X-Scapes panels are engineered to perform in hot summers and freezing winter conditions.