

## VOLM'S EZ Privacy Screen Installation Guide:

**Step 1:** Remove the EZ Privacy Screen from the packaging

**Step 2:** Determine your fence starting point and unroll the EZ Privacy Screen along the fence line

**Step 3:** Using whatever fastener you prefer (not included), thread the fastener through the integrated buttonhole and attached the top corner of the mesh to the top horizontal fence frame.

**Step 4:** Continue down the fence line, attaching the EZ Privacy Screen to the top horizontal fence frame by slightly stretching the fence in order to pull out any creases in the mesh.

**Step 5:** When top frame is complete, start over by attaching the EZ Privacy Screen to the bottom horizontal fence frame, and continue down the fence line.

**Step 6:** Inspect all fastener to be sure they are secure.

**Step 7:** If you need to connect another extension on to the fence; you can do so by lining up the side panels and fastening them together to link from one piece of screen to the next length wise.

**Step 8:** In order to complete the installation, at the beginning and the end of your fence line, cut the EX Privacy Screen with a pair a scissors to the desired length. *Please note, EZ Privacy Screen is made with a Lock Stich construction and will not fray when cut.* Attach the Mesh to the vertical fence frame every 6-8 inches to make a neat and secure fit.