

How to make Sound Absorbing Panels more Firmly

1. Please press the sound insulation cotton as hard as possible, and press the adhesive surface of the sound insulation cotton and various positions of the wall.
2. Clean the dust on the wall in advance. They will stick to the wall and stick firmly.