
Item #1004489664 Model #SK19346Ar2-B-1

Item #1004489673 Model #SK19346Ar2-W-2 Item #1004489665 Model #SK19346Ar2-B-2

USE AND CARE GUIDE

TWO TONE DESK WITH HUTCH



Questions, problems, missing parts? Before returning to the store, call Home Decorators Collection Customer Service.

8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-998-7021

HOMEDEPOT.COM/HOMEDECORATORS

THANK YOU

We appreciate the trust and confidence you have placed in Home Decorators Collection through the purchase of this two tone desk with hutch. We strive to continually create quality products designed to enhance your home. Visit us online to see our full line of products available for your home improvement needs. Thank you for choosing Home Decorators Collection!

Table of Contents

Table of Contents	2
Safety Information	
Warranty	
3 Year Warranty	2
What is Covered	
What is Not Covered	
Pre-assembly	3
Planning Assembly	
Tools Required	

Hardware Included	3
Pre-assembly (continued)	4
Package Contents	
Assembly	5

Safety Information



DANGER

- Keep small parts away from children during assembly.
- Read and follow instructions carefully.



WARNING

- Read these instructions carefully and keep in a safe place.
- TO GUARANTEE THE SAFE USE OF THIS PRODUCT, FOLLOW THE WARNINGS, GUIDELINES AND RECOMMENDATIONS IN THIS MANUAL.
- Adult assembly required.
- □ Small parts may present choking hazard prior to assembly.
- Do not place heavy objects on the glass top.
- □ Some assembly may involve attaching glass or mirrors.
- Be very careful handling the glass or mirrors, as severe injury may result if the glass or mirror breaks.
- □ Never handle large pieces of glass or mirrors by yourself.



CAUTION

- Do not use power tools to assemble your furniture. Power tools may strip or damage parts/product.
- Do not overtighten connectors (screws, bolts, etc.).
 Overtightening can lead to product damage.
- Be sure to check all packing materials carefully for small parts that may have come loose inside the carton during shipment. If parts are missing, contact THE HOME DEPOT to obtain any missing parts.
- DO NOT USE SUBSTITUTE PARTS.
- This product should only be used on a flat, level surface.

Warranty

3 YEAR WARRANTY

WHAT IS COVERED

We guarantee this product to be free of manufacturing defects to the original purchaser for three years.

WHAT IS NOT COVERED


This warranty does not cover commercial use, acts of nature, and abusive use.

Pre-assembly


PLANNING ASSEMBLY

Keep children and pets away from build area. Make sure your area is large enough to unpack, sort and assemble the unit.

TOOLS REQUIRED




HARDWARE INCLUDED



Part	Description	Quantity
AA	Wood dowel	52
BB	Cam lock bolt	34
CC	Cam lock	34
DD	Long plastic cover	8
EE	Short plastic cover	4
FF	Stopper	2
GG	1 in.Flat head screw	43
НН	1-1/2 in.Flat head screw	2
II	Handle	3
JJ	Handle bolt	6

Part	Description	Quantity	
KK	5/8 in.Round head screw	46	
LL	Metal plate	6	
MM	Wire plug	1	
NN	Bolt	6	
00	Washer	6	
PP	Spring washer	6	
QQ	Allen wrench	1	
RR	Anti-tipping hardware package	1	

Pre-assembly (continued)




Part	Description	Quantity
Α	Hutch top panel	1
В	Hutch left side panel	1
С	Hutch right side panel	1
D	Top crossbar	1
E	Hutch fixed panel	1
F	Hutch left partition	1
G	Hutch right partition	1
Н	Hutch bottom panel	1
I	Middle crossbar	1
J	Desk face panel	1
K	Bottom left side panel	1
L	Bottom right side panel	1
М	Bottom left partition	1
N	Bottom right partition	1

Part	Description	Quantity		
0	Bottom fixed panel	1		
Р	Bottom crossbar	1		
Q	Top back panel	1		
R	Middle back panel	1		
S	Bottom back panel	1		
Т	·			
U	U Small drawer left side panel			
V	Small drawer right side panel	2		
W	W Small drawer back panel			
Х	Small drawer bottom panel	2		
Υ	Large drawer front panel	3		
Z	Large drawer left side panel	3		
1	Large drawer right side panel	3		
2	Large drawer back panel	3		
3	Large drawer bottom panel	3		


Assembly

Attaching hutch partition to the hutch fixed panel


a) Install dowel (AA) and bolt (BB) into panel (E).




□ b) Insert lock (CC) into partitions (F) and (G).



 \Box c) Join partitions (F) and (G) to the panel (E) with dowel (AA).



d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.





Wood dowel Cam lock bolt Cam lock Small head Large head

(AA) x 4 (BB) x 4 (CC) x 4


2 Attaching hutch bottom panel

a) Attach stopper (FF) onto panel (H) with screw (KK).
 Install dowel (AA) into panel (H).





 b) Join panel (H) to the assembled body with dowel (AA).



Wood dowel

Stopper

5/8 in. Round head

1 in. Flat head screw

Small head

 $(AA) \times 4$

(**FF**) x 2





screw


(**KK**) x 2






3 Attaching hutch left side panel and middle crossbar


a) Install dowel (AA) and bolt (BB) into panel (B).




 \Box b) Insert lock (CC) into panels (E) and (H),and bar (I).



□ c) Join panels (E) and (H), and bar (I) to the panel (B) with dowel (AA).



d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.




Wood dowel Cam lock bolt Cam lock Small head Large head


(AA) x 5 (BB) x 5 (CC) x 5

Attaching hutch right side panel and top crossbar


a) Install dowel (AA) and bolt (BB) into panel (C).




b) Insert lock (CC) into panels (E) and (H), and bar (I).



c) Join bar (D) and panel (C) to the assembled body with dowel (AA).



d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.



Wood dowel Cam lock bolt Cam lock Small head Large head $(AA) \times 7$ $(BB) \times 5$ $(CC) \times 5$











5 Attaching hutch top panel


a) Install dowel (AA) and bolt (BB) into panel (A).




□ b) Insert lock (CC) into panels (B) and (C).



□ c) Join panel (A) to the assembled body with dowel (AA).



d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.




e) Tighten bar (D) with screw (GG).
 Cover the cam holes with the cover (DD).




Large head

6 Attaching the bottom partition to the bottom fixed panel


a) Install dowel (AA) into panel (0).



c) Tighten panel (0) with screw (GG).



□ b) Join partitions (M) and (N) to the panel (0).



Wood dowel 1 in. Flat head screw Small head

(**AA**) x 4








7 Attaching the bottom left side panel

□ a) Join panel (0) to the panel (K) with dowel (AA).




b) Attach panel (0) with washer (00), spring washer (PP), and bolt (NN), Turn and tighten bolt (NN) with wrench (QQ).

Wood dowel Bolt Washer Spring washer Allen wrench


(AA) x 2 (NN) x 3 (OO) x 3 (PP) x 3 (QQ) x 1

Attaching the bottom right side panel and bottom crossbar


a) Join bar (P) and panel (L) to the panels (0) and (K) with dowel (AA).



b) Attach panel (0) with washer (00), spring washer (PP)
 and bolt (NN), Turn and tighten bolt (NN) with wrench (QQ).




□ c) Tighten bar (P) with screw (HH).






9 Attaching the desk face panel


a) Install dowels (AA) and bolt (BB) into panel (J).




 b) Insert lock (CC) into panels (K) and (L), and partitions (M) and (N).



□ c) Join panel (J) to the assembled body with dowel (AA).



d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.



Wood dowel Cam lock bolt Cam lock Small head Large head

 $8 \times (AA)$

 $(BB) \times 8$


(CC) x 8













Attaching the hutch


a) Install dowel (AA) and bolt (BB) into panel (J).




b) Insert lock (CC) into panels (B) and (C).



c) Join panels (B) and (C) to the assembled body



d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.



Cam lock bolt

Cam lock

Long plastic cover

Small head

Large head

 $(AA) \times 4$

Wood dowel

(BB) x 4

 $(CC) \times 4$

(DD) x 4









Attaching the back panel

a) Install wire plug (MM) into panel (R) as shown.



b) Tighten panels (Q),(R) and (S) to the assembled body with screw (KK) and metal plates (LL) as shown.



5/8 in. Round head screw

Wire plug Metal plate Small head

(**KK**) x 44

 $(MM) \times 1$




 $(LL) \times 6$




12 Assembling the large drawer


a) Tighten panels (Z) and (1) to panel (Y) with screw (GG).




c) Tighten panel (2) to the assembled body with screw (GG).



 \Box b) Slide panel (3) into the grooves on panels (Z) and (1).



d) Tighten handle (II) to panel (Y) with bolt (JJ).



Handle

Handle bolt

1 in. Flat head screw

Small head

/II) v 3

 $(JJ) \times 6$











13 Assembling the small drawer


a) Install dowel (AA) and bolt (BB) into panel (T).




d) Tighten bolt (BB) with lock (CC) in the pre-drilled holes.




b) Insert lock (CC) into panels (U) and (V).




e) Slide panel (X) into the grooves on panels (U) and (V).



c) Join panels (U) and (V) to panel (T) with dowel (AA).



f) Tighten panel (W) to the assembled body with screw (GG).



g) Cover the cam holes with the cover (EE).

Wood dowel

Cam lock bolt

Cam lock Short plastic

1 in.

1 in. Flat head screw

Small head

Large head

(**AA**) x 4

(BB) x 4

(CC) x 4

cover (EE) x 4













14 Inserting the drawer

Insert the drawer into the assembled body as shown.



15 Finalizing the assembly

Install the anti-tipping hardware as shown.



Rectangle	1/2 in. Flat head screw	Plastic anchor	Plastic band	1-1/2 in. Flat head	Small head
metal plate				screw	
(1) x 4	(2) x 2	(3) x 2	(4) x 2	(5) x 2	
	Manage .			Coacacacacac	—RR



Questions, problems, missing parts?

Before returning to the store, call Home Decorators Collection Customer Service.

8 a.m. – 7 p.m., EST, Monday – Friday, 9 a.m. – 6 p.m., EST, Saturday

1-800-998-7021

HOMEDEPOT.COM/HOMEDECORATORS

Retain this manual for future use.