



Square Drain Shower Pan Installation Guide

CLAMP RING INSTALLATION

SUBFLOOR PREP

You must begin with a dry and structurally sound subfloor. If water damage, rotting, or any other structural defects are present, you MUST repair prior to installing your new shower pan. A clean and level subfloor is required for a successful installation. After cleaning the subfloor, use a level to check the subfloor. The subfloor MUST be level so that the shower pan will drain correctly. *Note: a self-leveling mortar can be used to level the subfloor.*

STEP 1

Remove the four screws and discharge the white clamp ring. Install a bead of urethane onto the clamp ring and around each screw as show in picture two. Screw the adapter on using the screws from the clamp ring.



STEP 2

Pre-fit the shower pan and cut to fit the shower area, if needed. You can cut the foam board with a utility knife or a circular saw. Install the cone on the shower pan.



STEP 3

Mix a modified thin-set mortar suitable for the subfloor as per manufacturer specification. Use a 3/8" square notched trowel and apply thin-set mortar to the floor and backside of shower pan. Assure that the thin set is troweled in the same direction. Spreading the thin set with a square notched trowel will assure full coverage. Set the shower pan into place.

STEP 4

Protect the shower pan by using a double layer of cardboard. Take two bags of thin-set and place them in the drain area for extra weight to assure the pan slope stays at a minimum of 2%. The drain cover will be screwed onto the pan just before tile installation.

CONNECTITE® DWV FITTING INSTALLATION

SUBFLOOR PREP

You must begin with a dry and structurally sound subfloor. If water damage, rotting, or any other structural defects are present, you MUST repair prior to installing your new shower pan. A clean and level subfloor is required for a successful installation. After cleaning the subfloor, use a level to check the subfloor. The subfloor MUST be level so that the shower pan will drain correctly. *Note: a self-leveling mortar can be used to level the subfloor.*

STEP 1

Cut the PVC pipe down to 2" below subfloor by using an internal PVC pipe cutter drill bit. Use a 2" CONNECTITE® and follow the easy to install CONNECTITE® installation instructions.



STEP 2

Pre-fit the shower pan and cut to fit the shower area, if needed. You can cut the foam board with a utility knife or a circular saw. If the hole in the subfloor is wider than 4" diameter, use the metal plate to support the area around the PVC pipe. Install the adapter to the CONNECTITE® and follow the easy to install CONNECTITE® installation instructions. The adapter has to sit 1/4" above the level subfloor.



STEP 3

Mix a modified thin-set mortar suitable for the subfloor as per manufacturer specification. Use a 3/8" square notched trowel and apply thin-set mortar to the floor and backside of shower pan. Assure that the thin set is troweled in the same direction. Spreading the thin set with a square notched trowel will assure full coverage. Set the shower pan into place.

STEP 4

Protect the shower pan by using a double layer of cardboard. Take two bags of thin-set and place them in the drain area for extra weight to assure the pan slope stays at a minimum of 2%. The drain cover will be screwed onto the pan just before tile installation.

RUBBER GASKET MUST HAVE ACCESS FROM THE BOTTOM

SUBFLOOR PREP

You must begin with a dry and structurally sound subfloor. If water damage, rotting, or any other structural defects are present, you MUST repair prior to installing your new shower pan. A clean and level subfloor is required for a successful installation. After cleaning the subfloor, use a level to check the subfloor. The subfloor MUST be level so that the shower pan will drain correctly. *Note: a self-leveling mortar can be used to level the subfloor.*

STEP 1

Cut the PVC pipe down to 2" below subfloor by using an internal PVC pipe cutter drill bit. Use a 2" rubber gasket to connect to the 2" waste pipe and to the adapter.



STEP 2

Pre-fit the shower pan and cut to fit the shower area, if needed. You can cut the foam board with a utility knife or a circular saw. If the hole in the subfloor is wider than 4" diameter, use the metal plate to support the area around the PVC pipe. Install the adapter to the rubber gasket. The adapter has to sit 1/4" above the level subfloor.



STEP 3

Mix a modified thin-set mortar suitable for the subfloor as per manufacturer specification. Use a 3/8" square notched trowel and apply thin-set mortar to the floor and backside of shower pan. Assure that the thin set is troweled in the same direction. Spreading the thin set with a square notched trowel will assure full coverage. Set the shower pan in place.

STEP 4

Protect the shower pan by using a double layer of cardboard. Take two bags of thin-set and place them in the drain area for extra weight to assure the pan slope stays at a minimum of 2%. The drain cover will be screwed onto the pan just before tile installation.