

Note on installation

These are peel and stick; once you place them on the wall you can't move them.

There is no wiggle room like setting a tile into mortar.

If you need to cut, you may be able to use a glass cutting hand tool or a wet saw.

Use 1/8 spacers and pre-mixed, non-sanded grout.





CAUTION

All this can not be directly installed on rough surface,
orange peeling wall is unwelcome, smooth surface is required.

The texture must be sanded firstly, a coat of primer should be made secondly ,
after 72 hours curing, tiles can be applied firmly.