

28"-8.5" L X 35.5" H Single Post Wrought Iron Handrails Installation Guide

Tools Required

Tape Measure

Drill

Screwdriver

Level

Safety Gloves

Pencil

Step 1: Measure and Mark

Before installation, measure the length of your 1 - 3 steps accurately. Use a tape measure to determine the exact position where the single post and handrail will be installed. Mark the positions on the steps or floor using a pencil. Ensure that the markings are level and aligned properly to guarantee a stable installation.

Step 2: Install the Single Post

Put on your safety gloves. Place the single post at the marked position. Using a drill, create holes in the floor or step according to the pre-drilled holes on the base of the post. Insert the provided screws through the holes in the post base and into the drilled holes, then use a screwdriver to tighten them firmly. Check the post with a level to make sure it stands upright.

Step 3: Attach the Handrail

Position the 28"-8.5" L handrail onto the single post. Align the connection points carefully. Secure the handrail to the post using the included fasteners. Tighten all the screws evenly to ensure a stable and wobble-free connection. Recheck the entire structure with a level to confirm everything is properly aligned.

Step 4: Final Checks

After installation, give the handrail a gentle shake to check for any looseness. Make sure all screws are tightened securely. Wipe down the handrail and post to remove any dust or smudges left during the installation process. Your wrought iron handrail is now ready for use, providing both safety and style to your outdoor steps.