


Damp It: Lightly dampen surface with water before applying glue.



Glue It: Apply a thin layer of Clear Gorilla Glue on one side of the project. Wipe excess glue off with dry cloth during first 15 minutes of setup. After glue hardens, chip away or sand off excess residue



Clamp It: Clamp for at least two hours and allow 24 hours for a full cure

