INSTRUCTION GUIDE THREAD SEAL TAPE



1	Separate some tape from the roll.	
2	Wrap the tape around the thread in a clockwise motion being sure to cover the threads completely.	
3	After completing the recommend number of revolutions around the thread, simply pull the roll and the tape will snap free easily.	
4	Your pipe is ready to be threaded into the fitting.	

©2020 Oatey SCS. All Rights Reserved. This information is based on data believed to be reliable but Oatey makes no warranties, express or implied, as to its accuracy and assumes no liability arising out of its use. The data listed falls within the normal range of product properties but should not be used to establish specification limits or used alone as the basis of design. Oatey's liability to purchasers is expressly limited to the terms and conditions of sale. Oatey is trademark of Oatey Co. All other trademarks can be found www.Oatey.com.