

Installation Guide for Car Window Sun Shade

Preparation

- Ensure the car window glass is clean and dry (wipe with a cloth if needed) to optimize suction cup adhesion.
- Confirm the sun shade (18" x 20") matches your window size; it fits most sedans, SUVs, trucks, etc.

Installation Steps

- . **Unroll the Sun Shade:** Pull the shade out from its rolled-up state until it reaches the desired length.
- . **Position on Window:** Align the shade with the inner side of the car window, ensuring full coverage of the glass area.
- . **Attach Suction Cups:** Press all 6 suction cups firmly against the clean window glass. Hold each cup for 2–3 seconds to secure adhesion.
- . **Adjust as Needed:** Fine-tune the shade's position to block sunlight effectively. It can be adjusted to fit different window shapes.