
D420, D421, D422, D423, 109606, and 109606W

Slip Joint Extensions


You May Need:



Silicone Seal
Sello de silicona




Wrench
Llave




Tape Measure
Medida de cinta



PTFE Tape
Cinta de PTFE





Tubing Cutter
or Hacksaw
Cortador de tubos o
sierra hacksaw

1. Measure length first and dry fit extension.
2. Place nut on existing tube, then the ferrule or washer.
3. Tighten nut onto extension. Do not overtighten.

Note: Poly extensions should be checked for leakage one or two days after first installation.

1. Mida la longitud primero y la extensión de ajuste seco.
2. Coloque la tuerca en el tubo existente y, a continuación, en la virola o arandela.
3. Apriete la tuerca sobre la extensión. No se sobretentes.

Nota: Las extensiones Poly deben comprobarse para detectar fugas uno o dos días después de la primera instalación.