Installation Guide
MEGABRAND NICHE Recessed Shelves

To help you through the MEGABRAND NICHE installation process, we have provided the following Installation Guide which is intended to provide an easy-to-follow step-by-step process for the installation of your MEGABRAND NICHE recessed shelf whether you are a professional or a novice. Please remember to comply with the recommendations and standards established for such projects from time to time by the National Tile Council of North America, Inc.

INSTALLATION INSTRUCTIONS FOR MEGABRAND NICHE

Overview: first, we describe how to frame the niche: (1) in an existing finished wall, and (2) in a newly constructed wall. Then we detail the rest of the steps: installing horizontal framing, screwing the niche into the framing, installing the drywall (or backer board for a shower) around the niche, waterproofing the gap between the niche flange and the backer board with a bead of silicon, and finally tiling the niche and wall.

1. Framing MEGABRAND NICHE into an existing finished wall (if new construction, skip to paragraph 2):
    a. Locate and mark the center of adjacent framing studs using a stud finder or by tapping the wall.
    b. Draw a level line between the two wall studs.
    c. Place the niche between the two marked studs with the flange walls flush against the wall and trace the outline of the niche on the wall. Be sure the top and bottom lines are level.
    d. Cut out the wall board along the traced lines between the two studs using a drywall saw and utility knife.
2. Measure the distance between vertical studs. (Please note that the distance between the center lines of 2 adjacent studs generally is 16 inches and the niche is designed for that condition.)
    a. If the distance is greater than 16 inches, attach vertical framing to one or both of the vertical studs to accommodate the size of the niche.
    b. If less than 16 inches, widen the framing to accommodate the niche.
3. Measure and cut top and bottom horizontal support framing to a length which permits each to run between and to be fastened to both vertical studs.
4. Level and mechanically fasten the top and bottom horizontal support brackets to both adjacent vertical studs so that the vertical dimension between the horizontal support framing matches the vertical dimension of the predrilled fastening holes on the MEGABRAND NICHE flange.
5. Place the MEGABRAND NICHE in between the framing.
6. Level and mechanically fasten the MEGABRAND NICHE using one framing screw in each pre-drilled hole.
7. Install your drywall or tile backer board around the MEGABRAND NICHE so it’s in accordance with industry standards.
8. Take 100% waterproofing silicone and seal the gap between the wall board and the MEGABRAND NICHE and each of the screw holes.
9. Now apply your setting material and set your tile, marble or stone directly to MEGABRAND NICHE surface.

Guía de instalación
EstantesempotradosMEGABRAND NICHE

Para ayudarlo con el proceso de instalación de MEGABRAND NICHE, hemosprovisto la siguienteGuía de instalación que tieneporobjetivoproporcionarle un proceso de fácilinstalación, paso a paso, para la instalación de suestanteempotradoMEGABRAND NICHE, ya sea usted un profesional o un novato. Recuerderespetar las recomendaciones y estándares para dichosproyectosestablecidospor el National Tile Council of North America, Inc. de tantoentanto.

INSTRUCCIONES DE INSTALACIÓN PARA EL MEGABRAND NICHE

Información general: Describiremos primero cómoenmarcar la celda: (1) enuna pared terminadaexistente, y (2) enuna pared recientementeconstruida. Luego, detallaremos el resto de lospasos: la instalación de un marco horizontal, cómoatornillar la celdadentro del marco, la instalación del panel (o panel posterior para unaducha) alrededor de la celda, la impermeabilización del espacio entre el flanco de la celda y el panel posterior con unagota de silicona, y el azulejado final de la celda y la pared.

1. Enmarcado de MEGABRAND NICHEdentro de una pared terminadaexistente (si la construcciónesnueva, pase al párrafo 2):
    a. Coloque y marque el centro de las columnas de metal adyacentesusando un localizador de columnas o golpeando la pared.
    b. Dibujeunalínea de nivel entre las dos columnas de metal.
    c. Coloque la celda entre las dos columnasmarcadas con losflancos de la pared a nivel contra la pared y trace el contorno de la celdasobre la pared. Asegúrese de que las líneas superior e inferior queden a nivel.
    d. Recorte la placa de pared a lo largo de las líneastrazadas entre las dos columnasusandouna sierra para tabiques y un cuchillomultiuso.
2. Mida la distancia entre las columnasverticales (Sírvasenotar que la distancia entre la líneas del centro de las dos columnasadyacentesesgeneralmente de 16 pulgadas y la celda ha sidodiseñado para respetarestacondición).
    a. Si la distanciaes mayor a 16 pulgadas, adjunteunaestructura vertical a una o ambascolumnasverticales para alojar el tamaño de la celda.
    b. Si la distanciaesmenor a 16 pulgadas, ensanche el marco para alojar la celda.
3. Mida el soporte horizontal superior e inferior hasta un largo que permita que cadaunoquepadentro y que éstos se puedanasegurar a ambascolumnasverticales.
4. Nivele y aseguremecánicamentelosbrazoshorizontales de soporte superior e inferior a las columnasverticalesadyacentes para que la dimensión vertical entre el marco de soporte horizontal concuerde con la dimensión vertical de losorificios de sujeciónpreviamenteperforadosen el brida del MEGABRAND NICHE.
5. Coloque el MEGABRAND NICHEdentro del enmarcado.
6. Nivele y aseguremecánicamente el MEGABRAND NICHE, usando un tornillo de bastidorencadaorificiopreviamenteperforado.
7. Instalesuplaca o panel posterior alrededor del MEGABRAND NICHE para que cumpla con losestándares de la industria.
8. Use silicona impermeable a un 100% y selle el espacio entre la placa de pared y el MEGABRAND NICHE, al igual que cadauno de losorificios de los tornillos.
9. Apliqueahorasu material de sujeción y coloquesuazulejo, mármol o piedradirectamenteen la superficieMEGABRAND NICHE.