

## Installing a ADS1K Drain Saddle



1. Choose a spot on the drain pipe that is convenient for installing the drain saddle and tubing. A horizontal pipe is recommended to minimize the dripping sound.
2. Drill a 1 / 4" hole in the drain pipe, and paste the black sticky pad around the hole.
3. Cut the drain tubing end to make a 45 degree angle. Insert the tubing into the blue quick fitting in the front plate . Insert the tubing into the 1 / 4" hole in the drain pipe, install the back plate, and tighten the two screws with hex nuts while the tubing remains in the hole.
4. Tighten the nut on the Drain Saddle by hand. Pull the tubing lightly to make sure it is secure.