

Technical Bulletin

Framed Gable Vent Installation

Gable vents are designed for decorative and functional application. Expansion and contraction is also a factor when surrounding the vent with trim. Fixed trim should be at least 1/8" away from vent.

