

How-To Prep • Patch • Repair



Use the recommended professional grade **Latex•ite** products and follow the instructions below to attain **Pro-Contractor results** at a fraction of the cost.

For Best Results ...

follow application instructions on each product container. Plan on prep and repair on one day and sealing on the next day.

Trim all grass and vegetation away from the edges of the asphalt surface. Leave nothing overhanging or in contact with the asphalt surface.

Cut out broken or severely cracked areas or deteriorated asphalt using a hammer and cold chisel. If it is deteriorated along driveway edge, install a piece of wood along the edge of the driveway to act as a frame.

Sweep

Sweep and clean off the entire driveway. Remove dirt and pickup loose stones and asphalt from any ruts, potholes or low spots.



Clean

Oil /Gas Spots

Scrub oil, gas spots and other stains with **Latex·ite Driveway Cleaner**.

This full strength penetrating cleaner should be liberally applied to the stain and vigorously scrubbed with a stiff wire brush. Rinse away the dirty residue area with water. Repeat this process until clean. If stain is soft, cut out with chisel and follow repair instructions.



[Read more about Latex·ite Driveway Cleaner](#)

Rinse

After scrubbing problem spots, thoroughly flush the entire driveway with a final rinse.



Prime

Better Bond

Apply **Latex·ite Oil Spot Primer**, an acrylic penetrating primer, to prevent any bleedthrough of minute traces of gas and oil and to promote a better bond of **Latex·ite** sealers to the cleaned area.

Apply **Oil Spot Primer** full strength from the bottle ... spread with a brush. This product goes on white and dries clear. More than one coat may be needed.



[Read more about Latex·ite Oil Spot Primer](#)

Fill

Fine & Medium Cracks

Fill with **Latex·ite 2X Premium Crack Filler**.

Snip off end of spout and pour black rubberized sealant into unsightly cracks up to 1/2".

Fill just below asphalt surface ... do not over fill. Filler will remain pliable ... expanding when hot, contracting when cold.

[Read more about Latex·ite 2X Premium Crack Filler](#)



Trowel

Large Cracks, Depressions & Low Spots

Latex·ite Trowel Patch

is a smooth asphalt repair product. It is designed to repair medium to large cracks, smooth out rough spots and fill minor depressions. Trowel in layers of 1/4" to 1/2". Allow each layer to harden before applying next layer. Build up the patch until level and feather out the edges for a smooth, neat, uniform appearance.



Smooth

Once you finished troweling, give it at least 24 hours to properly cure prior to sealing over it.

[Read more about Latex·ite Trowel Patch](#)



Fill and Tamp

Ruts • Potholes & Cut Out Areas

Fill area to be repaired with **Latex·ite Tamp & Set or Super Patch**, a black stone adhesive mix, until slightly above the asphalt surface. Use end of 2 x 4 or tamp and compact until level with the pavement. Check your work with a straight edge.



Year-Round Repair

Latex·ite Tamp & Set or Super Patch is a multi-purpose Hi-Tech stone compound. Special additives let you repair in any kind of weather ... hot/cold or wet/dry! Just shovel and tamp ... ready for traffic.

[Read more about Latex·ite Super Patch](#)

[Read more about Latex·ite Tamp & Set](#)

CAUTION

Make repairs when pavement temperature is 55 degrees F and rising and no rain is forecast for 24 hours.

[Home](#) | [Products](#) | [How To...](#) | [Site Map](#) | [Contact Us](#)

[Find Your Local Latex·ite Dealer](#)

[Conditions of Use](#)

Email [Dalton Enterprises, Inc.](#)

© Dalton Enterprises, Inc.