

installation instructions:

CABINET COLUMN

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

TOOL & MATERIAL CHECKLIST

- Wood Screws
- 'L' Brackets (optional)
- Power Drill
- Drill Bit

IMPORTANT INFO

- It is highly recommended that you paint or finish your cabinet column before you install it.
- Once installed, you can apply any necessary touch-up paint or finish.
- Clean the installation surface and cabinet block of any debris with a clean cloth or sponge.
- Measure and mark the location where the cabinet column is going to be installed.

IMPORTANT NOTE:

This is an application and project specific product. These are recommendations based on common installation methods and are not manufacturer install instructions. Use good construction practices and common sense when installing this product.

Option 1

1. Cut cabinet column(s) to desired height.
2. Place column in final location and pre-drill holes through the surface-supporting plywood and into the columns. Use at least 2 screws.
3. Screw through plywood into the column. Counter sink screws.

Option 2

1. Cut cabinet column(s) to desired height.
2. Place column in final location. Place "L" brackets in appropriate location and mark the bracket holes in both the plywood and the columns.
3. Pre-drill holes into the surface-supporting plywood and into the columns.
4. Screw "L" brackets into place. Make sure to not screw all the way up through the plywood as the screws will then get in the way of the surface or be exposed.

EXAMPLE DIAGRAM:

