



*Manufacturers* Advanced Composite Materials, Automotive and Apparel  
Specialty Fabrics, Bias Binding, Electrical Insulation,  
Narrow Fabrics, P.V.C. Film, Construction, Survey & Safety Accessories

## **MUTUAL INDUSTRIES INC.**

707 W. GRANGE STREET, PHILADELPHIA, PA 19120

800 523-0888

215 927-6000

FAX: 215 927-3388

CUSTOMER SERVICE LINE

### **6 in. X 1 in. X 6 in. Sod Staples**

#### Suggested Installation Instructions:

1. With geotextile fabric in place in the installation area, secure the fabric with staples every 12 inches.
2. Insert staples along the edges, then along any overlapping portions of additional fabrics and as needed across the length and width of the fabric.