

This reed fencing can be attached to garden wire fences and chain link fences by using plastic cable ties or by using galvanized garden wire lengths cut to about 140mm. How to install reed fencing is to attach this reed screening roll to existing wall and other solid surfaces two lengths of wooden slats attached to the wall near the top and bottom of where the garden screening is to be held.